

**SPLIT TYPE  
ROOM AIR CONDITIONER  
WALL MOUNTED<sup>type</sup>  
INVERTER**

# **SERVICE INSTRUCTION**

<b>Models</b>	<b>Indoor unit</b>	<b>Outdoor unit</b>
	ASU18RLB	AOU18RLB
	ASU24RLB	AOU24RLB

*Refrigerant*  
**R410A**

# CONTENTS

## 1. DESCRIPTION OF EACH CONTROL OPERATION

1. COOLING OPERATION.....	01-01
2. HEATING OPERATION.....	01-02
3. DRY OPERATION.....	01-02
4. AUTO CHANGEOVER OPERATION.....	01-03
5. INDOOR FAN CONTROL.....	01-04
6. OUTDOOR FAN CONTROL.....	01-06
7. LOUVER CONTROL.....	01-07
8. COMPRESSOR CONTROL.....	01-08
9. TIMER OPERATION CONTROL.....	01-09
10. ELECTRONIC EXPANSION VALVE CONTROL.....	01-12
11. TEST OPERATION CONTROL.....	01-12
12. PREVENT TO RESTART FOR 3 MINUTES ( 3 MINUTES ST ).....	01-12
13. FOUR-WAY VALVE EXTENSION SELECT.....	01-12
14. AUTO RESTART.....	01-13
15. MANUAL AUTO OPERATION ( INDOOR UNIT BODY OPERATION ).....	01-13
16. FORCED COOLING OPERATION.....	01-13
17. COMPRESSOR PREHEATING.....	01-14
18. MINIMUM HEAT OPERATION .....	01-14
19. ECONOMY OPERATION.....	01-14
20. HEAT INSULATION CONDITION ( BUILDING INSULATION ).....	01-15
21. THERMO CONTROL ( FOR INDOOR UNIT SENSOR ).....	01-15
22. THERMO CONTROL ( FOR WIRED REMOTE SENSOR ).....	01-15
23. DEFROST OPERATION CONTROL.....	01-16
24. OFF DEFROST OPERATION CONTROL.....	01-18
25. VARIOUS PROTECTIONS.....	01-19

## 2. TROUBLE SHOOTING

2-1 ERROR DISPLAY.....	02-01
2-1-1 INDOOR UNIT AND WIRED REMOTE CONTROLLER DISPLAY.....	02-01
2-1-2 WIRED REMOTE CONTROLLER DISPLAY ( OPTION ).....	02-02
2-2 TROUBLE SHOOTING WITH ERROR CODE.....	02-03
2-3 TROUBLE SHOOTING WITH NO ERROR CODE.....	02-24
2-4 SERVICE PARTS INFORMATION.....	02-33

## 3. APPENDING DATA

3-1 FUNCTION SETTING.....	03-01
3-1-1 INDOOR UNIT.....	03-01
3-1-2 PROCEDURES TO CHANGE THE FUNCTION SETTING FOR WIRELESS RC...	03-05
3-2 THERMISTOR RESISTANCE VALUES.....	03-07
3-2-1 INDOOR UNIT.....	03-07
3-2-2 OUTDOOR UNIT.....	03-07

# ***WALL MOUNTED type INVERTER***

## **1 . DESCRIPTION OF EACH CONTROL OPERATION**

# 1. COOLING OPERATION

A sensor (room temperature thermistor) built in the indoor unit body will usually perceive difference or variation between a set temperature and present room temperature, and controls the operation frequency of the compressor.


- \* If the room temperature is 7°F(3.5°C) higher than a set temperature, the compressor operation frequency will attain to maximum performance.
- \* If the room temperature is 1°F(0.5°C) lower than a set temperature, the compressor will be stopped.
- \* When the room temperature is between +7°F(+3.5°C) to -1°F(-0.5°C) of the setting temperature, the compressor frequency is controlled within the range shown in Table 1 .  
However, the maximum frequency is limited in the range shown in Fig. 1 based on the fan speed mode and the outdoor temperature.

( Table 1 : Compressor frequency range )

	Minimum frequency	Maximum frequency I	Maximum frequency II
AOU18RLB	12rps	104rps	63rps
AOU24RLB	12rps	104rps	72rps

When the compressor operates for 30 minutes continuously at over the maximum frequency II , the maximum frequency is changed from the maximum frequency I to the maximum frequency II .

( Fig. 1 : Outdoor temperature zone )



( Table 2 : Limit of maximum speed based on outdoor temperature )

	Outdoor temp. zone	Indoor fan mode			
		Hi	Me	Lo	Quiet
AOU18RLB AOU24RLB	A zone	104rps	59rps	48rps	38rps
	B zone	104rps	59rps	48rps	38rps
	C zone	86rps	59rps	48rps	38rps
	D zone	63rps	56rps	41rps	34rps
	E zone	63rps	56rps	41rps	34rps
	F zone	63rps	56rps	41rps	34rps

## 2. HEATING OPERATION

A sensor (room temperature thermistor) built in the indoor unit body will usually perceive difference or variation between a set temperature and present room temperature, and controls the operation frequency of the compressor.

- \* If the room temperature is lower by 9°F(4.5°C) than a set temperature, the compressor operation frequency will attain to maximum performance.
- \* If the room temperature is higher 1°F(0.5°C) than a set temperature, the compressor will be stopped.
- \* When the room temperature is between +1°F(+0.5°C) to -9°F(-4.5°C) of the setting temperature, the compressor frequency is controlled within the range shown in Table 3 .

( Table 3 : Compressor frequency range )

	Minimum frequency	Maximum frequency
AOU18RLB	12rps	119rps
AOU24RLB	12rps	119rps

## 3. DRY OPERATION


The compressor frequency shall change according to the temperature, set temperature, and room temperature variation which the room temperature sensor of the indoor unit body has detected as shown in the Table 4 .

However, after the compressor is driven, the outdoor unit shall run at operation frequency of 40rps (AOU18RLB), 40rps (AOU24RLB) for 80 seconds.

( Table 4 : Compressor frequency in Dry mode )

		Operating frequency			Operating frequency
AOU18RLB	X zone	38rps	AOU24RLB	X zone	30rps
	J zone	16rps		J zone	16rps
	Y zone	0rps		Y zone	0rps


( Fig. 2 : Compressor control based on room temperature )



## 4. AUTO CHANGEOVER OPERATION

When the air conditioner is set to the AUTO mode by remote control, operation starts in the optimum mode from among the HEATING, COOLING, DRY and MONITORING modes. During operation, the optimum mode is automatically switched in accordance with temperature changes. The temperature can be set between 64°F(18°C) and 88°F(30°C) in 2°F(1°C) steps.

( Fig. 3 : Operation flow chart )



## 5. INDOOR FAN CONTROL

### 1. Fan speed

( Table 5 : Indoor fan speed )

Operation mode	Air flow mode	Speed (rpm)	
		ASU18RLB	ASU24RLB
Heating	Hi	1260	1430
	Me+	1120	1320
	Me	1020	1220
	Lo	900	1020
	Quiet	790	900
	Cool air prevention	680	720
	S-Lo	270	270
Cooling/ Fan	Hi	1260	1480
	Me	1020	1220
	Lo	900	1020
	Quiet	770	900
Dry		X zone: 770 J zone: 720	X zone: 900 J zone: 850

### 2. FAN OPERATION


The airflow can be switched in 5 steps such as Auto, Quiet, Lo, Me, Hi, while the indoor fan only runs. When fan mode is set at [Auto], it operates on [Me] fan Speed.

### 3. COOLING OPERATION

Switch the airflow [Auto], and the indoor fan motor will run according to a room temperature, as shown in Fig. 4 .

On the other hand, if switched in [Hi]~[Quiet], the indoor motor will run at a constant airflow of [Cool] operation modes Quiet, Lo, Me, Hi, as shown in Table 5 .

( Fig. 4 : Airflow change - over ( Cooling : Auto ) )



TR : Room temperature  
Ts : Setting temperature

### 4. DRY OPERATION


Refer to the Table 5 .

During the dry mode operation, the fan speed setting can not be changed.

## 5. HEATING OPERATION

Switch the airflow [Auto], and the indoor fan motor will run according to a room temperature, as shown in Fig. 5. On the other hand, if switched in [Hi] ~ [Quiet], the indoor motor will run at a constant airflow of [Heat] operation modes Quiet, Lo, Me, High, as shown in Table 5.


( Fig. 5 : Airflow change - over ( Heating : Auto ) )



## 6. COOL AIR PREVENTION CONTROL (Heating mode)

The maximum value of the indoor fan speed is set as shown in Fig. 6 based on the detected temperature by the indoor heat-exchanger sensor on heating mode.


( Fig. 6 : Cool air prevention control )



## 7. MOISTURE RETURN PREVENTION CONTROL (Cooling mode & Dry mode)

Switch the airflow [Auto] at cooling mode, and the indoor fan motor will run as shown in Fig. 7.

( Fig. 7 : Indoor fan control )



( Table 6 : Indoor fan speed )

	Dry			Cooling
	X zone	J zone	Y zone	
ASU18RLB	770rpm	720rpm	0⇔270rpm	770rpm
ASU24RLB	900rpm	850rpm	0⇔270rpm	900rpm

## 6. OUTDOOR FAN CONTROL

### 1. Outdoor Fan Motor

The Table 7 shows the type of the outdoor fan motor.

The control method is different between AC motor and DC motor.

( Table 7 : Type of motor )

	AC Motor	DC Motor
AOU18RLB		○
AOU24RLB		


### 2. Fan Speed

( Table 8 : Outdoor fan speed )

	Zone ※	Cooling	Heating	Dry
AOU18RLB	Y	1050/ 870/ 720/ 530	1100/ 1000/ 780/ 720/ 590/ 480	530
	Z	870/530/300		
	F	300		
	G	250/ 200		
AOU24RLB	Y	1050/ 870/ 720/ 530	1100/ 1000/ 780/ 720/ 590/ 480	530
	Z	870/530/300		
	F	300		
	G	250/ 200		

※ Refer to Fig. 8

( Fig. 8 : Outside air temperature zone selection )



- \* The outdoor fan speed mentioned above depends on the compressor frequency.  
(When the compressor frequency increases, the outdoor fan speed also changes to the higher speed. When the compressor frequency decreases, the outdoor fan speed also changes to the lower speed.)
- \* After the defrost control is operated on the heating mode, the fan speed keeps at the higher speed as Table 9 without relating to the compressor frequency.

( Table 9 : Outdoor fan speed after the defrost )

	Fan speed
AOU18RLB	1100rpm
AOU24RLB	1100rpm

# 7. LOUVER CONTROL

## 1. VERTICAL LOUVER CONTROL

(Function Range)

Each time the button is pressed, the air direction range will change as follow: ( Fig. 9 : Vertical air direction range )

Cooling / Heating / Dry / Fan mode

① ⇄ ② ⇄ ③ ⇄ ④ ⇄ ⑤ ⇄ ⑥


Use the air direction adjustments within the ranges shown above.

- The vertical airflow direction is set automatically as shown, in accordance with the type of operation selected.

Cooling / Dry mode : Horizontal flow ①

Heating mode : Downward flow ⑤

- When the temperature of the air being blown out is low at the start of heating operation or during defrosting, the airflow direction temporarily becomes ① to prevent cold air being blown onto the body.
- During use of the Cooling and Dry modes, do not set the Air Flow Direction Louver in the Heating range ( ④~⑥ ) for long period of time, since water vapor may condense near the outlet louvers and drop of water may drip from the air conditioner. During the Cooling and Dry modes, if the Air Flow Direction Louvers are left in the heating range for around 20 minutes, they will automatically return to position ③ .



## 2. HORIZONTAL LOUVER CONTROL


(Function Range)

Each time the button is pressed, the air direction range will change as follows.


Cooling / Heating / Dry / Fan mode

① ⇄ ② ⇄ ③ ⇄ ④ ⇄ ⑤

( Fig. 10 : Horizontal air direction range )



Horizontal Louver



## 3. SWING OPERATION

### Vertical Airflow Swing Operation

When the swing signal is received from the remote controller, the vertical louver starts to swing.

(Swinging Range)

Cooling / Dry / Fan mode(①⇄③) : ① ⇄ ④

Heating / Fan mode(④⇄⑥) : ③ ⇄ ⑥

- When the indoor fan is S-Lo or Stop mode, the swing operation is interrupted and it stops at either upper end or bottom end.

### Horizontal Airflow Swing Operation

When the swing signal is received from the remote controller, the horizontal louver starts to swing.

(Swinging Range)

Cooling / Heating / Dry / Fan mode : ① ⇄ ⑤

- When the indoor fan is S-Lo or Stop mode, the swing operation is interrupted and it stops at either upper end or bottom end.

### Vertical and Horizontal Airflow Swing Operation

- When the horizontal swing signal is input from remote control, the combination of the vertical and horizontal swing operation is performed.

※ **Power Diffuser doesn't swing in any swing operation.**

## 8. COMPRESSOR CONTROL

### 1. OPERATION FREQUENCY RANGE

The operation frequency of the compressor is different based on the operation mode as shown in the Table 10 .


( Table 10 : Compressor frequency range )

	Cooling		Heating		Dry	
	Minimum	Maximum	Minimum	Maximum	Minimum	Maximum
AOU18RLB	12rps	104rps	12rps	119rps	16rps	38rps
AOU24RLB	12rps	104rps	12rps	119rps	16rps	30rps

### 2. OPERATION FREQUENCY CONTROL AT NORMAL START UP

The compressor frequency soon after the start-up is controlled as shown in the Fig. 11 .

( Fig. 11 : Compressor control at start-up )



(Frequency)

	Frequency I	Frequency II	Frequency III	Frequency IV	Frequency V	Frequency VI
AOU18RLB	40rps	59rps	72rps	80rps	101rps	110rps
AOU24RLB	40rps	59rps	72rps	80rps	101rps	110rps

(Time)

	Time ①	Time ②	Time ③	Time ④	Time ⑤	Time ⑥
AOU18RLB	80sec	110sec	140sec	200sec	350sec	410sec
AOU24RLB	80sec	110sec	140sec	200sec	350sec	410sec

### 3. LIMITATION OF COMPRESSOR FREQUENCY BY OUTDOOR TEMPERATURE

The minimum compressor frequency is limited by outdoor temperature as shown in the Table 11 .

( Table 11 : Limitation of compressor frequency )

[ Cooling/ Dry ]

	32°F (0°C)		50°F (10°C)		104°F (40°C)	
	Under	Over	Under	Over	Under	Over
AOU18RLB	24rps	18rps	12rps	16rps		

[ Heating ]

	37°F (3°C)		45°F (7°C)		104°F (40°C)	
	Under	Over	Under	Over	Under	Over
AOU18RLB	24rps	18rps	16rps	16rps		

[ Cooling/ Dry ]

	32°F (0°C)		50°F (10°C)		104°F (40°C)	
	Under	Over	Under	Over	Under	Over
AOU24RLB	24rps	18rps	12rps	16rps		

[ Heating ]

	37°F (3°C)		45°F (7°C)		104°F (40°C)	
	Under	Over	Under	Over	Under	Over
AOU24RLB	24rps	18rps	16rps	16rps		

## 9. TIMER OPERATION CONTROL

### 9-1 WIRELESS REMOTE CONTROLLER


The Table 12 shows the available timer setting based on the product model.

( Table 12 : Timer setting )


	ON TIMER / OFF TIMER	PROGRAM TIMER	SLEEP TIMER
ASU18RLB	○	○	○
ASU24RLB	○	○	○

#### 1. ON TIMER / OFF TIMER

- OFF timer : When the clock reaches the set time, the air conditioner will be turned off.




- ON timer : When the clock reaches the set time, the air conditioner will be turned on.



#### 2. PROGRAM TIMER

- The program timer allows the OFF timer and ON timer to be used in combination one time.




- Operation will start from the timer setting (either OFF timer or ON timer) whichever is closest to the clock's current timer setting.  
The order of operations is indicated by the arrow in the remote control unit's display.
- SLEEP timer operation cannot be combined with ON timer operation.

### 3. SLEEP TIMER

If the sleep is set, the room temperature is monitored and the operation is stopped automatically. If the operation mode or the set temperature is change after the sleep timer is set, the operation is continued according to the changed setting of the sleep timer from that time ON.


#### In the cooling operation mode

When the sleep timer is set, the setting temperature is increased  $2^{\circ}\text{F}(1^{\circ}\text{C})$ . It increases the setting temperature another  $2^{\circ}\text{F}(1^{\circ}\text{C})$  after 1 hour. After that, the setting temperature is not changed and the operation is stopped at the time of timer setting.



#### In the heating operation mode

When the sleep timer is set, the setting temperature is decreased  $2^{\circ}\text{F}(1^{\circ}\text{C})$ . It decreases the setting temperature another  $2^{\circ}\text{F}(1^{\circ}\text{C})$  every 30 minutes. Upon lowering  $8^{\circ}\text{F}(4^{\circ}\text{C})$  the setting temperature is not changed and the operation stops at the time of timer setting.



## 9-2 WIRED REMOTE CONTROLLER ( OPTION )

The Table 13 shows the available timer setting based on the product model.

( Table 13 : Timer setting )

	ON TIMER / OFF TIMER	WEEKLY TIMER	TEMPERATURE SET BACK TIMER
ASU18RLB	○	○	○
ASU24RLB			


### 1. ON TIMER / OFF TIMER

Same to 9-1 1.ON TIMER / OFF TIMER and shown in those.

### 2. WEEKLY TIMER

This timer function can set operation times of the each day of the week.


All days can be set together,the weekly timer can be used to repeat the timer setting for all of the days.



### 3. TEMPERATURE SET BACK TIMER

This timer function can change setting temperature of setting operation times of the each day of the week.

This can be together with other timer setting.



## 10. ELECTRONIC EXPANSION VALVE CONTROL

The most proper opening of the electronic expansion valve is calculated and controlled under the present operating condition based on the Table 14 .

The compressor frequency, the detected temperature by the discharge temperature sensor, the indoor heat exchanger sensor, the outdoor heat exchanger sensor, and the outdoor temperature sensor.

( Table 14 : The pulse range of the electronic expansion valve control )

	Operation mode	Pulse range
AOU18RLB AOU24RLB	Cooling / Dry mode	Between 32 to 480 pulses.
	Heating mode	

- \* The expansion valve is set at 480 pulses 110seconds after the compressor had stopped.
- \* Initialization will start after 24 hours pass from the last initialization, and the compressor stops
- \* At the time of supplying the power to the outdoor unit, the initialization of the electronic expansion valve is operated (528 pulses are input to the closing direction).

## 11. TEST OPERATION CONTROL

Under the condition where the air conditioner runs, press the test run button of the remote control, and the test operation control mode will appear. During test running, the operation lamp and timer lamp of the air conditioner body twinkle simultaneously. Set the test operation mode, and the compressor will continue to run regardless of whether the room temperature sensor detects. The test operation mode is released if 60 minutes have passed after setting up the test operation.

## 12. PREVENT TO RESTART FOR 3 MINUTES ( 3 MINUTES ST )

The compressor won't enter operation status for 2 minutes and 20 seconds after the compressor is stopped, even if any operation is given.

## 13. FOUR-WAY VALVE EXTENSION SELECT

At the time when the air conditioner is switched from the cooling mode to heating mode, the compressor is stopped, and the four-way valve is switched in 2 minutes and 20 seconds later after the compressor stopped.

## 14. AUTO RESTART

When the power was interrupted by a power failure, etc. during operation, the operation contents at that time are memorized and when power is recovered, operation is automatically started with the memorized operation contents.

When the power is interrupted and recovered during timer operation, since the timer operation time is shifted by the time the power was interrupted, an alarm is given by blinking (7 sec ON/2 sec OFF) the indoor unit body timer lamp.

[ Operation contents memorized when the power is interrupted ]


- Operation mode
- Set temperature
- Set air flow
- Timer mode and set time (set by wireless remote controller)
- Set air flow Direction
- Swing
- ECONOMY operation
- MINIMUM HEAT operation

## 15. MANUAL AUTO OPERATION ( INDOOR UNIT BODY OPERATION )

When the remote control is lost or battery power dissipated, this function will work without the remote control. When MANUAL AUTO button is set more than 3seconds and less than 10seconds, MANUAL AUTO OPERATION will be started as shown in Table 15 .To stop operationpress the MANUAL AUTO button for 3seconds.

( Table 15 : Manual auto operation )

	Manual auto operation
OPERATION MODE	Auto changeover
FAN CONT. MODE	Auto
TIMER MODE	Continuous (No timer setting available)
SETTING TEMP.	75°F(24°C)
SETTING LOUVER	Standard
SWING	OFF
ECONOMY	OFF



## 16. FORCED COOLING OPERATION ( TEST OPERATION )

When FORCED COOLING OPERATION is set, the operation is controlled as shown in Table 16 .

( Table 16 : Forced cooling operation )

	Forced cooling operation
OPERATION MODE	Cooling
FAN CONT. MODE	Hi
TIMER MODE	-
SETTING TEMP.	Room Temp is not controlled
SETTING LOUVER	Horizontal (It is changed follow as setting of remote controller)
SWING	OFF
ECONOMY	-

- Forced cooling operation is started when press MANUAL AUTO button for 10 seconds or more.
- During the forced cooling operation, it operates regardless of room temperature sensor.
- Operation LED and timer LED blink at the same time during the forced cooling operation. They blink for 1 second ON and 1 second OFF on both operation LED and timer LED (same as test operation).
- Forced cooling operation is released after 60 minutes of starting operation or pressing MANUAL AUTO button for 3 seconds.

## 17. COMPRESSOR PREHEATING

When the outdoor heat exchanger temperature is lower than 41°F(5°C) and the all operation has been stopped for 30 minutes, power is applied to the compressor and the compressor is heated. (By heating the compressor, warm air is quickly discharged when operation is started.) When operation was started, and when the outdoor heat exchanger temperature rises to 44.6°F(7°C) or greater, preheating is ended.

## 18. MINIMUM HEAT OPERATION

MINIMUM HEAT OPERATION performs as below when pressing MIN. HEAT button or Weekly timer setting on the remote controller.

( Table 17 : Minimum heat operation )

Mode	Heating
Setting temperature	50°F(10°C)
Fan mode	Auto
LED display	Economy
Defrost operation	Operate as normal

## 19. ECONOMY OPERATION

The ECONOMY operation functions by pressing ECONOMY button on the remote controller. At the maximum output, ECONOMY Operation is approximately 70% of normal air conditioner operation for cooling and heating.

The ECONOMY operation is almost the same operation as below settings.

( Table 18 : Economy operation )

Mode	Cooling/ Dry	Heating
Target temperature	Setting temp.+2°F(+1°C)	Setting temp.-2°F(-1°C)

## 20. HEAT INSULATION CONDITION ( BUILDING INSULATION )

This setting can make the room temperature control more suitable for homes or buildings with high insulation (Function Number 95).


When the thermo sensor is turned ON it controls the compressor frequency at initial start to prevent overshoot in heating or cooling.

## 21. THERMO CONTROL ( FOR INDOOR UNIT SENSOR )


When room temperature is controlled by the Indoor unit sensor, compressor operation is as shown in Fig. 12 and 13 .

But, adjustment is possible by the room temperature correction function setting. ( Function Number 30 or 31)

( Fig. 12 : For cooling operation )



( Fig. 13 : For heating operation )




•  $T_s$  : Setting temperature

## 22. THERMO CONTROL ( FOR WIRED REMOTE SENSOR )


When room temperature is controlled by the Wired remote sensor, compressor operation is as shown in Fig. 14 and 15 .

But, adjustment is possible by the room temperature correction function setting. (Function Number 92 or 93)

( Fig. 14 : For cooling operation )



( Fig. 15 : For heating operation )



•  $T_s$  : Setting temperature

## 23. DEFROST OPERATION CONTROL

### 1. CONDITION OF STARTING THE DEFROST OPERATION

The defrost operation starts as shown in the following Table 19 .

( Table 19 : Condition of starting defrost operation )

Normal defrost	Compressor integrating operation time	
	Less than 40 minutes (AOU18RLB) Less than 40 minutes (AOU24RLB)	More than 40 minutes (AOU18RLB) More than 40 minutes (AOU24RLB)
	Does not operate	Outdoor heat exchanger temp. $\leq 1.4^{\circ}\text{F}(-17^{\circ}\text{C})$ (at outside air temp. $\geq 14^{\circ}\text{F}(-10^{\circ}\text{C})$ ) ----- Outdoor heat exchanger temp. $\leq$ Outside air temp. $-(12.6^{\circ}\text{F} (7^{\circ}\text{C}))$ or Outdoor heat exchanger temp. $\leq -13^{\circ}\text{F} (-25^{\circ}\text{C})$ (at $-4^{\circ}\text{F} (-20^{\circ}\text{C}) \leq$ Outdoor air temp. $< 14^{\circ}\text{F} (-10^{\circ}\text{C})$ ) ----- Outdoor heat exchanger temp. $\leq$ Outside air temp. $-(12.6^{\circ}\text{F} (7^{\circ}\text{C}))$ or Outdoor heat exchanger temp. $\leq -22^{\circ}\text{F}(- 30^{\circ}\text{C})$ (at outside air temp. $< -4^{\circ}\text{F}(-20^{\circ}\text{C})$ )

Integrating defrost	Compressor integrating operation time		
	More than 240 minutes (For continuous operation)	More than 213 minutes (For continuous operation)	Less than 10 minutes* ( For intermittent operation )
	Outdoor heat exchanger temperature below $26.6^{\circ}\text{F}(-3^{\circ}\text{C})$	Outdoor heat exchanger temperature below $23^{\circ}\text{F}(-5^{\circ}\text{C})$	OFF count of the compressor 40 times

\*If the compressor continuous operation time is less than 10 minutes,  
the OFF number of the compressor is counted.  
If any defrost operated, the compressor OFF count is cleared.

### 2. CONDITION OF THE DEFROST OPERATION COMPLETION


Defrost operation is released when the conditions become as shown in Table 20 .

( Table 20 : Defrost release condition )

Release Condition
Outdoor heat exchanger temperature sensor value is higher than $60.8^{\circ}\text{F}(16^{\circ}\text{C})$ or Compressor operation time has passed 15 minutes.

### 3. Defrost Flow Chart

The defrosting shall proceed by the integrating operation time, outdoor temperature and outdoor heat exchanger temperature as follows.



## 24. OFF DEFROST OPERATION CONTROL

When operation stops in the [Heating operation] mode, if frost is adhered to the outdoor unit heat exchanger, the defrost operation will proceed automatically. In this time, if indoor unit operation lamp flashes slowly (7 sec ON / 2 sec OFF), the outdoor unit will allow the heat exchanger to defrost, and then stop.

### 1. OFF DEFROST OPERATION CONDITION


In heating operation, the outdoor heat exchanger temperature is less than 24.8°F(- 4°C), compressor continuous operation more than 10 minutes, and compressor operation integrating time lasts for more than 30 minutes.

### 2. OFF DEFROST END CONDITION

( Table 21 : OFF defrost release condition )

Release Condition
Outdoor heat exchanger temperature sensor value is higher than 60.8°F(16°C) or Compressor operation time has passed 15 minutes.

### OFF Defrost Flow Chart



## 25. VARIOUS PROTECTIONS

### 1. DISCHARGE GAS TEMPERATURE OVERRISE PREVENION CONTROL

The discharge gas thermosensor (discharge thermistor : Outdoor side) will detect discharge gas temperature.

When the discharge temperature becomes higher than Temperature I, the compressor frequency is decreased 20rps, and it continues to decrease the frequency for 20rps every 120 seconds until the temperature becomes lower than Temperature I .

When the discharge temperature becomes lower than Temperature II, the protection control of the compressor frequency will be released.

When the discharge temperature becomes higher than Temperature III, the compressor is stopped and the indoor unit LED starts blinking.

( Table 22 : Discharge temperature over rise prevention control / Release temperature )

Temperature I	Temperature II	Temperature III
219.2°F (104°C)	213.8°F (101°C)	230°F (110°C)

### 2. CURRENT RELEASE CONTROL

The compressor frequency is controlled so that the outdoor unit input current does not exceed the current limit value that was set up with the outdoor temperature.

The compressor frequency returns to the designated frequency of the indoor unit at the time when the frequency becomes lower than the release value.

( Table 23 : Current release operation value / Release value )

#### [ Heating ]

AOU18RLB	
OT (Control / Release)	
62.6°F (17°C)	7.0A / 6.5A
53.6°F (12°C)	9.0A / 8.5A
41°F (5°C)	10.0A / 9.5A
	11.0A / 10.5A

OT : Outdoor Temperature

#### [ Heating ]

AOU24RLB	
OT (Control / Release)	
62.6°F (17°C)	7.0A / 6.5A
53.6°F (12°C)	9.0A / 8.5A
41°F (5°C)	11.0A / 10.5A
	13.0A / 12.5A

OT : Outdoor Temperature

#### [ Cooling ]

AOU18RLB	
OT (Control / Release)	
114.8°F (46°C)	4.5A / 4.0A
104°F (40°C)	6.0A / 5.5A
	7.5A / 7.0A

OT : Outdoor Temperature

#### [ Cooling ]

AOU24RLB	
OT (Control / Release)	
114.8°F (46°C)	4.5A / 4.0A
104°F (40°C)	6.0A / 5.5A
	11.0A / 10.5A

OT : Outdoor Temperature

### 3. ANTIFREEZING CONTROL (Cooling and Dry mode)

The compressor frequency is decrease on cooling & dry mode when the indoor heat exchanger temperature sensor detects the temperature lower than Temperature I. Then, the anti-freezing control is released when it becomes higher than Temperature II.

( Table 24 : Anti-freezing protection operation / Release temperature )

Outdoor temperature	Temperature I	Temperature II
Over than 50°F (10°C)*1 or 54°F (12°C)*2	39.2°F (4°C)	44.6°F (7°C)
Less than 50°F (10°C)*1 or 54°F (12°C)*2		55.4°F (13°C)

\*1. When the temperature drops.

\*2. When the temperature rises.


### 4. COOLING PRESSURE OVERRISE PROTECTION

When the outdoor unit heat exchange sensor temperature rises to 152.6°F(67°C) or greater, the compressor and the outdoor fan motor are stopped and trouble display is performed.

### 5. HIGH TEMPERATURE RELEASE CONTROL (Heating mode)

On heating mode, the compressor frequency is controlled as following based on the detection value of the indoor heat exchanger temperature sensor.

[ Control System ]



# ***WALL MOUNTED type INVERTER***

## **2 . TROUBLE SHOOTING**

## 2-1 ERROR DISPLAY

### 2-1-1 INDOOR UNIT AND WIRED REMOTE CONTROLLER DISPLAY

Please refer the flashing pattern as follows.

Indoor Unit : ASU18 / 24RLB


The OPERATION, TIMER and ECONOMY lamps operate as follows according to the error contents.

Error Contents	Indoor Unit Display			Wired Remote Controller Display	Trouble shooting
	OPERATION [ I ] (Green)	TIMER [ ⌚ ] (Orange)	ECONOMY [ ⌚ ] (Green)		
Serial Communication Error	1 times	1 times	Continuous	11	1
Wired Remote Controller Communication Error	1 times	2 times	Continuous	12	2
Indoor Unit Model Information Error EEPROM Access Abnormal	3 times	2 times	Continuous	32	3
Manual Auto Switch Error	3 times	5 times	Continuous	35	4
Indoor Room Thermistor Error	4 times	1 times	Continuous	41	5
Indoor Heat Ex.(Pipe) Thermistor Error	4 times	2 times	Continuous	42	6
Indoor Unit Fan Motor Error	5 times	1 times	Continuous	51	7
Intake Grille Error	5 times	8 times	Continuous	58	8
Outdoor Unit Main PCB Error	6 times	2 times	Continuous	62	9
Active Filter Error	6 times	4 times	Continuous	64	10
IPM Error	6 times	5 times	Continuous	65	11
Discharge Thermistor Error	7 times	1 times	Continuous	71	12
Heat Ex. (Pipe) Thermistor Error	7 times	3 times	Continuous	73	13
Outdoor Thermistor Error	7 times	4 times	Continuous	74	14
Current Sensor Error	8 times	4 times	Continuous	84	15
Trip Detection	9 times	4 times	Continuous	94	16
Compressor Control Error	9 times	5 times	Continuous	95	17
Outdoor Unit Fan Motor Error	9 times	7 times	Continuous	97	18
4 Way Valve Error	9 times	9 times	Continuous	99	19
Discharge Temp. Error	10 times	1 times	Continuous	A1	20

## 2-1-2 WIRED REMOTE CONTROLLER DISPLAY ( OPTION )

### 1. SELF - DIAGNOSIS

When " Er " in Temperature Display is displayed, inspection of the air conditioning system is necessary. Please consult authorized service personnel.





ex. Self-diagnosis check

### 2. ERROR CODE HISTORY DISPLAY


Up to 16 memorized error codes may be displayed for the indoor unit connected to the remote controller.

1. Stop the air conditioner operation.

2. Press the SET TEMPERATURE buttons  $\nabla$ ,  $\blacktriangle$  simultaneously for 3 seconds or more to start the self-diagnosis.



3. Press the SET TEMPERATURE button to select the error history number.



0 ↔ 1 ↔ 2 ↔ 3 ↔ 4 ↔ 5 ↔ 6 ↔ 7  
F ↔ E ↔ d ↔ c ↔ b ↔ A ↔ 9 ↔ 8

4. Press the SET TEMPERATURE buttons  $\nabla$ ,  $\blacktriangle$  simultaneously for 3 seconds or more or there is no key input for 60 seconds to stop the display.

## 2-2 TROUBLE SHOOTING WITH ERROR CODE

**Trouble shooting 1-1**  
**OUTDOOR UNIT Error Method:**  
**Serial Communication Error**  
**(Serial Reverse Transfer Error)**

**Indicate or Display:**  
 Outdoor Unit : No indication  
 Indoor Unit : Operation lamp: 1 time Flash, Timer lamp: 1 time Flash  
 Economy lamp: Continuous flash.  
**ERROR CODE : [E : 11]**

**Detective Actuators:**

Outdoor unit Main PCB  
 Outdoor unit fan motor

**Detective details:**

When the indoor unit cannot receive the serial signal from Outdoor unit more than 2minutes after power ON, or the indoor unit cannot receive the serial signal more than 15seconds during normal operation.

**Forecast of Cause:**

1. Connection failure    2. External cause    3. Main PCB failure    4. Outdoor unit fan motor failure

Check Point 1-1 : Reset the power and operate

· Does Error indication show again?

YES

NO

Check Point 2 : Check Connection

· Check any loose or removed connection line of Indoor unit and Outdoor unit.  
 >> **If there is an abnormal condition, correct it by referring to Installation Manual or Data & Technical Manual.**

Check Point 1-2: Check external cause such as noise

· Check the complete insulation of the grounding.  
 · Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave).

OK

Check Point 3 : Check the voltage of power supply


· Check the voltage of power supply  
 >> **Check if AC187V (AC208V -10%) - 253V (AC230V +10%) appears at Outdoor Unit Terminal L - N.**



OK

Check Point 4 : Check Serial Signal (Reverse Transfer Signal)


· Check Serial Signal (Reverse Transfer Signal)  
 >> **Check if Indicated value swings between AC90V and AC270V at Outdoor Unit Terminal 1 - 3.**  
 >> **If it is abnormal, Check Outdoor unit fan motor. (PARTS INFORMATION 5)**  
 >> **If Outdoor fan motor is abnormal, replace Outdoor unit fan motor and Main PCB.**  
 >> **If Outdoor fan motor is normal, replace Main PCB.**



<b>Trouble shooting 1-2</b> <b>INDOOR UNIT Error Method:</b> <b>Serial Communication Error</b> <b>(Serial Forward Transfer Error)</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 1 time Flash, Timer lamp: 1 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 11]</b>
--	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Indoor unit Fan motor	<b>Detective details:</b> When the outdoor unit cannot receive the serial signal from Indoor unit more than 10seconds.
--	---

**Forecast of Cause:**  
1. Connection failure    2. External cause    3. Controller PCB failure    4. Indoor unit fan motor failure



<b>Trouble shooting 2</b> <b>INDOOR UNIT Error Method:</b> <b>Wired Remote Controller Communication Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 1 time Flash, Timer lamp: 2 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 12]</b>
---	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Wired remote control	<b>Detective details:</b> When the indoor unit cannot receive the signal from Wired Remote Control more than 1minute during normal operation.
---	--

<b>Forecast of Cause:</b> 1. Terminal connection abnormal    2. Wired remote control failure    3. Controller PCB failure
--

<b>Check Point 1 : Check the connection of terminal</b>
<u>After turning off the power, check &amp; correct the followings.</u> • Check the connection of terminal between remote control and Indoor unit, and check if there is a disconnection of the cable.




<b>Check Point 2 : Check Remote Control and Controller PCB</b>	
• Check Voltage at CN6 (terminal 1-3) of Controller PCB . (Power supply to Remote Control) >> If it is DC12V, Remote Control is failure. (Controller PCB is normal)                    >> Replace Remote Control >> If it is DC 0V, Controller PCB is failure. (Check Remote Control once again) >> Replace Controller PCB ▶ <b><u>Upon correcting the removed connector or miss-wiring, reset the power.</u></b>	

<p><b>Trouble shooting 3</b>  <b>INDOOR UNIT Error Method:</b>  <b>Indoor Unit Model Information Error</b>  <b>EEPROM Access Abnormal</b></p>	<p><b>Indicate or Display:</b>  Outdoor Unit : No indication  Indoor Unit : Operation lamp: 3 time Flash, Timer lamp: 2 time Flash  Economy lamp: Continuous flash.  <b>ERROR CODE : [E : 32]</b></p>
---	---

<p><b>Detective Actuators:</b>  Indoor unit Controller PCB</p>	<p><b>Detective details:</b>  When power is on and there is some below case.  1. When model information of EEPROM is incorrect.  2. When the access to EEPROM failed.</p>
--	---

<p><b>Forecast of Cause:</b>  1. External cause    2. Defective connection of electric components    3. Controller PCB failure</p>
--




**Note : EEPROM**  
EEPROM(Electronically Erasable and Programmable Read Only Memory) is a non-volatile memory which keeps memorized information even if power is turned off. It can change the contents electronically. To change the contents, it uses higher voltage than normal, and it can not change a partial contents. (Rewriting shall be done upon erasing the all contents.) There is a limit in a number of rewriting.

<b>Trouble shooting 4</b> <b>INDOOR UNIT Error Method:</b> <b>Manual Auto Switch Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 3 time Flash, Timer lamp: 5 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 35]</b>
--	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Indicator PCB Manual auto switch	<b>Detective details:</b> When the Manual Auto Switch becomes ON for consecutive 60 or more seconds.
--	---

Forecast of Cause :  
1. Manual auto switch failure    2.Controller PCB and Indicator PCB failure

<b>Check Point 1 : Check the Manual auto switch</b> <ul style="list-style-type: none"> <li>• Check if Manual auto switch is kept pressed.</li> <li>• Check ON/OFF switching operation by using a meter.</li> </ul> <b>&gt;&gt;If Manual Auto Switch is disabled (on/off switching), replace it.</b>	
--	--



<b>Check Point 2 : Replace Controller PCB</b>
<b>▶ If Check Point 1 do not improve the symptom, change Controller PCB and Indicator PCB.</b>

<b>Trouble shooting 5</b> <b>INDOOR UNIT Error Method:</b> <b>Indoor Room Thermistor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 4 time Flash, Timer lamp: 1 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 41]</b>
--	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Room temperature thermistor	<b>Detective details:</b> When Room Temperature Thermistor open or short-circuit is detected.
--	--

Forecast of Cause :  
1. Connector connection failure 2. Thermistor failure 3. Controller PCB failure


**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

**>>Upon correcting the removed connector or miss-wiring, reset the power.**



**Check Point 2 : Remove connector and check Thermistor resistance value**



Thermistor Characteristics (Approx. value)

Temperature (°F)	14°F	23°F	32°F	41°F	50°F	59°F	68°F	77°F
Resistance Value (kΩ)	58.2	44.0	33.6	25.9	20.2	15.8	12.5	10.0

Temperature (°F)	86°F	95°F	104°F	113°F
Resistance Value (kΩ)	8.0	6.5	5.3	4.4

**► If Thermistor is either open or shorted, replace it and reset the power.**



**Check Point 3 : Check voltage of Controller PCB (DC5.0V)**



Make sure circuit diagram of indoor unit and check terminal voltage at Thermistor (DC5.0V)

THERMISTOR (PIPE TEMP.)

THERMISTOR (ROOM TEMP.)

**► If the voltage does not appear, replace Controller PCB.**

<b>Trouble shooting 6</b> <b>INDOOR UNIT Error Method:</b> <b>Indoor Heat Ex.(Pipe)</b> <b>Thermistor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 4 time Flash, Timer lamp: 2 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 42]</b>
--	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Heat Ex. temperature thermistor	<b>Detective details:</b> When Heat Ex. Temperature Thermistor open or short-circuit is detected.
--	--

**Forecast of Cause :**  
 1. Connector connection failure   2. Thermistor failure   3. Controller PCB failure


**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

**>>Upon correcting the removed connector or miss-wiring, reset the power.**



**Check Point 2 : Remove connector and check Thermistor resistance value**



Thermistor Characteristics (Approx. value)

Temperature (°F)	14°F	23°F	32°F	41°F	50°F	68°F
Resistance Value (kΩ)	312.3	233.2	176.0	134.2	103.3	62.9

Temperature (°F)	86°F	104°F	122°F	140°F	149°F
Resistance Value (kΩ)	39.6	25.6	17.1	11.6	10.4


**► If Thermistor is either open or shorted, replace it and reset the power.**



**Check Point 3 : Check voltage of Controller PCB (DC5.0V)**



Make sure circuit diagram of indoor unit and check terminal voltage at Thermistor (DC5.0V)



**► If the voltage does not appear, replace Controller PCB.**

<b>Trouble shooting 7</b> <b><u>INDOOR UNIT Error Method:</u></b> <b>Indoor Unit Fan Motor Error</b>	<b><u>Indicate or Display:</u></b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 5 time Flash, Timer lamp: 1 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 51]</b>
--	---

<b><u>Detective Actuators:</u></b> Indoor unit Controller PCB Indoor unit Fan motor	<b><u>Detective details:</u></b> When the condition that actual frequency of Indoor Fan is below 1/3 of target frequency is continued more than 56 seconds.
---	--

<b><u>Forecast of Cause:</u></b> 1. Fan rotation failure    2. Fan motor winding open    3. Motor protection by surrounding temperature rise 4. Control PCB failure    5. Indoor unit fan motor failure
---

<b>Check Point 1 : Check rotation of Fan</b>
<ul style="list-style-type: none"> <li>· Rotate the fan by hand when operation is off. (Check if fan is caught, dropped off or locked motor)</li> <li><b>&gt;&gt;<u>If Fan or Bearing is abnormal, replace it.</u></b></li> </ul>

↓ **OK**

<b>Check Point 2 : Check ambient temp. around motor</b>
<ul style="list-style-type: none"> <li>· Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat)</li> <li><b>&gt;&gt;<u>Upon the temperature coming down, restart operation.</u></b></li> </ul>

↓ **OK**

<b>Check Point 3 : Check Indoor unit fan motor</b>
<ul style="list-style-type: none"> <li>· Check Indoor unit fan motor. (PARTS INFORMATION 4)</li> <li><b>&gt;&gt;<u>If Indoor unit fan motor is abnormal, replace Indoor unit fan motor.</u></b></li> </ul>


↓ **OK**

<b>Check Point 4 : Replace Controller PCB</b>
<ul style="list-style-type: none"> <li><b>▶ <u>If Check Point 1- 3 do not improve the symptom, replace Controller PCB.</u></b></li> </ul>

<b>Trouble shooting 8</b> <b>INDOOR UNIT Error Method:</b> <b>Intake Grille Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 5 time Flash, Timer lamp: 8 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 58]</b>
---	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Micro switch	<b>Detective details:</b> When the Micro switch is detected open while running the compressor.
---	---

**Forecast of Cause :**  
1. Micro switch failure    2. Shorted connector/ wire    3. Controller PCB failure

<b>Check Point 1 : Check Limit switch</b> <ul style="list-style-type: none"> <li>· Check operation of Micro switch. (any blocking by dust, etc.)</li> <li>· Remove Micro switch and check ON/OFF switching operation by using a meter.</li> </ul> <b>&gt;&gt;If Micro switch is detective, replace it.</b>	
---	---



<b>Check Point 2 : Check Connector (CN11) / Wire</b> <ul style="list-style-type: none"> <li>· Check loose contact of CN11 /shorted wire (pinched wire).</li> </ul> <b>&gt;&gt;Replace Micro switch if the wire is abnormal</b>
---




<b>Check Point 3 : Replace Controller PCB</b> <b>▶ If Check Point 1 &amp; 2 do not improve the symptom, change Controller PCB.</b>
---

<b>Trouble shooting 9</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit Main PCB Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 6 time Flash, Timer lamp: 2 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 62]</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB	<b>Detective details:</b> Access to EEPROM failed due to some cause after outdoor unit started.
--	--

<b>Forecast of Cause:</b> 1. External cause (Noise, temporary open, voltage drop)    2. Main PCB failure
---



<b>Trouble shooting 10</b> <b>OUTDOOR UNIT Error Method:</b> <b>Active Filter Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 6 time Flash, Timer lamp: 4 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 64]</b>
---	--

<b>Detective Actuators:</b> Outdoor unit Main PCB Active filter module	<b>Detective details:</b> When inverter input DC voltage is higher than 425V or lower than 80V. When a momentary power cut off occurred on low voltage
--	--

<u>Forecast of Cause :</u> 1. External cause    2. Connector connection failure    3. Main PCB failure    4. Active filter module failure
--

<b>Check Point 1 : Check external cause at Indoor and Outdoor (Voltage drop or Noise)</b>
<ul style="list-style-type: none"> <li>• Instant drop : Check if there is a large load electric apparatus in the same circuit.</li> <li>• Momentary power failure : Check if there is a defective contact or leak current in the power supply circuit.</li> <li>• Noise : Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave) Check the complete insulation of grounding.</li> </ul>



<b>Check Point 2 : Check connection of Connector</b>
<ul style="list-style-type: none"> <li>• Check if connector is removed.</li> <li>• Check erroneous connection.</li> <li>• Check if cable is open.</li> </ul> <p><b>&gt;&gt;Upon correcting the removed connector or miss-wiring, reset the power.</b></p>



<b>Check Point 3 : Check Active filter module</b>
<ul style="list-style-type: none"> <li>• Check Active filter module. <b>(PARTS INFORMATION 6)</b></li> </ul> <p><b>&gt;&gt;If Active filter module is abnormal, replace it.</b></p>



<b>Check Point 4 : Replace Main PCB</b>
<p><b>► If Check Point 1 - 3 do not improve the symptom, change Main PCB.</b></p>

<b>Trouble shooting 11</b> <b>OUTDOOR UNIT Error Method:</b> <b>IPM Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 6 time Flash, Timer lamp: 5 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 65]</b>
---	--

<b>Detective Actuators:</b> Outdoor unit Main PCB Outdoor unit Transistor PCB (14L) Compressor	<b>Detective details:</b> ① When more than normal operating current to IPM in Main PCB flows, the compressor stops. ② After the compressor restarts, if the same operation is repeated within 40sec, the compressor stops again. ③ If ① and ② repeats 5 times, the compressor stops permanently.
---	---

<b>Forecast of Cause :</b> 1. Defective connection of electric components    2. Outdoor Fan Operation failure 3. Outdoor Heat Exchanger clogged                    4. Compressor failure 5. Main PCB failure    6. Transistor PCB failure
--

<b>Check Point 1 : Check connections of Outdoor Unit Electrical Components</b>
<ul style="list-style-type: none"> <li>• Check if the terminal connection is loose.</li> <li>• Check if connector is removed.</li> <li>• Check erroneous connection.</li> <li>• Check if cable is open.</li> </ul> <b>&gt;&gt; Upon correcting the removed connector or miss-wiring, reset the power.</b>



<b>Check Point 2 : Check Outdoor Fan, Heat Exchanger</b>
<ul style="list-style-type: none"> <li>• Is there anything obstructing the air distribution circuit?</li> <li>• Is there any clogging of Outdoor Heat Exchanger?</li> <li>• Is the Fan rotating by hand when operation is off ?</li> </ul> <b>&gt;&gt; If the Fan Motor is locked, replace it.</b>



<b>Check Point 3 : Check Outdoor Fan</b>
<ul style="list-style-type: none"> <li>• Check Outdoor Fan Motor. (Refer to Trouble shooting 18)</li> </ul> <b>&gt;&gt; If the Fan Motor is failure, replace it.</b>



<b>Check Point 4 : Check Compressor</b>
<ul style="list-style-type: none"> <li>• Check Compressor. (PARTS INFORMATION 2)</li> </ul>



<b>Check Point 5 : Check Transistor PCB</b>
<ul style="list-style-type: none"> <li>• Check Transistor PCB. (PARTS INFORMATION 7)</li> </ul>



<b>Check Point 6 : Replace Main PCB</b>
<b>► If Check Point 1 ~ 5 do not improve the symptom, change Main PCB.</b>

<b>Trouble shooting 12</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Thermistor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 7 time Flash, Timer lamp: 1 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 71]</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB Discharge pipe temperature thermistor	<b>Detective details:</b> When Discharge pipe temperature thermistor open or short-circuit is detected at power ON or while running the compressor.
---	--

**Forecast of Cause :**  
1. Connector connection failure 2. Thermistor failure 3. Main PCB failure

**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

**>>Upon correcting the removed connector or miss-wiring, reset the power.**



**Ω**

**Check Point 2 : Remove connector and check Thermistor resistance value**

Thermistor Characteristics (Approx. value)

Temperature (°F)	14°F	23°F	32°F	41°F	50°F	68°F	86°F	104°F	122°F
Resistance Value (kΩ)	292.9	221.1	168.6	129.8	100.9	62.5	40.0	26.3	17.8

Temperature (°F)	140°F	158°F	176°F	194°F	212°F	230°F	248°F
Resistance Value (kΩ)	12.3	8.7	6.3	4.6	3.4	2.6	2.0

**► If Thermistor is either open or shorted, replace it and reset the power.**



**DC**

**Check Point 3 : Check voltage of Main PCB (DC5.0V)**

Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)

**► If the voltage does not appear, replace Main PCB.**

<b>Trouble shooting 13</b> <b>OUTDOOR UNIT Error Method:</b> <b>Heat Ex.(Pipe) Thermistor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 7 time Flash, Timer lamp: 3 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 73]</b>
---	--

<b>Detective Actuators:</b> Outdoor unit Main PCB Heat exchanger thermistor	<b>Detective details:</b> When Heat exchanger temperature thermistor open or short-circuit is detected at power ON or while running the compressor.
---	--

**Forecast of Cause :**  
1. Connector connection failure 2. Thermistor failure 3. Main PCB failure

**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

**>>Upon correcting the removed connector or miss-wiring, reset the power.**



**Check Point 2 : Remove connector and check Thermistor resistance value**

Thermistor Characteristics (Approx. value)

Temperature (°F)	14°F	23°F	32°F	41°F	50°F	68°F	86°F	104°F	122°F
Resistance Value (kΩ)	27.8	21.0	16.1	12.4	9.6	6.0	3.8	2.5	1.7

Temperature (°F)	140°F	158°F	176°F
Resistance Value (kΩ)	1.2	0.8	0.6

**► If Thermistor is either open or shorted, replace it and reset the power.**



**Check Point 3 : Check voltage of Main PCB (DC5.0V)**

Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)

**THERMISTOR (PIPE)**

**THERMISTOR (DISCHARGE)**

**THERMISTOR (OUTDOOR)**

**► If the voltage does not appear, replace Main PCB.**

<b>Trouble shooting 14</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Thermistor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 7 time Flash, Timer lamp: 4 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 74]</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB Outdoor thermistor	<b>Detective details:</b> When Outdoor temperature thermistor open or short-circuit is detected at power ON or while running the compressor.
--	---

**Forecast of Cause :**  
1. Connector connection failure 2. Thermistor failure 3. Main PCB failure

**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

>>**Upon correcting the removed connector or miss-wiring, reset the power.**



**Check Point 2 : Remove connector and check Thermistor resistance value**

Thermistor Characteristics (Approx. value)

Temperature (°F)	-4°F	5°F	14°F	23°F	32°F	41°F	50°F	68°F	86°F
Resistance Value (kΩ)	115.2	84.2	62.3	46.6	35.2	26.9	20.7	12.6	8.0

Temperature (°F)	95°F	104°F	113°F	122°F	131°F
Resistance Value (kΩ)	6.4	5.2	4.2	3.5	2.8

▶ **If Thermistor is either open or shorted, replace it and reset the power.**



**Check Point 3 : Check voltage of Main PCB (DC5.0V)**

Make sure circuit diagram of outdoor unit and check terminal voltage at Thermistor (DC5.0V)


THERMISTOR (PIPE) BLACK 1 1  
BLACK 2 2  
BLACK 3 3  
BLACK 4 4 CN61  
THERMISTOR (DISCHARGE)  
THERMISTOR (OUTDOOR) BLACK 1 1  
BLACK 2 2  
BLACK 3 3 CN62

▶ **If the voltage does not appear, replace Main PCB.**

<b>Trouble shooting 15</b> <b>OUTDOOR UNIT Error Method:</b> <b>Current Sensor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 8 time Flash, Timer lamp: 4 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 84]</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB	<b>Detective details:</b> When Input Current Sensor has detected 0A, while Inverter Compressor is operating at higher than 56rps, after 1minute upon starting the Compressor. (Except during the defrost operation)
--	--

<b>Forecast of Cause :</b> 1. Defective connection of electric components    2. External cause    3. Main PCB failure
--



<b>Trouble shooting 16</b> <b>OUTDOOR UNIT Error Method:</b> <b>Trip Detection</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 9 time Flash, Timer lamp: 4 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 94]</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB Compressor	<b>Detective details:</b> <ul style="list-style-type: none"> <li>▪ <b>"Protection stop</b> by overcurrent generation after inverter compressor start processing completed" generated consecutively 10 times.</li> <li>* The number of generations is reset if the start-up of the compressor succeeds.</li> </ul>
--	--

<b>Forecast of Cause :</b> <ol style="list-style-type: none"> <li>1. Outdoor unit fan operation defective, foreign matter on heat exchanger, excessive rise of ambient temperature</li> <li>2. Main PCB failure</li> <li>3. Compressor failure (lock, winding short)</li> </ol>
---

<b>Check Point 1 :</b> Check the outdoor unit fan operation, heat exchanger, ambient temperature
<ul style="list-style-type: none"> <li>▪ No obstructions in air passages?</li> <li>▪ Heat exchange fins clogged</li> <li>▪ Outdoor unit fan motor check</li> <li>▪ Ambient temperature not raised by the effect of other heat sources?</li> <li>▪ Discharged air not sucked in?</li> </ul>



<b>Check Point 2 :</b> Replace Main PCB
▶ <b><u>If Check Point 1 do not improve the symptom, change Main PCB.</u></b>



<b>Check Point 3 :</b> Replace Compressor
▶ <b><u>If Check Point 2 do not improve the symptom, change Compressor.</u></b>

<b>Trouble shooting 17</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Compressor Motor Control Error</b>	<b><u>Indicate or Display:</u></b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 9 time Flash, Timer lamp: 5 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 95]</b>
---	---

<b><u>Detective Actuators:</u></b> Outdoor unit Main PCB Compressor	<b><u>Detective details:</u></b> ① If the detected rotor location is out of phase with actual rotor location more than 90°, the compressor stops. After the compressor restarts, if the same operation is repeated ② within 40sec, the compressor stops again. ③ If ① and ② repeats 5 times, the compressor stops permanently.
---	--

<b><u>Forecast of Cause :</u></b> 1. Defective connection of electric components    2. Main PCB failure    3. Compressor failure
---

<b>Check Point 1 : Check Noise from Compressor</b>
<ul style="list-style-type: none"> <li>• Turn on Power and check operation noise.</li> </ul> <p>▶ <b><u>If an abnormal noise show, replace Compressor.</u></b></p>



<b>Check Point 2 : Check connection of around the Compressor components</b>
For Compressor Terminal, Main PCB <ul style="list-style-type: none"> <li>• Check if connector is removed.</li> <li>• Check erroneous connection.</li> <li>• Check if cable is open.</li> </ul> (Refer to PARTS INFORMATION 2) <p>&gt;&gt;<b><u>Upon correcting the removed connector or miss-wiring, reset the power.</u></b></p>



<b>Check Point 3 : Replace Main PCB</b>
▶ <b><u>If Check Point 1,2 do not improve the symptom, change Main PCB.</u></b>



<b>Check Point 4 : Replace Compressor</b>
▶ <b><u>If Check Point 3 do not improve the symptom, change Compressor.</u></b>

<b>Trouble shooting 18</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit Fan Motor Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 9 time Flash, Timer lamp: 7 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 97]</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB Outdoor unit Fan motor	<b>Detective details:</b> ① When outdoor fan rotation speed is less than 100rpm in 20 seconds after fan motor starts, fan motor stops. ② After fan motor restarts, if the same operation within 60sec is repeated 3 times in a row, compressor and fan motor stops. ③ If ① and ② repeats 5 times in a row, compressor and fan motor stops permanently.
--	---

<b>Forecast of Cause:</b> 1. Fan rotation failure   2. Motor protection by surrounding temperature rise   3. Main PCB failure 4. Outdoor unit fan motor
---

<b>Check Point 1 : Check rotation of Fan</b>
• Rotate the fan by hand when operation is off. (Check if fan is caught, dropped off or locked motor) <b>&gt;&gt;If Fan or Bearing is abnormal, replace it.</b>


↓  
OK

<b>Check Point 2 : Check ambient temp. around motor</b>
• Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat) <b>&gt;&gt;Upon the temperature coming down, restart operation.</b>

↓  
OK

<b>Check Point 3 : Check Outdoor unit fan motor</b>
• Check Outdoor unit fan motor. (PARTS INFORMATION 5) <b>&gt;&gt;If Outdoor unit fan motor is abnormal, replace Outdoor unit fan motor.</b>

↓  
OK

<b>Check Point 4 : Check Output Voltage of Main PCB</b> • Check outdoor unit circuit diagram and the voltage. (Measure at Main PCB side connector)	<div style="border: 1px solid black; padding: 5px; display: inline-block;">DC</div> 						
	<table border="1" style="width: 100%;"> <thead> <tr> <th>Read wire</th> <th>DC voltage</th> </tr> </thead> <tbody> <tr> <td>Red - Black (Vm)</td> <td>240 - 400V</td> </tr> <tr> <td>White - Black (Vcc)</td> <td>15 ± 1.5V</td> </tr> </tbody> </table>	Read wire	DC voltage	Red - Black (Vm)	240 - 400V	White - Black (Vcc)	15 ± 1.5V
Read wire	DC voltage						
Red - Black (Vm)	240 - 400V						
White - Black (Vcc)	15 ± 1.5V						
<b>▶ If the voltage is not correct, replace Main PCB.</b>							

<b>Trouble shooting 19</b> <b>OUTDOOR UNIT Error Method:</b> <b>4 Way Valve Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 9 time Flash, Timer lamp: 9 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : 99]</b>
---	--

<b>Detective Actuators:</b> Indoor unit Controller PCB Heat Ex. temperature thermistor Room temperature thermistor 4-way valve Main PCB	<b>Detective details:</b> When the indoor heat exchanger temperature is compared with the room temperature, and either following condition is detected continuously two times, the compressor stops. <ul style="list-style-type: none"> <li>▪ Cooling or Dry operation  [Indoor heat exchanger temp.] - [Room temp.] &gt; 40°F(20°C)</li> <li>▪ Heating operation  [Indoor heat exchanger temp.] - [room temp.] &lt; - 40°F(-20°C)</li> </ul> If the same operation is repeated 5 times, the compressor stops permanently.
--	---

**Forecast of Cause :**

1. Connector connection failure   2. Thermistor failure   3. Coil failure   4. 4-way valve failure  
5. Main PCB failure   6. Controller PCB failure

**Check Point 1 : Check connection of Connector**

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

**>> Upon correcting the removed connector or miss-wiring, reset the power.**



**Check Point 2 : Check each thermistor**

- Isn't it fallen off the holder?
- Is there a cable pinched?

**>> Check characteristics of thermistor (Refer to Trouble shooting 5, 6),  
If defective, replace the thermistor**



**Check Point 3 : Check the solenoid coil and 4-way valve**

[ Solenoid coil ]

- Remove CN500 from PCB and check the resistance value of coil.  
Resistance value is 1.88kΩ ~ 2.29kΩ at 68°F (20°C).

**>> If it is Open or abnormal resistance value, replace Solenoid Coil.**

[ 4-way valve ]

- Check each piping temperature, and the location of the valve by the temperature difference.

**>> If the value location is not proper, replace 4-way valve.**



**Check Point 4 : Check the voltage of 4-way valve**


- Check the voltage CN500 of Main PCB.  
**Check if AC187V(AC208V-10%) - 253V(AC230V+10%) appears at CN 30 or CN500 of Main PCB.**

[ Heating operation ]

**>> If it is not voltage, Replace Main PCB.**

[ Cooling operation ]

**>> If it is voltage, Replace Main PCB.**




**Check Point 5 : Replace Controller PCB**

**► If Check Point 1- 4 do not improve the symptom, replace Controller PCB.**

<b>Trouble shooting 20</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Temperature Error</b>	<b>Indicate or Display:</b> Outdoor Unit : No indication Indoor Unit : Operation lamp: 10 time Flash, Timer lamp: 1 time Flash Economy lamp: Continuous flash. <b>ERROR CODE : [E : A1]</b>
---	---

<b>Detective Actuators:</b> Outdoor unit Main PCB Discharge temperature thermistor	<b>Detective details:</b> <ul style="list-style-type: none"> <li>▪ "Protection stop by "discharge temperature <math>\geq 230^{\circ}\text{F}(110^{\circ}\text{C})</math> during compressor operation"" generated 2 times within 24 hours.</li> </ul>
--	---

<b>Forecast of Cause :</b>	1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation failure, foreign matter on heat exchanger 4. Discharge temperature thermistor failure 5. Insufficient refrigerant 6. Main PCB failure
----------------------------	---



## 2-3 TROUBLE SHOOTING WITH NO ERROR CODE

### Trouble shooting 21

Indoor Unit - No Power

#### Forecast of Cause:

1. Power supply failure
2. External cause
3. Electrical components defective

#### Check Point 1 : Check Installation Condition

- Isn't the breaker down?
- Check loose or removed connection cable.
- >> **If abnormal condition is found, correct it by referring to Installation Manual or Data & Technical Manual.**

↓  
OK

#### Check Point 2 : Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line.  
(Neon bulb or electric equipment that may cause harmonic wave)  
Check the complete insulation of grounding.

↓  
OK

#### Check Point 3 : Check Electrical Components



- Check the voltage of power supply.
- >> **Check if AC187 - 253V appears at Outdoor Unit Terminal L - N.**

↓  
YES

- Check Fuse in Main PCB.  
>> **If Fuse is open, check if the wiring between Terminal and Main PCB is loose, and replace Fuse.**
- Check Varistor in Main PCB.  
>> **If Varistor is defective, there is a possibility of an abnormal power supply. Check the correct power supply and replace Varistor. Upon checking the normal power supply, replace Varistor.**

## Trouble shooting 22

Outdoor Unit - No Power

### Forecast of Cause:

1. Power supply failure
2. External cause
3. Electrical Components defective

#### Check Point 1 : Check Installation Condition

- Isn't the breaker down?
- Check loose or removed connection cable.
- >>If abnormal condition is found, correct it by referring to Installation Manual or Data & Technical Manual.**

↓  
OK

#### Check Point 2 : Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line.  
(Neon bulb or electric equipment that may cause harmonic wave)  
Check the complete insulation of grounding.

↓  
OK

#### Check Point 3 : Check Electrical Components



- Check the voltage of power supply.  
**>> Check if AC187 - 253V appears at Outdoor Unit Terminal L - N.**

↓  
YES

- Check Fuse in Main PCB.  
**>> If Fuse is open, check if the wiring between Terminal and Main PCB is loose, and replace Fuse.**
- Check Varistor in Main PCB.  
**>> If Varistor is defective, there is a possibility of an abnormal power supply. Check the correct power supply and replace Varistor. Upon checking the normal power supply, replace Varistor.**

↓  
OK

▶ **If the symptom does not change by above Check 3, replace Main PCB.**

## Trouble shooting 23

No Operation (Power is ON)

### Forecast of Cause:

1. Setting/ Connection failure
2. External cause
3. Electrical component defective

### Check Point 1 : Check indoor and outdoor installation condition

- Indoor Unit - Check incorrect wiring between Indoor Unit - Remote Control.  
Or, check if there is an open cable connection.
- Are these Indoor Unit, Outdoor Unit, and Remote Control suitable model numbers to connect?  
**>> If there is some abnormal condition, correct it by referring to Installation manual and Data & Technical Manual.**

OK

Turn off Power and check/ correct followings.

- Is there loose or removed communication line of Indoor Unit and Outdoor Unit?

OK

### Check Point 2 : Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line.  
(Neon bulb or electric equipment that may cause harmonic wave)  
Check the complete insulation of grounding.

OK

### Check Point 3 : Check Electrical Components at Indoor and Outdoor

- Check Voltage at CNC01 (terminal 1-3) of Controller PCB.  
(Power supply to Remote Control)  
**>> If it is DC12V, Remote Control is failure. (Controller PCB is normal) >> Replace Remote Control**  
**>> If it is DC 0V, Controller PCB is failure. (Check Remote Control once again)**  
**>> Check Indoor unit fan motor. (PARTS INFORMATION 4)**  
    If it is normal, replace Controller PCB.  
    If it is abnormal, replace Indoor unit fan motor and Controller PCB.  
**>> If the symptom does not change by above Check 1, 2, 3, replace Main PCB of Outdoor unit.**



## Trouble shooting 24

No Cooling / No Heating

### Forecast of Cause:

1. Indoor Unit error
2. Outdoor Unit error
3. Effect by surrounding environment
4. Connection pipe / Connection wire failure
5. Refrigeration cycle failure

#### Check Point 1 : Check Indoor unit

- Does Indoor unit Fan run on High fan?
- Is Air filter dirty?
- Is Heat exchanger clogged?
- Check if Energy save function is operated.

↓ OK

#### Check Point 2 : Check Outdoor unit operation

- Check if Outdoor unit is operating
- Check any objects that obstruct the air flow route.
- Check clogged Heat Exchanger.
- Is the Valve open?

↓ OK

#### Check Point 3 : Check Site condition

- Is capacity of Indoor unit fitted to room size?
- Any windows open? or direct sunlight ?

↓ OK


#### Check Point 4 : Check Indoor / Outdoor installation condition

- Check connection pipe (specified pipe length & Pipe diameter?)
- Check any loose or removed communication line.
- >> **If there is an abnormal condition, correct it by referring to Installation Manual or Data & Technical Manual.**

↓ OK



#### Check Point 5 : Check Refrigeration cycle

- Check if Strainer is clogged (Refer to the figure at right).
- Measure Gas Pressure and if there is a leakage, correct it.
- >> **When recharging the refrigerant, make sure to perform vacuuming, and recharge the specified amount.**
- Check EEV (PARTS INFORMATION 3)
- Check Compressor (PARTS INFORMATION 1,2)
- Check Heater Unit (PARTS INFORMATION 8)



### Attention

Strainer normally does not have temperature difference between inlet and outlet as shown in ①, but if there is a difference like shown in ②, there is a possibility of inside clogged. In this case, replace Strainer.



### Trouble shooting 25

#### Abnormal Noise

#### Forecast of Cause :

1. Abnormal installation (Indoor/ Outdoor)
2. Fan failure (Indoor/ Outdoor)
3. Compressor failure (Outdoor)

#### Diagnosis method when abnormal noise is occurred

- Abnormal noise is coming from Indoor unit.  
(Check and correct followings)

- Is Main unit installed in stable condition?
- Is the installation of air suction grille and front panel normal?

OK

- Is Fan broken or deformed?
- Is the screw of Fan loose?
- Is there any object which obstruct the Fan rotation?

- Abnormal noise is coming from Outdoor unit.  
(Check and correct followings)

- Is Main unit installed in stable condition?
- Is Fan guard installed normally?

OK

- Is Fan broken or deformed?
- Is the screw of Fan loose?
- Is there any object which obstruct the Fan rotation?

OK

- Check if vibration noise by loose bolt or contact noise of piping is happening.

OK

- Is Compressor locked?  
>> Check Compressor (PARTS INFORMATION 1,2)

### Trouble shooting 26

#### Water Leaking

#### Forecast of Cause:

1. Erroneous installation
2. Drain hose failure

#### Diagnosis method when water leak occurs

- Is Main unit installed in stable condition?
- Is Main unit broken or deformed at the time of transportation or maintenance?

OK

- Is Drain hose connection loose?
- Is there a trap in Drain hose?
- Is Drain hose clogged?

OK


- Is Fan rotating?

#### Diagnosis method when water is spitting out.

- Is the filter clogged?

OK

- Check Gas pressure and correct it if there was a gas leak.



**Trouble shooting 27**

Too Warm

Forecast of Cause :

1. House insulation setting has not been changed.
2. Temperature sensing location has not been changed.
3. Installation location of the wired remote.
4. Function settings have not been changed.

**Check Point 1 : Check insulation level of structure of house**

Is insulation level greater than R-13.

YES

**Check Point 1-1 : Check Function Setting**

If insulation level is greater than R-13 set function 95 to 01. (Ref.)

Function Number	Setting Value	Setting Description
95	00	Standard insulation
	01	High insulation

※ Please reference the APPENDING DATA

OK

**Check Point 1-2 : Check effects of Function Setting change**

Is the space still too warm in relation to set point.

Too warm

NO

**Check Point 2 : Verify room temperature sensing location**

Do you want room temperature sensed at the wired remote controller (Wired remote sensor) or by they build in sensor inside the unit (Indoor unit sensor).


“Wired remote sensor”

TO NEXT PAGE

“Indoor unit sensor”

**Check Point 3 : Check the remote controller display**


Is the "Thermo Sensor Icon" displayed on the screen?



YES

**Check Point 3-1 : Check the remote controller**

Hold down the THERMO SENSOR button until the thermo sensor icon is turned off.



Too warm

NO

**Check Point 4 : Check Function Settings**

Using the table on the right adjust function 31. (Room Temperature Control for indoor unit sensor)


※ Please reference the APPENDING DATA

Ref.)

Function Number	Setting Value	Setting Description
31 (For heating)	00	Standard setting
	01	No correction 0.0°F (0.0°C)
	02	-1°F (-0.5°C)
	03	-2°F (-1.0°C)
	04	-3°F (-1.5°C)
	05	-4°F (-2.0°C)
	06	-5°F (-2.5°C)
	07	-6°F (-3.0°C)
	08	-7°F (-3.5°C)
	09	-8°F (-4.0°C)

Less Heating

“Wired remote sensor”



**Trouble shooting 28**  
Too Cool

- Forecast of Cause :
1. House insulation setting has not been changed.
  2. Temperature sensing location has not been changed.
  3. Installation location of the wired remote.
  4. Function settings have not been changed.

**Check Point 1 : Check insulation level of structure of house**  
Is insulation level greater than R-13.

**YES**

**Check Point 1-1 : Check Function Setting**  
If insulation level is greater than R-13 set function 95 to 01. Ref.)

Function Number	Setting Value	Setting Description
95	00	Standard insulation
	01	High insulation

※ Please reference the APPENDING DATA

**OK**

**Check Point 1-2 : Check effects of Function Setting change**  
Is the space still too cool in relation to set point.

**Too cool**

**NO**


**Check Point 2 : Verify room temperature sensing location**  
Do you want room temperature sensed at the wired remote controller (Wired remote sensor) or by they build in sensor inside the unit (Indoor unit sensor).

**"Wired remote sensor"**

**TO NEXT PAGE**


**"Indoor unit sensor"**

**Check Point 3 : Check the remote controller display**  
Is the "Thermo Sensor Icon" displayed on the screen?



**YES**

**Check Point 3-1 : Check the remote controller**  
Hold down the THERMO SENSOR button until the thermo sensor icon is turned off.



**Too cool**


**NO**

**Check Point 4 : Check Function Settings**  
Using the table on the right adjust function 30. (Room Temperature Control for indoor unit sensor)  
※ Please reference the APPENDING DATA

Function Number	Setting Value	Setting Description
30 (For cooling)	00	Standard setting
	01	No correction 0.0°F (0.0°C)
	10	+1°F (+0.5°C)
	11	+2°F (+1.0°C)
	12	+3°F (+1.5°C)
	13	+4°F (+2.0°C)
	14	+5°F (+2.5°C)
	15	+6°F (+3.0°C)
	16	+7°F (+3.5°C)
	17	+8°F (+4.0°C)

Less Cooling

“Wired remote sensor”




## 2-4 SERVICE PARTS INFORMATION

### SERVICE PARTS INFORMATION 1

#### Compressor

Diagnosis method of Compressor ( If Outdoor Unit LED displays Error, refer to Trouble shooting )




## SERVICE PARTS INFORMATION 2

### Compressor

#### Check Point 1 : Check Connection


- Check terminal connection of Compressor (loose or incorrect wiring)



#### Check Point 2 : Check Winding Resistance

- Check winding resistance of each terminal

► **If the resistance value is 0 Ω or infinite, replace Compressor.**



• **AOU18/24RLB**  
Resistance Value :  
0.7 Ω at 77°F(25°C)

#### Check Point 3 : Replace Main PCB


► **If the symptom does not change with above Check 1, 2, replace Main PCB.**

### SERVICE PARTS INFORMATION 3

#### Outdoor unit Electronic Expansion Valve (EEV)

##### Check Point 1 : Check Connections

- Check connection of connector (CN700) ( Loose connector or open cable )



##### Check Point 2 : Check Coil of EEV

- Remove connector, check each winding resistance of Coil.

Read wire	Resistance value
White - Red	$46 \Omega \pm 4 \Omega$ at 68°F(20°C)
Yellow - Red	
Orange - Red	
Blue - Red	

► **If Resistance value is abnormal, replace EEV.**

##### Check Point 3 : Check Voltage from Main PCB.

- Remove Connector and check Voltage (DC12V)

► **If it does not appear, replace Main PCB.**



##### Check Point 4 : Check Noise at start up

- Turn on Power and check operation noise.


► **If an abnormal noise does not show, replace Main PCB.**

##### Check Point 5 : Check Opening and Closing Operation of Valve

When Valve is closed, it has a temp. difference between Inlet and Outlet.

**CLOSE**  
Example : Hot Gas

Pipe (In)  
Hi TEMP.




Pipe (Out)  
Normal TEMP.

If it is open, it has no temp. difference between Inlet and Outlet.

**OPEN**  
Example : Hot Gas



Pipe (In)  
Hi TEMP.



Pipe (Out)  
Hi TEMP.

##### Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in ①, but if there is a difference as shown in ②, there is a possibility of inside clogged. In this case, replace Strainer.



#### **SERVICE PARTS INFORMATION 4**

Indoor unit fan motor

#### Check Point 1 : Check rotation of Fan

- Rotate the fan by hand when operation is off.  
(Check if fan is caught, dropped off or locked motor)
- >>If Fan or Bearing is abnormal, replace it.**

#### Check Point 2 : Check resistance of Indoor Fan Motor

- Refer to below. Circuit-test "Vm" and "GND" terminal.  
(Vm: DC voltage, GND: Earth terminal)
- >>If they are short-circuited (below 300 kΩ), replace Indoor fan motor and Controller PCB.**

Pin number (wire color)	Terminal function (symbol)
1 (Blue)	Feed back (FG)
2 (Yellow)	Speed command (Vsp)
3 (White)	Control voltage (Vcc)
4 (Black)	Earth terminal (GND)
5	No function
6 (Red)	DC voltage (Vm)

---

#### **SERVICE PARTS INFORMATION 5**

Outdoor unit fan motor

#### Check Point 1 : Check rotation of Fan

- Rotate the fan by hand when operation is off.  
(Check if fan is caught, dropped off or locked motor)
- >>If Fan or Bearing is abnormal, replace it.**

#### Check Point 2 : Check resistance of Outdoor Fan Motor

- Refer to below. Circuit-test "Vm" and "GND" terminal.  
(Vm: DC voltage, GND: Earth terminal)
- >>If they are short-circuited (below 300 kΩ), replace Outdoor fan motor and Main PCB.**

Pin number (wire color)	Terminal function (symbol)
1 (Red)	DC voltage (Vm)
2	No function
3	No function
4 (Black)	Earth terminal (GND)
5 (White)	Control voltage (Vcc)
6 (Yellow)	Speed command (Vsp)
7 (Brown)	Feed back (FG)

## SERVICE PARTS INFORMATION 6

Active filter module

Check Point 1 : Check Open or Short-circuit and Diode (D1)



• Remove connector, check the open or short-circuit and the diode in the module

Check the open or short-circuit

Table.1 Each type standard value

Terminal		Resistance value			
		Type A	Type B		
multimeter (+)	multimeter (-)	SACT32010 [ HITACHI ] LACT33020 [ HITACHI ]	PM-604 [ FGEL ] PM-703 [ FGEL ]		
		PM-601 [ FGEL ] <b>LOT No. - 1302931395</b>	PM-601 [ FGEL ] <b>LOT No. 1302931396 -</b>		
+	(+IN)*	-	(-IN)*	360kΩ ± 20%	360kΩ ± 20%
-	(-IN)*	N1	(N)*	0 Ω	0 Ω
※	P	+	(+IN)*	720kΩ ± 20%	900kΩ ± 20%
L1	L2	$1.01M\Omega$ / $0.76M\Omega$ (Ref. value 1) (Ref. value 2)			
P	N1	(N)*		360kΩ ± 20%	540kΩ ± 20%
L1, L2	Control Box	∞ Ω			
※	L2	N1	(N)*	$1.65M\Omega$ / $1.14M\Omega$ (Ref. value 1) (Ref. value 2)	$1.65M\Omega$ / $1.14M\Omega$ (Ref. value 1) (Ref. value 2)

\* ( ) is FGEL terminal name.

Table.2 Standard value is changed by the tool specification  
(Type A and B are the same value)

Terminal		Resistance value	
multimeter (+)	multimeter (-)		
※	L2	P	$1.32M\Omega$ / $0.66M\Omega$ (Ref. value 1) (Ref. value 2)
※	P	L2	$1.01M\Omega$ / $0.76M\Omega$ (Ref. value 1) (Ref. value 2)

※ By kind of multimeter , the value may change significantly.

Ref. value 1



Specifications for Multimeter  
 Manufacturer : FLUKE  
 Model name : FLUKE11  
 Power source : DC9V.

Ref. value 2

Specifications for Multimeter  
 Manufacturer : SANWA  
 Model name : PM3  
 Power source : DC3V.

► If it is abnormal,replace ACTIVE FILTER MODULE

LOT No. of PM-601 [ FGEL ] type



Check Point 2 : Check the Output DC voltage (between P and N)

DC



• Check the Output DC voltage (between P and N) of compressor stopping and operating.


>> If the output voltage of compressor operating is less than the output voltage of compressor stopping,  
 Active Filter Module is defective. >> **Replace Active Filter Module**

## SERVICE PARTS INFORMATION 7

IPM

(Mounted on Transistor PCB)

### Check Point 1 : Check the Transistor of PCB ( for Resistance )




① Disconnect the connection wires between the Transistor PCB - Capacitor PCB and Transistor PCB - Inverter Compressor.

② Set the tester to the "Resistance" mode, and measure the resistance between the following terminals.


TM301 (P) - TM305(U) / TM304(V) / TM303(W)  
 TM302 (N) - TM305(U) / TM304(V) / TM303(W)

③ Judge the result of ② as follows:

Terminal		Resistance value
Tester(+)	Tester(-)	
P	U	Over 2k $\Omega$ (Including $\infty\Omega$ )
P	V	
P	W	
U	P	Over 20k $\Omega$ (Including $\infty\Omega$ )
V	P	
W	P	
N	U	Over 2k $\Omega$ (Including $\infty\Omega$ )
N	V	
N	W	
U	N	
V	N	
W	N	



### Check Point 2 : Check the Transistor of PCB ( for Diode )



④ Set the tester to the "Diode" mode, and measure the voltage value between the following terminals.

⑤ Judge the result of ④ as follows:

Terminal		Tester display
Tester(+)	Tester(-)	
P	U	$\infty$
P	V	
P	W	
U	P	0.3V~0.7V
V	P	
W	P	
N	U	$\infty$
N	V	
N	W	
U	N	
V	N	
W	N	

# ***WALL MOUNTED type INVERTER***

## 3 . APPENDING DATA

## 3-1. FUNCTION SETTING

### 3-1-1 INDOOR UNIT

- Follow the instructions in the Local Setup Procedure, which is supplied with the remote control, in accordance with the installed condition.  
After the power is turned on, perform the Function Setting on the remote control.
- The settings may be selected between the following two: Function Number or Setting Value.
- Settings will not be changed if invalid numbers or setting values are selected.

#### Function Details

##### 1-1. Setting the Filter sign

Select appropriate intervals for displaying the filter sign on the indoor unit according to the estimated amount of dust in the air of the room.  
If the indication is not required, select "No indication" (03).

(◆ . . . Factory setting)

Function Number	Setting Value	Setting Description
11	00	Standard (400 hours)
	01	Long interval (1000 hours)
	02	Short interval (200 hours)
	03	No indication

##### 1-2. Setting the Auto restart

Enable or disable automatic restart after a power interruption.

(◆ . . . Factory setting)

Function Number	Setting Value	Setting Description
40	00	Enable
	01	Disable

Auto restart is an emergency function such as for power outage etc.  
Do not attempt to use this function in normal operation.  
Be sure to operate the unit by remote controller or external device.

##### 1-3. Setting the Room temperature sensor switching (Only for Wired remote controller)

When using the Wired remote controller temperature sensor, change the setting to "Both" (01).

(◆ . . . Factory setting)

Function Number	Setting Value	Setting Description
42	00	Indoor unit
	01	Both

00: Sensor on the indoor unit is active.

01: Sensors on both indoor unit and wired remote controller are active.

- Remote controller sensor must be turned on by using the remote controller.

#### 1-4. Setting the Remote controller custom code

##### (Only for wireless remote controller)

The indoor unit custom code can be changed.  
Select the appropriate custom code.

(◆ . . .Factory setting)

Function Number	Setting Value	Setting Description
44	00	A
	01	B
	02	C
	03	D

#### 1-5. Setting the External input control

"Operation / Stop" mode or "Forced stop" mode can be selected.

(◆ . . .Factory setting)

Function Number	Setting Value	Setting Description
46	00	Operation / Stop mode
	01	(Setting prohibited)
	02	Forced stop mode

#### 1-6. Setting the Room temperature sensor switching (Aux.)

To use the temperature sensor on the wired remote controller only, change the setting to "Wired remote controller" (01).  
This function will only work if the function setting 42 is set at "Both" (01)

(◆ . . .Factory setting)

Function Number	Setting Value	Setting Description
48	00	Both
	01	Wired remote controller

#### 1-7. Setting the Indoor unit fan control for energy saving for cooling

Enables or disables the power saving function by controlling the indoor unit fan rotation when the outdoor unit is stopped during cooling operation.

(◆ . . .Factory setting)

Function Number	Setting Value	Setting Description
49	00	Disable
	01	Enable

00 : When the outdoor unit is stopped, the indoor unit fan operates continuously following the setting on the remote controller.

01 : When the outdoor unit is stopped, the indoor unit fan operates intermittently at a very low speed.

## Temperature Correction

When changing Function 95, perform this setting before other Room temp. control settings (Function 30, 31, 92, 93).

If Function 95 is not set first, Room temperature control settings (Function 30, 31, 92, 93) will be reset and you must redo them again.

### 1-8. Setting the Heat Insulation condition (building insulation)

Heat insulation conditions differ according to the installed environment.

Standard insulation "00" allows system to rapidly respond to the cooling or heating load changes.

High insulation "01" is when the heat insulation structure of the building is high and does not require system to rapidly respond to cooling or heating load changes. When High insulation "01" is selected;

- Overheating (overcooling) is prevented at the start-up.
- All room temp. control settings (Function 30, 31, 92, 93) will reset to No correction [0.0°F (0.0°C)].

◆ . . . Factory setting)

Function Number	Setting Value	Setting Description
95	00	Standard insulation ◆
	01	High insulation

### 1-9. Setting the Room temperature control for indoor unit sensor

Depending on the installed environment, correction of the room temperature sensor may be required.

Select the appropriate control setting according to the installed environment.

The temperature correction values show the difference from the Standard setting "00" (manufacturer's recommended value).

- When Function 95-01(High insulation) is set, the Standard setting "00" will be the same as No correction "01" [0.0°F(0.0°C)].

◆ . . . Factory setting)

Function Number	Setting Value	Setting Description		
30 (For cooling)	31 (For heating)	00	Standard setting ◆	
		01	No correction 0.0°F (0.0°C)	
		02	-1°F (-0.5°C)	More Cooling Less Heating
		03	-2°F (-1.0°C)	
		04	-3°F (-1.5°C)	
		05	-4°F (-2.0°C)	
		06	-5°F (-2.5°C)	
		07	-6°F (-3.0°C)	
		08	-7°F (-3.5°C)	
		09	-8°F (-4.0°C)	Less Cooling More Heating
		10	+1°F (+0.5°C)	
		11	+2°F (+1.0°C)	
		12	+3°F (+1.5°C)	
		13	+4°F (+2.0°C)	
		14	+5°F (+2.5°C)	
		15	+6°F (+3.0°C)	
		16	+7°F (+3.5°C)	
17	+8°F (+4.0°C)			

**1-10. Setting the Room temperature control for wired remote controller sensor**

Depending on the installed environment, correction of the wire remote temperature sensor may be required. Select the appropriate control setting according to the installed environment. To change this setting, set Function 42 to Both "01". Ensure that the Thermo Sensor icon is displayed on the remote controller screen.

(◆ . . . Factory setting)


Function Number		Setting Value	Setting Description	
92 (For cooling)	93 (For heating)	00	No correction 0.0°F (0.0°C)	◆
		01	No correction 0.0°F (0.0°C)	
		02	-1°F (-0.5°C)	More Cooling Less Heating
		03	-2°F (-1.0°C)	
		04	-3°F (-1.5°C)	
		05	-4°F (-2.0°C)	
		06	-5°F (-2.5°C)	
		07	-6°F (-3.0°C)	
		08	-7°F (-3.5°C)	
		09	-8°F (-4.0°C)	
		10	+1°F (+0.5°C)	Less Cooling More Heating
		11	+2°F (+1.0°C)	
		12	+3°F (+1.5°C)	
		13	+4°F (+2.0°C)	
		14	+5°F (+2.5°C)	
		15	+6°F (+3.0°C)	
		16	+7°F (+3.5°C)	
		17	+8°F (+4.0°C)	

## 3-1-2 PROCEDURES TO CHANGE THE FUNCTION SETTING FOR WIRELESS RC

- This procedure changes to the function settings used to control the indoor unit according to the installation conditions. Incorrect settings can cause the indoor unit malfunction.
- After the power is turned on, perform the "FUNCTION SETTING" according to the installation conditions using the remote controller.
- Settings will not be changed if invalid numbers or setting values are selected.


### Entering the Function Setting Mode

- While pressing the FAN button and SET TEMP.(▲) simultaneously, press the RESET button to enter the function setting mode.




### Selecting the Function Number and Setting Value

- (1) Press the MODE button, and proceed to Function Number and Setting Value.  
(There is no necessity for setting remote control signal code. Because signal code is setting by Function Number and Setting Value.)



- (2) Press the SET TEMP. (▲) (▼) buttons to select the Function Number.  
(Press the MODE button to switch between the left and right digits.)



- (3) Press the FAN button to proceed to Setting Value.  
(Press the FAN button again to return to the Function Number selection.)


- (4) Press the SET TEMP. (▲) (▼) buttons to select the Setting Value.  
(Press the MODE button to switch between the left and right digits.)

- (5) Press the TIMER MODE button. It makes a signal to indoor unit.  
(Indoor unit recognize the setting.)

- (6) Press the START/STOP button. It makes a signal to indoor unit.  
(Indoor unit run the setting.)



- (7) Press the RESET button to cancel the function setting mode.
- (8) After completing the FUNCTION SETTING, be sure to turn of the power and turn it on again.



#### ⚠ CAUTION

After turning off the power, wait 10 seconds or more before turning on it again.  
The FUNCTION SETTING doesn't become effective if it doesn't do so.

## Custom code setting for remote controller

- (1) Press the MODE button for more than 5 seconds.
- (2) Press the SET TEMP. (▲) (▼) buttons to change the signal code between  $\overline{A} \rightarrow \overline{b} \rightarrow \overline{c} \rightarrow \overline{d}$ .  
Match the code on the display to the air conditioner signal code. (initially set to  $\overline{A}$ )
- (3) Press the MODE button. (Return to normal display)

### CAUTION

If you change the setting of Function Number and Setting Value after setting custom code in remote controller, please set custom code in remote controller again.

The remote control unit resets to signal code A when the batteries in the remote control unit are replaced. If you use a signal code other than signal code A, reset the signal code after replacing the batteries.

If you do not know the air conditioner signal code setting, try each of the signal codes (  $\overline{A} \rightarrow \overline{b} \rightarrow \overline{c} \rightarrow \overline{d}$  ) until you find the code which operates the air conditioner.

## 3-2. THERMISTOR RESISTANCE VALUES

### 3-2-1 INDOOR UNIT

Room temperature thermistor		
Temp °F(°C)	Resistance(k Ω)	Voltage(V)
14 (-10)	58.2	0.73
23 (-5)	44.0	0.93
32 (0)	33.6	1.15
41 (5)	25.9	1.39
50 (10)	20.2	1.66
59 (15)	15.8	1.94
68 (20)	12.5	2.22
77 (25)	10.0	2.50
86 (30)	8.0	2.77
95 (35)	6.5	3.03
104 (40)	5.3	3.27
113 (45)	4.4	3.49


Indoor heat exchanger thermistor		
Temp °F(°C)	Resistance(k Ω)	Voltage(V)
-22 (-30)	1131.9	0.21
-13 (-25)	804.5	0.29
-4 (-20)	579.6	0.40
5 (-15)	422.9	0.53
14 (-10)	312.3	0.69
23 (-5)	233.2	0.88
32 (0)	176.0	1.10
41 (5)	134.2	1.36
50 (10)	103.3	1.63
59 (15)	80.3	1.92
68 (20)	62.9	2.21
77 (25)	49.7	2.51
86 (30)	39.6	2.79
95 (35)	31.7	3.06
104 (40)	25.6	3.30
113 (45)	20.8	3.53
122 (50)	17.1	3.73
131 (55)	14.1	3.90
140 (60)	11.6	4.05
149 (65)	10.4	4.14

### 3-2-2 OUTDOOR UNIT

Discharge thermistor		
Temp °F(°C)	Resistance(k Ω)	Voltage(V)
-22 (-30)	1013.1	0.06
-12 (-25)	729.1	0.09
-4 (-20)	531.6	0.12
5 (-15)	392.3	0.16
14 (-10)	292.9	0.21
23 (-5)	221.1	0.28
32 (0)	168.6	0.36
41 (5)	129.8	0.46
50 (10)	100.9	0.57
59 (15)	79.1	0.71
68 (20)	62.5	0.86
77 (25)	49.8	1.03
86 (30)	40.0	1.23
95 (35)	32.4	1.43
104 (40)	26.3	1.65
113 (45)	21.6	1.88
122 (50)	17.8	2.11
131 (55)	14.8	2.34
140 (60)	12.3	2.57
149 (65)	10.3	2.79
158 (70)	8.7	3.00
167 (75)	7.4	3.19
176 (80)	6.3	3.37
185 (85)	5.4	3.54
194 (90)	4.6	3.69
203 (95)	4.0	3.83
212 (100)	3.4	3.96
221 (105)	3.0	4.07
230 (110)	2.6	4.17
239 (115)	2.3	4.26
248 (120)	2.0	4.33

Outdoor heat exchanger thermistor		
Temp °F(°C)	Resistance(k Ω)	Voltage(V)
-22 (-30)	95.6	0.24
-12 (-25)	68.9	0.32
-4 (-20)	50.3	0.43
5 (-15)	37.2	0.57
14 (-10)	27.8	0.73
23 (-5)	21.0	0.92
32 (0)	16.1	1.14
41 (5)	12.4	1.39
50 (10)	9.6	1.65
59 (15)	7.6	1.93
68 (20)	6.0	2.21
77 (25)	4.8	2.49
86 (30)	3.8	2.77
95 (35)	3.1	3.02
104 (40)	2.5	3.26
113 (45)	2.1	3.48
122 (50)	1.7	3.68
131 (55)	1.4	3.85
140 (60)	1.2	4.00
149 (65)	1.0	4.13
158 (70)	0.8	4.25
167 (75)	0.7	4.35
176 (80)	0.6	4.43

Outdoor temperature thermistor		
Temp °F(°C)	Resistance(k Ω)	Voltage(V)
-22 (-30)	224.3	0.73
-12 (-25)	159.7	0.97
-4 (-20)	115.2	1.25
5 (-15)	84.2	1.56
14 (-10)	62.3	1.90
23 (-5)	46.6	2.26
32 (0)	35.2	2.61
41 (5)	26.9	2.94
50 (10)	20.7	3.25
59 (15)	16.1	3.52
68 (20)	12.6	3.76
77 (25)	10.0	3.97
86 (30)	8.0	4.14
95 (35)	6.4	4.28
104 (40)	5.2	4.41
113 (45)	4.2	4.51
122 (50)	3.5	4.59
131 (55)	2.8	4.65



**FUJITSU GENERAL LIMITED**

**3-3-17, Suenaga, Takatsu-ku, Kawasaki 213-8502, Japan**