

Service Instructions

Split System Air Conditioners, Split System Heat Pumps with R-22 Refrigerant Blowers, Coils, & Accessories





June 2017

This manual is to be used by qualified, professionally trained HVAC technicians only. Goodman does not assume any responsibility for property damage or personal injury due to improper service procedures or services performed by an unqualified person.

Copyright © 2005 - 2017 Goodman Manufacturing Company, L.P.

TABLE OF CONTENTS

IMPORTANT INFORMATION2 - 3	SYSTEM OPERATION31 - 36
MODEL IDENTIFICATION 4 - 14	TROUBLESHOOTING CHART 37
AIR HANDLER/COIL IDENTIFICATION 16 - 22	SERVICING TABLE OF CONTENTS 38
ACCESSORIES23 - 28	SERVICING 39 - 68
PRODUCT DESIGN 29 - 30	ACCESSORIES WIRING DIAGRAMS 69-78
	WIRING DIAGRAMS79 - 120

IMPORTANT INFORMATION

Pride and workmanship go into every product to provide our customers with quality products. It is possible, however, that during its lifetime a product may require service. Products should be serviced only by a qualified service technician who is familiar with the safety procedures required in the repair and who is equipped with the proper tools, parts, testing instruments and the appropriate service manual. **REVIEW ALL SERVICE INFORMATION IN THE APPROPRIATE SERVICE MANUAL BEFORE BEGINNING REPAIRS.**

IMPORTANT NOTICES FOR CONSUMERS AND SERVICERS

RECOGNIZE SAFETY SYMBOLS, WORDS AND LABELS



WARNING -

This unit should not be connected to, or used in conjunction with, any devices that are not design certified for use with this unit or have not been tested and approved by the manufacturer. Serious property damage or personal injury, reduced unit performance and/or hazardous conditions may result from the use of devices that have not been approved or certified by the manufacturer.



WARNING -

Only personnel that have been trained to install, adjust, service or repair (hereinafter, "service") the equipment specified in this manual should service the equipment. The manufacturer will not be responsible for any injury or property damage arising from improper service or service procedures. If you service this unit, you assume responsibility for any injury or property damage which may result. In addition, in jurisdictions that require one or more licenses to service the equipment specified in this manual, only licensed personnel should service the equipment. Improper installation, adjustment, servicing or repair of the equipment specified in this manual, or attempting to install, adjust, service or repair the equipment specified in this manual without proper training may result in product damage, property damage, personal injury or death.



▲ WARNING —

To prevent the risk of property damage, personal injury, or death, do not store combustible materials or use gasoline or other flammable liquids or vapors in the vicinity of this appliance.

To locate an authorized servicer, please consult your telephone book or the dealer from whom you purchased this product. For further assistance, please contact:

CONSUMER INFORMATION LINE
GOODMAN® BRAND PRODUCTS
TOLL FREE 1-877-254-4729 (U.S. only)
email us at: customerservice@goodmanmfg.com
fax us at: (713) 856-1821
(Not a technical assistance line for dealers.)

CONSUMER INFORMATION LINE
AMANA® BRAND PRODUCTS
TOLL FREE 1-877-254-4729 (U.S. only)
email us at: customerservice@goodmanmfg.com
fax us at: (713) 856-1821
(Not a technical assistance line for dealers.)

Outside the U.S., call 1-713-861-2500.(Not a technical assistance line for dealers.) Your telephone company will bill you for the call.

IMPORTANT INFORMATION

SAFE REFRIGERANT HANDLING

While these items will not cover every conceivable situation, they should serve as a useful guide.



WARNING

Refrigerants are heavier than air. They can "push out" the oxygen in your lungs or in any enclosed space.To avoid possible difficulty in breathing or death:

- Never purge refrigerant into an enclosed room or space. By law, all refrigerants must be reclaimed.
- If an indoor leak is suspected, thoroughly ventilate the area before beginning work.
- Liquid refrigerant can be very cold. To avoid possible frostbite or blindness, avoid contact with refrigerant and wear gloves and goggles. If liquid refrigerant does contact your skin or eyes, seek medical help immediately.
- Always follow EPA regulations. Never burn refrigerant, as poisonous gas will be produced.



WARNING

To avoid possible explosion:

- Never apply flame or steam to a refrigerant cylinder.
 If you must heat a cylinder for faster charging,
 partially immerse it in warm water.
- Never fill a cylinder more than 80% full of liquid refrigerant.
- Never add anything other than R-22 to an R-22 cylinder or R-410A to an R-410A cylinder. The service equipment used must be listed or certified for the type of refrigerant used.
- Store cylinders in a cool, dry place. Never use a cylinder as a platform or a roller.



WARNING

HIGH VOLTAGE

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.





WARNING

To avoid possible injury, explosion or death, practice safe handling of refrigerants.



WARNING

To avoid possible explosion, use only returnable (not disposable) service cylinders when removing refrigerant from a system.

- Ensure the cylinder is free of damage which could lead to a leak or explosion.
- Ensure the hydrostatic test date does not exceed 5 years.
- Ensure the pressure rating meets or exceeds 400 lbs.

When in doubt, do not use cylinder.



WARNING -

System contaminants, improper service procedure and/or physical abuse affecting hermetic compressor electrical terminals may cause dangerous system venting.

The successful development of hermetically sealed refrigeration compressors has completely sealed the compressor's moving parts and electric motor inside a common housing, minimizing refrigerant leaks and the hazards sometimes associated with moving belts, pulleys or couplings.

Fundamental to the design of hermetic compressors is a method whereby electrical current is transmitted to the compressor motor through terminal conductors which pass through the compressor housing wall. These terminals are sealed in a dielectric material which insulates them from the housing and maintains the pressure tight integrity of the hermetic compressor. The terminals and their dielectric embedment are strongly constructed, but are vulnerable to careless compressor installation or maintenance procedures and equally vulnerable to internal electrical short circuits caused by excessive system contaminants.

In either of these instances, an electrical short between the terminal and the compressor housing may result in the loss of integrity between the terminal and its dielectric embedment. This loss may cause the terminals to be expelled, thereby venting the vaporous and liquid contents of the compressor housing and system.

A venting compressor terminal normally presents no danger to anyone, providing the terminal protective cover is properly in place.


If, however, the terminal protective cover is not properly in place, a venting terminal may discharge a combination of


- (a) hot lubricating oil and refrigerant
- (b) flammable mixture (if system is contaminated with air)

in a stream of spray which may be dangerous to anyone in the vicinity. Death or serious bodily injury could occur.


Under no circumstances is a hermetic compressor to be electrically energized and/or operated without having the terminal protective cover properly in place.

See Service Section S-17 for proper servicing.







14 - 14 SEER



All Airhandlers use **DIRECT DRIVE MOTORS**. Power supply is AC 208-230v, 60 hz, 1 phase.





GSC10		
	Goodman® BRAND SPLIT CONDENSERS 10 SEER - R22	
Model/Rev Description		
GSC100903AD	New ball valve/brackets, suction tube/assembly and panel w/offset.	
GSC100903BA GSC101203BA	Initial release of light commercial models with holding charge only in a double row coil. MODELS DO NOT CONTAIN REFRIGERANT. Units must be evacuated and charged with R-22 per the installation instructions.	
GSC100904AC GSC101204BA	Initial release of light commercial 460V models with holding charge only in a double row coil. MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions.	

Goodman® BRAND SPLIT CONDENSERS 13 SEER - R22	
Model/Rev	Description
GSC130[18-24]1AA	Initial release of 26" chassis R-22
GSC130[36-48]1AA	Initial release of 29" chassis R-22
GSC13036,48*AA	Initial release of 3 Phase models
GSC130**1AB GSC13048*AC	Screw hole location moved.
GSC130[36,48]*AB GSC130361BB	8-pole fan motors replaced with 6-pole.
GSC130[18-30]AC	Broad Ocean motor 0131M00060.
GSC130[18, 24, 30]1AD GSC130[421, 484]AC GSC130[18, 24, 30]1AE GSC130[481, 483] AE/AF GSC130363[AE/AF] GSC130361[DE/DD]	Hairpin removed from coil.
GSC13048*AD	Broad Ocean motor 0131M00061.
GSC130481AG GSC130361DF	Bristol compressors.
GSC130[483/484]CA	Changed from Copeland ZRK3 series to Compressors Copeland ZRK5 series [ZR38K5TF5130 and ZR38K5TFD130].
GSC130181B* GSC130421B* GSC13048[1B*/3B*/4B*]	Conversion from 3/8" diameter tube coils to 5 mm coils.
GSC130361BA	Initial release of 35" chassis with Copeland Scroll compressor.
GSC130181CA	Compressor change from a recip compressor to a Panasonic Rotary compressor.
GSC130[24-30]1CA	Reduced chassis size from the current 29x32.5 to 26x32.
GSC130241DA	Conversion from 3/8" diameter tube coils to 5 mm coils. Compressor changed to CR18K7-PFV-230; Refrigerant charge reduced.
GSC130361FA GSC130363BA GSC130301DA	Conversion from 3/8" diameter tube coils to 5 mm coils. 2.5 & 3 ton units have new coil slab height and new louver panels. 2.5 ton - small chassis; 3 ton - medium chassis.
GSC130601CA GSC13060[3BA/4BA]	5 mm coil and 29" chassis.
GSC130181DA GSX130[24-30]1EA GSC130361GA	Replaces Copeland compressor with Briston reciprocating compressor.
GSC130601DA GSC130603CA	Changed from Copeland ZRK3 series to Copeland ZRK5 series [ZR48K5PFV130 and ZR48K5TF130.

GSC130363BD

GSC13		
Goodman® BRAND SPLIT CONDENSERS 13 SEER - R22 Model/Rev Description		
	Description	
GSC130181BB GSC130241DB		
GSC130241DB GSC130301DB		
GSC130361FB	Released models holding charge only; MODELS DO NOT CONTAIN REFRIGERANT .	
GSC130421BB	Units must be evacuated and charged with R-22 per the installation instructions.	
GSC130481BB		
GSC130601CB		
GSC130421CA GSC130481CA	Released models holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. Replacing Copeland ZRK3 series compressor with Copeland ZRK5 series.	
GSC130361GB GSC130421CB GSC130481CB GSC130601DB	Release models holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per installation instructions. Changed from four-piece louver assembly to a two-piece louver assembly to a two-piece louver assembly.	
GSC130181DA GSC130241EA GSC130301EA GSC130361GA	Release models holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. Replaced Copeland compressor with Bristol reciprocating compressor.	
GSC130181FA GSC130241FA	Release models holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. Reduction of chassis to 23".	
GSC130181GA	Release models holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. This is the reintroduction of the Panasonic compressor.	
GSC130301EC	Release models holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. Changed from four-piece louver assembly to a two-piece louver assembly.	
GSC130363BB GSC130483BB GSC130603BB	Release models holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions.	
GSC130483CB GSC130603CB	Release models holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. Change from four-piece louver assembly to a two-piece louver assembly.	
GSC130484BB GSC130604BB	Release 460v models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions.	
GSC130604BC	Release 460v models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. Changed from four-piece louver assembly to a two-piece louver assembly.	
GSC130363BC	3 ton condensing unit. Release of Goodman 13 SEER Condensers with updated serial	

plates (MCA and compressor RLA/LRA ratings).

3 ton condensing unit. Changed from four-piece louver assembly to a two-piece louver

assembly plus a corner post on Goodman and value series 26" and 29" chassis.

GSC13	
Model/Rev	Goodman® BRAND SPLIT CONDENSERS 13 SEER - R22 Description
GSC130484BC	Release 460v models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT. Units must be evacuated and charged with R-22 per the installation instructions. Replaced Copeland ZRK3 series compressor with Copeland ZRK5 series compressor.
GSC130484BD	Release 460v models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. The current four piece louver assembly has changed to a two piece louver assembly.
GSC100903AE GSC100904AD GSC130241FC GSC130301ED GSC130361GC GSC130363BE GSC130[42-48]1CC GSC130484BE GSC130601DC GSC130603CC GSC130604BE	Compressors changed from those using mineral oil to those using oil type POE.
GSC130181GB GSC130241FD GSC130301EE GSC130361GD GSC130363BF GSC130421CD GSC13048(1/3)CD GSD130601DD GSC130603CD GSC130604BF	Hairpin removal to improve airflow.
GSC130241FF	Changing Flat BOM structure to Indented BOM structure

	GSC14
	Goodman® BRAND SPLIT CONDENSERS 14 SEER - R22
Model/Rev	Description
GSC140**1AA	Introduces Goodman® Brand 14 Seer AC R-22 models.
GSC140**1AB	New revisions have screw locations moved in the top panel, base pans, louvers, and control box covers.
GSC140**1AC	Release models containing the Broad Ocean motor 0131M00060 and 0131M00061
GSC140**1AD	Revise condenser coils by removing (1) hairpin. Reducing refrigerant quantities by 6 ounces.
GSC140(18-42)1BA	Conversion of existing models using 3/8" diameter tube coils to 5 mm coils.
GSC140(18-42)1CA	Initial release of 14 SEER Dry Charge R-22 compatible AC units

ASC13 Amana® BRAND SPLIT CONDENSERS 13 SEER - R22	
Model/Rev	Description
ASC130**1AA	Initial release new models of Amana® Brand Deluxe 13 Seer AC R-22 conditioners.
ASC130**1AB	Moved location of screw hole.
ASC130**1AC	Introduces horizontal style louvers.
ASC1301**1AD	Remove 1 hairpin from coil.
ASC130601BD	Remove 1 hairpin from coil. Reduce refrigerant quantities by 6 ounces.

VSC13		
	VALUE SPLIT CONDENSERS 13 SEER - R22	
Model/Rev	Description	
VSC13018-601AA	Initial release of Value 13 Seer AC R-22 models. 2 year part & 5 year compressor warranty in Bahama Beige.	
VSC130181BA VSC13030-361BA	Converts models from 3/8" to 5mm with new coil slab height & new louver panels. 2 year part & 5 year compressor warranty in Bahama Beige.	

GSH10 Goodman® SPLIT HEAT PUMP 10 SEER - R22 Model/Rev Description GSH10***AA Initial release. GSH10***AB Screw locations moved in the top panel, base pans, louvers, and control box covers. Heat pump unit without R-22 refrigerant. MODELS DO NOT CONTAIN REFRIGERANT. GSH100903AC Units must be evacuated and charged with R-22 per the installation instructions. GSH101203AC Heat pump unit without R-22 refrigerant with new ball valve/brackets, suction tube/assembly GSH101203AD and panel w/offset. GSH13042-48*AE GSH130191AC Added mufflers. GSH130484AC, GSH13060*AC Initial release of 460v light commercial models without R-22 refrigerant. MODELS DO NOT GSH100904BA CONTAIN REFRIGERANT. Units must be evacuated and charged with R-22 per the GSH101204AC installation instructions. GSH100904BB R22 Condenser Models New Compressor with Oil Change from Mineral to POE GSH100903BC Added Export Label "Not for same or use in the United States" to existing domestic GSH GSH100904BC GSH101203AF unit. The new minor revision will say "EXPORT ONLY" in the description. GSH101204AE

GSH13		
Goodman® SPLIT HEAT PUMP 13 SEER - R22		
Model/Rev	Description	
GSH13***AA	Initial release of G oodman® Brand S plit H eat Pump 13 Seer heat pump units	
GSH13**1AB	Replaced 8-pole fan motors with 6-pole. Screw locations moved in the top panel, base pans, louvers, and control box covers.	
GSH13**1AC	Broad Ocean motors. Screw locations moved in the top panel, base pans, louvers, and control box covers.	
GSH13036-48*AD	Broad Ocean motors	
GSH13018-301BA	Chassis reduction from medium to small.	
GSH130421AE	V10 reversing valve replaced with V6 reversing valve.	
GSH13048*AG	Bristol Compressor.	
GSH13036*[BA/BB]	Improvements to increase MOP values on 3 ton units.	
GSH13042-48*AE GSH130191AC GSH130484AC GSH13060*AC	Added mufflers.	
GSH130[18/24]1CD	Changed reversing valve from Dunan to new SanHua reversing valve.	
GSH10090[3-4]BB GSH101203AE GSH101204AD GSH130[18-30]1CE	Introduced model with compressor oil type POE.	
GSH130361CE GSH130363AH GSH130[42-48]1BC GSH130483BC GSH130484AF	Introduced model with compressor oil type POE and changes current reversing valve from Dunan to SanHua.	
GSH13060[1,3,4]AD	Introduced model with compressor oil type POE.	
GSH130181BB GSH130241BB GSH130301BB GSH130361BC GSH130421AF GSH130481AE GSH130601AC	Release of models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions.	
GSH130421BA	Release of models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. Replacing Copeland ZRK3 series compressors with ZRK5 series compressors.	

GSH13			
Goodman®	S PLIT	H EAT PUMP	13 SEER - R22

Goodman® SPLIT HEAT PUMP 13 SEER - R22	
Model/Rev	Description
GSH130181CA GSH130241CA GSH130301CA GSH130361CA	Release models holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. Changing reciprocating compressor to scroll compressor.
GSH130[18,24]1CB GSH130[30,36]1CB GSH130421AG GSH130481AF	Release models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. Models listed have new 6 pole motor and corresponding new fan blades.
GSH130(18,24,30)1CC GSH130361CD	Release of models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. The current four-piece louver assembly has changed to a two-pieced louver assembly
GSH130361CC	Changed to motor (0131M00018P; 1/4 hp, 6 pole), fan blade (B21086750), outdoor piston (0.059) and indoor piston (0.071).
GSH130481BA	Release of 4 ton model with Copeland ZR42K5PFV130 compressor.
GSH130421BB GSH130481BB	Release of 4 ton model with Copeland ZR42K5PFV130 compressor. The current four piece louver assembly has changed to a two piece louver plus a corner post on Goodman and value series 26" and 29" chassis.
GSH130363AE GSH130483AE GSH130603AC	Release models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions.
GSH130363AF	Release of models with updated serial plates (MCA and compressor RLA/LRA ratings).
GSH130363AG	Changed current four piece louver assembly to a two piece louver assembly plus a corner post on Goodman series 26" and 29" chassis.
GSH130484AC GSH130604AC	Release of 460V models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions.
GSH130483BA GSH130484AD	Release of models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. Replacing Copeland ZRK3 series compressors with ZRK5 series.
GSH130483BB	Release of models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. The current four piece louver assembly has changed to a two piece louver plus a corner
GSH130484AE	Release of models with holding charge only; MODELS DO NOT CONTAIN REFRIGERANT . Units must be evacuated and charged with R-22 per the installation instructions. The current four piece louver assembly has changed to a two piece louver plus a corner
GSH130363AJ GSH130483BD GSH130484AG GSH130603AE GSH130604AE	Added Export Label "Not for same or use in the United States" to existing domestic GSH unit. The new minor revision will say "EXPORT ONLY" in the description.
GSH130361CF GSH130[421,481]BD	Replaced motor 0131M00018P with 0131M00813

	GSH14
	Goodman® SPLIT HEAT PUMP 14 SEER - R22
Model/Rev	Description
GSH140**1AA	Initial release of Goodman® Brand <u>S</u> plit <u>H</u> eat Pump 14 Seer heat pump units.
GSH140**1AB	Screw locations moved in the top panel, base pans, louvers, and control box covers.
GSH140**1AC	Broad Ocean motor.
GSH140361AF, GSH140421-48AD GSH140601AE	Replaced TXV and compensator with flowrator and accumulator.

ASH13	
Amana® BRAND SPLIT HEAT PUMPS 13 SEER - R22	
Model/Rev	Description
ASH130**1AA	Initial release of Amana® Brand Deluxe 13 Seer R-22 heat pumps.
ASH130**1AB	Screw locations moved in the top panel, base pans, louvers, and control box covers.
ASH130**1AC	New horizontal style louvers.

VSH13	
VALUE SPLIT HEAT PUMP 13 Seer	
Model/Rev	Description
VSH1318-601AA	Initial release of Value Split Heat Pumps 13 Seer R-22 models. 2 year parts and 5 year compressor warranty in Bahama Beige.

A SINGLE PIECE AIR HANDLER R-MULTI-POSITION PSC MOTOR UNPAINTED FLOWRATOR

Model/Rev	Description
ARUF***16AA	Introduction of new 13 SEER Air Handler Model suitable for use with R-22 and R-410A
ARUF364216AB ARUF486016AB ARUF364216AC	Replaced current spot welded blower housing with the same cinched or crimped design used on the 80% furnace line.
ARUF***16BA	Replaced ARUFcoils using wavy fin with louver enhanced fin.
ARUF***1BA	Introducation of R-22 Only Air Handlers.

ARPF 13 SEER

A SINGLE PIECE AIR HANDLER R-MULTI-POSITION MOTOR PAINTED FLOWRATOR

Model/Rev	Description
ARPF****16AA	Introducation of new 13 SEER Air Handler Model suitable for use with R-22 and R-410A
ARPF364216AB ARPF486016AB	Replaced current spot welded blower housing with the same cinched or crimped design used on the 80% furnace line.
ARPF****16BA	Replaced ARPF coils using wavy fin with louver enhanced fin.
ARPF****1BA	Introducation of R-22 Only Air Handlers.

ADPF 13 SEER

A SINGLE PIECE AIR HANDLER DOWNFLOW PSC MOTOR PAINTED FLOWRATOR

None Control of the C	
Model/Rev	Description
ADPF***16AA	Introducation of new 13 SEER Air Handler Model suitable for use with R-22 and R-410A.
ADPF364216AB ADPF486016AB ADPF304216AC	Replaced current spot welded blower housing with the same cinched or crimped design used on the 80% furnace line.
ADPF***1BA	Replaced ADPF coils using wavy fin with louver enhanced fin.

ASPF

A SINGLE PIECE AIR HANDLER S-MULTI-POSITION EEM MOTOR PAINTED FLOWRATOR

Model/Rev	Description
ASPF313716AA	Introduction of 3-Ton Air Handler units with 3-row coil.
ASPF***16AA	Introduces new ASPF Air Handlers
ASPF***16BA	Control scheme modification that ensures blower operation during and after call for heat on units with heat kits. Replaced coil wavy fin with louver enhanced fin.

AIR HANDLERS

AEPF 13 SEER	
A SINGLE PIECE AIR H	HANDLER E- MULTI-POSITION VARIABLE-SPEED MOTOR P AINTED F LOWRATOR
Model/Rev	Description
AEPF***16AA	Introduction of new 13 SEER Air Handler Models suitable for use with R-22 and R-410A
AEPF***16BA	Introduction of models adding lower kW hit kits on the S&R plate.
AEPF***16BB	Replaced current spot welded blower housing with the same cinched or crimped design used on the 80% furnace line.
AEPF***16CA	Replaced AEPF coils using wavy fin with louver enhanced fin.
AEPF***1BA	Introduction of R-22 Only Air Handlers.
AEPF313716AA	Introduction of 3-Ton Air Handler units with 3-row coil.

AWUF 13 SEER		
A SINGLE PIECE A	A SINGLE PIECE AIR HANDLER WALL MOUNT PSC MOTOR UNPAINTED FLOWRATOR	
Model/Rev	Description	
AWUF***1AA	Initial release of 13 SEER Dayton wall mount air handlers.	
AWUF***16AA	Initial release 13 SEER Dayton wall mount air handlers suitable for use with R-22 and R-410A refrigerant.	
AWUF3005-101AA	Introduces 13 SEER Dayton wall mount air handlers using a Burr Oak Louvered Fin coil.	
AWUF***1BA	Replaced wave fin design with new louvered fin design	
AWUF370**16AA	Introduction of AWUF37 Air Handlers for use with R-22 and R410A.	
AWUF***16BA	Revision has louver fins & replaces copper tube hairpins with aluminum hairpins.	

AIR HANDLERS

ACNF 13 SEER A SINGLE PIECE AIR HANDLER CEILING MOUNT N-UNCASED FLOWRATOR	
Model/Rev	Description
ACNF***1AA	Initial release of 13 SEER Dayton uncased air handlers.
ACNF***16AA	Initial release of 13 SEER Dayton uncased air handlers suitable for use with R-22 and R-410A
ACNF***1AB	Drain pan material change.
ACNF****1BA	Replaced wavy fin design with new louvered fin design

MBR	
MODULAR BLOWER AIR HANDLER R-MULTI-POSITION PSC MOTOR	
Model/Rev	Description
MBR****AA-1AA	Initial release of modular blower with PSC blower motor.

MBE	
$m{M}$ ODULAR $m{B}$ LOWER AIR HANDLER $m{E}$ -MULTI-POSITION VARIABLE-SPEED MOTOR	
Model/Rev	Description
MBE****AA-1AA	Initial release of modular blower with variable speed blower motor.
MBE****AA-1BA	Initial release of new models with added lower kW hit kits on the S&R plate.

CAUF						
C-IND	C-INDOOR COIL A-UPFLOW/DOWNFLOW UNCASED FLOWRATOR					
Model/Rev	Description					
CAUF****6AA	Initial release of CAUF Dayton Upflow/Downflow coils.					
CAUF****6BA Burr Oak Louvered Fin replaced Wavy Fin.						
CAUF***6*DA	Replaced existing copper coils and other associated parts with aluminum components.					
CAUF****6DB	Drain pan material change to a Decabromodiphenyl Ether free resin.					

GSC13048*AD	Broad Ocean motor 0131M00061.
GSC130481AG GSC130361DF	Bristol compressors.
GSC130[483/484]CA	Changed from Copeland ZRK3 series to Compressors Copeland ZRK5 series [ZR38K5TF5130 and ZR38K5TFD130].
GSC130181B* GSC130421B* GSC13048[1B*/3B*/4B*]	Conversion from 3/8" diameter tube coils to 5 mm coils.
GSC130361BA	Initial release of 35" chassis with Copeland Scroll compressor.
GSC130181CA	Compressor change from a recip compressor to a Panasonic Rotary compressor.
GSC130[24-30]1CA	Reduced chassis size from the current 29x32.5 to 26x32.

CPTF						
	C-INDOOR COIL T-COATED P-PAINTED FLOWRATOR					
Model/Rev	Model/Rev Description					
CTPF****6AA	Initial release of coated coils.					
CTPF1824*6AB CTPF3030*6AB CTPF3131*6AB CTPF3636*6AC CTPF3642*6AB CTPF4860*6AB	Drain pan material change to a Decabromodiphenyl Ether free resin.					

CSCF 13 SEER							
C-INDOOR	C-INDOOR COIL HORIZONTAL SLAB COIL C-UNPAINTED FLOWRATOR 13 SEER						
Model/Rev	Description						
CSCF****6AA	Initial release of 13 SEER horizontal slab coil.						
CSCF****6BA	Initial release of Burr Oak Louvered Fin. Rows changed by one, (i.e. 4 row to 3 row; 3 row to 2 row) where applicable.						
CSCF1824N6BB CSCF3036N6BB CSCF3642N6CB CSCF4860N6CB	Drain pan material change to a Decabromodiphenyl Ether free resin.						

CHPF						
C-INDOOR COIL HORIZONTAL A-COIL PAINTED FLOWRATOR						
Model/Rev	Description					
CHPF****6AA	Intial release of 13 SEER CHPF horizontal A coil.					
CHPF****6BA	Released Burr Oak Louvered Fin in place of the Wavy Fin. The rows changed by one, (i.e. 4 row to 3 row; 3 row to 2 row) where applicable.					
CHPF1824A6CA CHPF2430B6CA CHPF3636B6CA CHPF3642C6CA CHPF3642D6CA CHPF3743C6BA CHPF3743D6BA CHPF4860D6DA	Louvered fins. Replaced copper tube hairpins with aluminum hairpins.					
CHPF1824A6CB CHPF2430B6CB CHPF3636B6CB CHPF3642C6CB CHPF3642D6CB CHPF3743C6BB CHPF3743D6BB CHPF4860D6DB	Drain pan material change to a Decabromodiphenyl Ether free resin.					
CHPF1824A6CC CHPF2430B6CC CHPF3636B6CC CHPF3642C6CC CHPF3642D6CC CHPF3743C6BC CHPF3743D6BC CHPF4860D6DC	Change to prepainted wrappers					

CTUF					
C-INDOOR COIL T-COATED U-UNPAINTED FLOWRATOR Model/Rev Description					
CTUF1824*6AA CTUF3030*6AA CTUF3131*6AA CTUF3636*6AA CTUF3642*6AA CTUF4860*6AA	Initial release.				
CTUF1824*6AB CTUF3030*6AB CTUF3131*6AB CTUF3636*6AC CTUF3642*6AB CTUF4860*6AB	Drain pan material change to a Decabromodiphenyl Ether free resin.				

CAPT						
C-INDOOR COIL A-UPFLOW/DOWNFLOW PAINTED CASED FLOWRATOR W/TXV						
Model/Rev	Description					
CAPT3131B4BA CAPT3131C4BA	Initial release of coils with factory-installed, non-adjustable TXV. Single stage AHRI ratings for CAPT3131 NTC combinations.					
CAPT3743C4AA CAPT3743D4AA	Initial release of single stage AHRI ratings for CAPT3743 NTC combinations.					
CAPT4961C4AA CAPT4961D4AA	Initial release of single stage AHRI ratings for CAPT4961C4 NTC combinations.					
CAPT3131B4AB CAPT3131C4AB CAPT3743C4AB CAPT3743D4AB CAPT4961C4AB CAPT4961D4AB	Redesign the wrapper for the CAPT to provide increased ease of installation.					

CAPF C-INDOOR COIL A-UPFLOW/DOWNFLOW PAINTED CASED FLOWRATOR							
Model/Rev	Description						
CAPF****6AA	Initial release of CAPF Dayton Upflow/Downflow coils.						
CAPF****6BA	Burr Oak Louvered Fin replaced Wavy Fin.						
CAPF/CAUF36***CA	Performance improvement from 2 row to 3 row.						
CAPF****6DA	Replaced existing copper coils and other associated parts with aluminum components.						
CAPF****6DB	Drain pan material change to a Decabromodiphenyl Ether free resin.						
CAPF1824A6DC CAPF1824B6DC CAPF1824C6DC CAPF3030A6DC CAPF3030C6DC CAPF3030D6DC CAPF3131B6DC CAPF3131C6DC CAPF3137B6AB CAPF3636A6DC CAPF3636C6DC CAPF3636C6DC CAPF3642C6DC CAPF3642C6DC CAPF3743C6DC CAPF3743C6DC CAPF4860C6DC CAPF4860C6DC CAPF4860C6DC CAPF4961C6DC CAPF4961C6DC CAPF4961D6DC	Redesign the wrapper for the CAPF to provide increased ease of installation.						

Model	Description	ASC13018	ASC13024	ASC13030	ASC13036	ASC13042	ASC13048	ASC13060
OT18-60A	Outdoor Thermostat							
FSK01A*	Freeze Protection Kit	Х	Х	Х	Х	Х	Х	Х
ASC01	Anti Short Cycle Kit	Х	Х	Х	Х	Х	Х	Х
TX2N2*	TXV Kit	Х						
TX3N2*	TXV Kit	Х	Х	х	Х			
TX5N2*	TXV Kit					Х	Х	Х
CSR-U-1	Hard Start Kit	Х	Х	Х	Х			
CSR-U-2	Hard Start Kit				Х	Х	Х	Х
CSR-U-3	Hard Start Kit						Х	Х
LSK02A	Liquid Solenoid Kit	Х	Х	Х	Х	Х	Х	Х

Model	Description	G/VSC13018	G/VSC13024	G/VSC13030	G/VSC13036
OT18-60A	Outdoor Thermostat				
FSK01A*	Freeze Protection Kit	Х	Х	Х	Х
ASC01	Anti Short Cycle Kit	Х	Х	Х	Х
TX2N2*	TXV Kit	Х			
TX3N2*	TXV Kit	х	х	х	Х
TX5N2*	TXV Kit				
CSR-U-1	Hard Start Kit	Х	Х	Х	Х
CSR-U-2	Hard Start Kit				Х
CSR-U-3	Hard Start Kit				
LSK02A	Liquid Solenoid Kit	Х	Х	Х	Х

Model	Description	G/VSC13042	G/VSC13048	G/VSC13060
OT18-60A	Outdoor Thermostat			
FSK01A*	Freeze Protection Kit	Х	Х	Х
ASC01	Anti Short Cycle Kit	Х	Х	Х
TX2N2*	TXV Kit			
TX3N2*	TXV Kit			
TX5N2*	TXV Kit	Х	Х	Х
CSR-U-1	Hard Start Kit			
CSR-U-2	Hard Start Kit	Х	Х	Х
CSR-U-3	Hard Start Kit		Х	Х
LSK02A	Liquid Solenoid Kit	Х	Х	Х

Model	Description	GSC100903	GSC100904	GSC101203	GSC101204
FSK01A*	Freeze Protection Kit	x	х	x	х
ASC01	Anti Short Cycle Kit	х	х	х	х
OT/EHR18-60	Emergency Heat relay kit				
LSK03*	Liquid Solenoid Kit	X	X	X	Х

^{*}Installed on indoor coil.

Model	Des cription	G/VSH13018	G/VSH13024	G/VSH13030	G/VSH13036	G/VSH13042	G/VSH13048	G/VSH13060
AFE18-60A	All Fuel Kit	Х	Х	Х	Х	Х	Х	Х
OT18-60A	Outdoor Thermostat	Х	Х	Х	Х	Х	Х	Х
FSK01A*	Freeze Protection Kit	Х	Х	Х	Х	Х	Х	Х
ASC01	Anti Short Cycle Kit	X	Х	Х	Х	Х	Х	Х
TX2N2*	TXV Kit	Х						
TX3N2*	TXV Kit	Х	Х	Х	Х			
TX5N2*	TXV Kit					X	Х	Х
OT18-60A	Outdoor Lockout Stat	Х	Х	Х	Х	Х	Х	Х
OT/EHR18-60	Emergency Heat relay kit	Х	Х	Х	Х	Х	Х	Х
CSR-U-1	Hard Start Kit	X	Х	Х	X			
CSR-U-2	Hard Start Kit				Х	Х	Х	Х
CSR-U-3	Hard Start Kit						Х	Х
LSK02A	Liquid Solenoid Kit	Х	Х	Х	Х	Х	Х	Х

Model	Description	ASH13018	ASH13024	ASH13030	ASH13036	ASH13042	ASH13048	ASH13060
AFE18-60A	All Fuel Kit	Х	Х	Х	Х	Х	Х	Х
OT18-60A	Outdoor Thermostat	X	Х	Х	Х	Х	Х	Х
FSK01A*	Freeze Protection Kit	X	Х	Х	Х	Х	Х	Х
ASC01	Anti Short Cycle Kit	X	Х	Х	Х	Х	Х	Х
TX2N2*	TXV Kit	Х						
TX3N2*	TXV Kit	Х	Х	Х	Х			
TX5N2*	TXV Kit					Х	Х	Х
OT18-60A	Outdoor Lockout Stat	X	Х	Х	Х	Х	Х	Х
OT/EHR18-60	Emergency Heat relay kit	Х	Х	Х	Х	Х	Х	Х
CSR-U-1	Hard Start Kit	Х	Х	Х	Х			
CSR-U-2	Hard Start Kit				Х	Х	Х	Х
CSR-U-3	Hard Start Kit						Х	Х
LSK02A	Liquid Solenoid Kit	Х	Х	Х	Х	Х	Х	Х

Model	Description	GSH100903	GSH100904	GSH101203	GSH101204
FSK01A*	Freeze Protection Kit	Х	Х	Х	Х
ASC01	Anti Short Cycle Kit	Х	Х	Х	Х
OT/EHR18-60	Emergency Heat relay kit				
LSK03*	Liquid Solenoid Kit	Х	X	X	Х

^{*}Installed on indoor coil.


Model	Description	CPKF24	CPKF36	CPKF42	CPKF48	CPKF60	CPKF61
AFE18-60A	All Fuel Kit	Х	Х	Х	Х	Х	Х
OT18-60A	Outdoor Thermostat	Х	Х	Х	Х	Х	Х
FSK01A*	Freeze Protection Kit	Х	Х	Х	Х	Х	Х
ASC01	Anti Short Cycle Kit	Х	Х	Х	Х	Х	х
TX2N2*	TXV Kit						
TX3N2*	TXV Kit	Х	Х				
TX5N2*	TXV Kit			х	х	х	х
OT18-60A	Outdoor Lockout Stat	Х	Х	Х	Х	Х	Х
OT/EHR18-60	Emergency Heat relay kit	Х	Х	Х	Х	Х	х
CSR-U-1	Hard Start Kit	Х	Х				
CSR-U-2	Hard Start Kit		Х	Х	Х	Х	х
CSR-U-3	Hard Start Kit				Х	Х	х


Model	Description	CKF24	CKF36	CKF48	CKF60	CKF70
AFE18-60A	All Fuel Kit					
OT18-60A	Outdoor Thermostat					
FSK01A*	Freeze Protection Kit	Х	Х	Х	Х	Х
ASC01	Anti Short Cycle Kit	Х	Х	Х	Х	Х
TX2N2*	TXV Kit					
TX3N2*	TXV Kit	Х	Х			
TX5N2*	TXV Kit			х	х	
OT18-60A	Outdoor Lockout Stat					
OT/EHR18-60	Emergency Heat relay kit					
CSR-U-1	Hard Start Kit	Х	Х			
CSR-U-2	Hard Start Kit		Х	Х	Х	
CSR-U-3	Hard Start Kit			Х	Х	


Model	Description	CKL18	CKL24	CKL30	CKL36	CKL42	CKL49	CKL60
AFE18-60A	All Fuel Kit							
OT18-60A	Outdoor Thermostat							
FSK01A*	Freeze Protection Kit	Х	Х	Х	Х	Х	Х	Х
ASC01	Anti Short Cycle Kit	Х	Х	х	Х	Х	Х	х
TX2N2*	TXV Kit	Х						
TX3N2*	TXV Kit	X	Х	Х	Х			
TX5N2*	TXV Kit					Х	Х	Х
OT18-60A	Outdoor Lockout Stat							
OT/EHR18-60	Emergency Heat relay kit							
CSR-U-1	Hard Start Kit	Х	Х	Х	Х			
CSR-U-2	Hard Start Kit				Χ	Х	Х	Х
CSR-U-3	Hard Start Kit						Х	Х


Model	Description	CE120
AFE18-60A	All Fuel Kit	
OT18-60A	Outdoor Thermostat	
FSK01A*	Freeze Protection Kit	Х
ASC01	Anti Short Cycle Kit	Х
TX2N2*	TXV Kit	
TX3N2*	TXV Kit	
TX5N2*	TXV Kit	
OT18-60A	Outdoor Lockout Stat	
OT/EHR18-60	Emergency Heat relay kit	
CSR-U-1	Hard Start Kit	
CSR-U-2	Hard Start Kit	
CSR-U-3	Hard Start Kit	


ACCESSORIES EXPANSION VALVE KITS












COIL ACCESSORIES

COIL MODEL	TX2N2 TXV KIT	TX3N2 TXV KIT	TX5N2 TXV KIT	FSK01A FREEZE PROTECTION KIT
CA*F030B4*		Х		X
CA*F036B4*		Х		X
CA*F042C4*			Х	X
CA*F048C4*			Х	X
CA*F057D4*			Х	X
CA*F060D4*			Х	X
CHPF030A4*		Х		X
CHPF036B4*		Х		X
CHPF042A4*			Х	X
CHPF048D4*			Х	X
CHPF060D4*			Х	X
CH36FCB		Х		X
CH48FCB			Х	X
CH60FCB			Х	X
CA*F18246*	Х	Х		X
CA*F30306*		Х		X
CA*F36426*		Х	Х	X
CHPF18246*	Х		Х	X
CHPF30306*			Х	X
CHPF36426*			X	X
CSCF1824N6*	Х			X
CSCF303N6*		Х		X
CSCF3642N6*		Х	Х	X



HKR SERIES ELECTRIC HEAT KITS ELECTRIC HEAT KITAPPLICATIONS MBR & MBE

BLOWER		ELECTRIC HEAT KIT										
	NO HEAT	HKR-03*	HKR05-(C)'	HKR-06*	HKR-08(C)*	HKR-10(C)*	HKR-15(C)*	HKR-20(C)*	HKR-21(C)*	^HKR3-15*	^HKR3-20A	
MBR0800AA-1AA	1	Х	Х	Х	Х	Х						
MBR1200AA-1AA	-	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
MBR1600AA-1AA	-	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
MBR2000AA-1AA	-	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
MBE1200AA-1AA	-	-	-	-	Х	Х	Х	-	-	-	-	
MBE1600AA-1AA	-	-	-	-	-	Х	Х	-	-	-	-	
MBE2000AA-1AA	-	-	-	-	-	Х	Х	Х	-	-	-	
MBE1200AA-1BA	-	Х	X	Х	Х	X	Х	-	-	-	-	
MBE1600AA-1BA	-	Х	Х	Х	Х	Х	Х	-	-	-	-	
MBE2000AA-1BA	-	Х	Х	Х	Х	Х	Х	Х	-	-	-	

^{- =} Restricted combinations

X = Allowable combinations ^ = Circuit 1: Single Phase for Air Handler Motor Circuit 2: 3-Phase for HKR3 Heater Kits

^{* =} Revision level that my or may not be designated

C = Circuit Breaker option

PRODUCT DESIGN

This section gives a basic description of cooling unit operation, its various components and their basic operation. Ensure your system is properly sized for heat gain and loss according to methods of the Air Conditioning Contractors Association (ACCA) or equivalent.

CONDENSING UNIT

These units are designed for free air discharge. Condensed air is pulled through the condenser coil by a direct drive propeller fan and then discharged from the cabinet top. The unit requires no additional resistance (i.e. duct work) and should not be added.

The GSH13, GSH14, ASH13 and VSH13 Heat Pump condensing units are designed for 208-230 dual voltage single phase applications. The GSH13 3 ton model is available in 230V, 3 phase applications. The GSH13 4 and 5 ton models are available for 230V, 3-phase and 460V, 3-phase applications.

The units range in size from 1.5 to 5-ton and have a rating of 13 and 14 SEER. SEER efficiency is dependent upon the unit and its components. Refer to the "Technical Information" manual of the unit you are servicing for further details.

The GSC13, GSC14 and ASC13 and VSC13 Condensing Units are made in 1.5 through 5 ton sizes. They are designed for 208-240 volt single phase applications. The GSC13 3 ton model is available in 230V, 3 phase applications. The GSC13 4 and 5 ton models are available for 230V, 3-phase and 460V, 3-phase applications.

Suction and Liquid Line Connections

All units come equipped with suction and liquid valves designed for connection to refrigerant-type copper. Front seating valves are factory-installed to accept the field-run copper. The total refrigerant charge needed for a normal operation is also factory-installed. For additional refrigerant line set information, refer to the "Technical Information" manual of the unit you are servicing.

Compressors

GSC13, VSC13, GSH13 and VSH13 use a mix of reciprocating and scroll compressors, except for the VSC130181AA/BA which uses a rotary compressor. The ASC13 and ASH13 use the Copeland Scroll® Compressor. There are a number of design characteristics which differentiate the scroll compressor from the reciprocating compressor. One is the scroll. A scroll is an involute spiral which, when matched with a mating scroll form, generates a series of crescent-shaped gas pockets between the members (see following illustration). During compression, one scroll remains stationary while the other form orbits. This motion causes the resulting gas pocket to compress and push toward the center of the scrolls. When the center is reached, the gas is discharged out a port located at the compressor center.



GSC130361D* and GSC130481AG use Bristol® BENCH-MARK™ compressors, the most advanced compressors in the industry today. The BENCHMARK™ reciprocating compressor can be recognized by a "J" in the fourth character of the compressor model number. Innovative mechanical design and gas management make the BENCHMARK™ compressor very efficient and remarkably quiet. The sound content (frequency) delivers exceptional acoustical characteristics and the virtually round housing design is compact and also helps to reduce the overall sound and vibration.

GSC130181BA and GSC130181CA use Panasonic® rotary compressors.

COILS AND BLOWER COILS

MBR/MBE blower cabinets are designed to be used as a two-piece blower and coil combination. MBR/MBE blower sections can be attached to cased evaporator coil. This two-piece arrangement allows for a variety of mix-matching possibilities providing greater flexibility. The MBE blower cabinet uses a variable speed motor that maintains a constant airflow with a higher duct static.

It is approved for applications with cooling coils of up to 0.8 inches W.C. external static pressure and includes a feature that allows airflow to be changed by +15%. The MBR blower cabinet uses a PSC motor. It is approved for applications with cooling coils of up to 0.5 inches W.C. external static pressure.

PRODUCT DESIGN

The MBR/MBE blower cabinets with proper coil matches can be positioned for upflow, counterflow, horizontal right or horizontal left operation. All units are constructed with R-4.2 insulation. In areas of extreme humidity (greater than 80% consistently), insulate the exterior of the blower with insulation having a vapor barrier equivalent to ductwork insulation, providing local codes permit.

The CAPX/CHPX coils are equipped with a thermostatic expansion valve that has a built-in internal check valve for refrigerant metering. The CACF/CAPF/CHPF coils are equipped with a fixed restrictor orifice.

The coils are designed for upflow, counterflow or horizontal application, using two-speed direct drive motors on the CACF/CAPF/CHPX models and BPM (Brushless Permanent Magnet) or ECM motors on the MBE models.

The ARUF is a multi-position air handler (upflow/horizontal or downflow) and is equipped with a flowrator for cooling and heat pump applications. Because of its seamless copper tubing and aluminum fins, there are fewer leaks. The steel cabinet of the ARUF is fully insulated and rust resistant. Thermal expansion kits for air conditioning and heat pump applications are available.

ARPF*B 2 to 5 ton air handlers are dedicated for downflow operation and are approved for modular homes. Flowrater. transformer and blower time delay are on all standard ARPF units. Both the ARUF and ARPF have direct-drive multispeed motors.

AEPF is a multi-position, variable-speed air handler and can be used with R-410A or R-22 (models ending in 1/16). The unit's blower design includes a variable-speed DC motor and is compatible with heat pumps and variable-capacity cooling applications.

ASPF is a multi-position air handler that can be used with R-410A or R-22 and it features a X-13 motor. This motor is a constant torque motor with very low power consumption and it is energized by a 24V signal. The X-13 features an integrated control module and is compatible with heat pumps and cooling applications.

COOLING

The refrigerant used in the system is R-22. It is a clear, colorless, non-toxic, non-irritating, and non-explosive liquid. The chemical formula is $CHCLF_2$. The boiling point, at atmospheric pressure is -41.4°F.

A few of the important principles that make the refrigeration cycle possible are: heat always flows from a warmer to a cooler body, under lower pressure a refrigerant will absorb heat and vaporize at a low temperature, the vapors may be drawn off and condensed at a higher pressure and temperature to be used again.

The indoor evaporator coil functions to cool and dehumidify the air conditioned spaces through the evaporative process taking place within the coil tubes.

NOTE: The pressures and temperatures shown in the refrigerant cycle illustrations on the following pages are for demonstration purposes only. Actual temperatures and pressures are to be obtained from the "Expanded Performance Chart."

Liquid refrigerant at condensing pressure and temperatures, (270 psig and 122°F), leaves the outdoor condensing coil through the drier and is metered into the indoor coil through the metering device. As the cool, low pressure, saturated refrigerant enters the tubes of the indoor coil, a portion of the liquid immediately vaporizes. It continues to soak up heat and vaporizes as it proceeds through the coil, cooling the indoor coil down to about 48°F.

Heat is continually being transferred to the cool fins and tubes of the indoor evaporator coil by the warm system air. This warming process causes the refrigerant to boil. The heat removed from the air is carried off by the vapor.

As the vapor passes through the last tubes of the coil, it becomes superheated, that is, it absorbs more heat than is necessary to vaporize it. This is assurance that only dry gas will reach the compressor. Liquid reaching the compressor can weaken or break compressor valves.

The compressor increases the pressure of the gas, thus adding more heat, and discharges hot, high pressure superheated gas into the outdoor condenser coil.

In the condenser coil, the hot refrigerant gas, being warmer than the outdoor air, first loses its superheat by heat transferred from the gas through the tubes and fins of the coil. The refrigerant now becomes saturated, part liquid, part vapor and then continues to give up heat until it condenses to a liquid alone. Once the vapor is fully liquefied, it continues to give up heat which subcools the liquid, and it is ready to repeat the cycle.

HEATING

The heating portion of the refrigeration cycle is similar to the cooling cycle. By energizing the reversing valve solenoid coil, the flow of the refrigerant is reversed. The indoor coil now becomes the condenser coil, and the outdoor coil becomes the evaporator coil.

The check valve at the indoor coil will open by the flow of refrigerant letting the now condensed liquid refrigerant bypass the indoor expansion device. The check valve at the outdoor coil will be forced closed by the refrigerant flow, thereby utilizing the outdoor expansion device.

The restrictor orifice used with the CA*F, CHPF coils and the AR*F air handler will be forced onto a seat when running in the cooling cycle, only allowing liquid refrigerant to pass through the orifice opening. In the heating cycle it will be forced off the seat allowing liquid to flow around the restrictor. A check valve is not required in this circuit.

COOLING CYCLE

When the contacts of the room thermostat close making terminals R to Y & G, the low voltage circuit of the transformer is completed. Current now flows through the magnetic holding coils of the compressor contactor (CC) and fan relay (RFC).

This draws in the normally open contact CC, starting the compressor and condenser fan motors. At the same time contacts RFC close starting the indoor fan motor.

When the thermostat is satisfied, it opens its contacts, breaking the low voltage circuit, causing the compressor contactor and indoor fan relay to open, shutting down the system.

If the room thermostat fan selector switch should be set on the "on" position, then the indoor blower would run continuous rather than cycling with the compressor.


Heat pumps energize the reversing valve thorough the "O" circuit in the room thermostat. Therefore the reversing valve remains energized as long as the thermostat subbase is in the cooling position. The only exception to this is during defrost.

DEFROST CYCLE

The defrosting of the outdoor coil is jointly controlled by the defrost timing board, defrost (30/60) control, and compressor run time.

Solid State Defrost Control

During operation the power to the circuit board is controlled by a temperature sensor, which is clamped to a return bend (3/8" coils) or a feeder tube (5 mm coils) entering the outdoor coil. Defrost timing periods of 30, 60, or 90 minutes may be selected by connecting the circuit board jumper to 30, 60, or 90 respectively. Accumulation of time for the timing period selected starts when the sensor closes (approximately 31° F), and when the room thermostat calls for heat. At the end of the timing period, the unit's defrost cycle will be initiated provided the sensor remains closed. When the sensor opens (approximately 75° F), the defrost cycle is terminated and the timing period is reset. If the defrost cycle is not terminated due to the sensor temperature, a ten minute override interrupts the unit's defrost period. The new upgraded defrost control has a 12 minute override interrupt.




HEATING CYCLE

The reversing valve on the heat pump models is energized in the cooling cycle through the "O" terminal on the room thermostat.


These models have a 24 volt reversing valve coil. When the thermostat selector switch is set in the cooling position, the "O" terminal on the thermostat is energized all the time.


Care must be taken when selecting a room thermostat. Refer to the installation instructions shipped with the product for approved thermostats.



EXPANSION VALVE/CHECK VALVE ASSEMBLY IN COOLING OPERATION








Most expansion valves used in current Amana® Brand Heat Pump products use an internally checked expansion valve.


This type of expansion valve does not require an external check valve as shown above. However, the principle of operation is the same.

RESTRICTOR ORIFICE ASSEMBLY IN COOLING OPERATION




In the cooling mode, the orifice is pushed into its seat, forcing refrigerant to flow through the metered hole in the center of the orifice.


RESTRICTOR ORIFICE ASSEMBLY IN HEATING OPERATION



In the heating mode, the orifice moves back off its seat, allowing refrigerant to flow unmetered around the outside of the orifice.

COOLING CYCLE - CONDENSING UNIT





In the cooling mode, the orifice is pushed into its seat, forcing refrigerant to flow through the metered hole in the center of the orifice.

AFE18-60A CONTROL BOARD

DESCRIPTION

The AFE18 control is designed for use in heat pump applications where the indoor coil is located above/downstream of a gas or fossil fuel furnace. It will operate with single and two stage heat pumps and single and two stage furnaces. The AFE18 control will turn the heat pump unit off when the furnace is turned on. An anti-short cycle feature is also incorporated which initiates a 3 minute timed off delay when the compressor goes off. On initial power up or loss and restoration of power, this 3 minute timed off delay will be initiated. The compressorwon't be allowed to restart until the 3 minute off delay has expired. Also included is a 5 second de-bounce feature on the "Y, E, W1 and O" thermostat inputs. These thermostat inputs must be present for 5 seconds before the AFE18 control will respond to it.


An optional outdoor thermostat, OT18-60A, can be used with the AFE18 to switch from heat pump operation to furnace operation below a specific ambient temperature setting, i.e. break even temperature during heating. When used in this manner, the "Y" heat demand is switched to the "W1" input to the furnace by the outdoor thermostat and the furnace is used to satisfy the first stage "Y" heat demand. On some controls, if the outdoor thermostat fails closed in this position

during the heating season, it will turn on the furnace during the cooling season on a "Y" cooling demand. In this situation, the furnace produces heat and increases the indoor temperature thereby never satisfying the cooling demand. The furnace will continue to operate and can only be stopped by switching the thermostat to the off position or removing power to the unit and then replacing the outdoor thermostat. When the AFE18 receives a "Y" and "O" input from the indoor thermostat, it recognizes this as a cooling demand in the cooling mode. If the outdoor thermostat is stuck in the closed position switching the "Y" demand to the "W1" furnace input during the cooling mode as described above, the AFE18 won't allow the furnace to operate. The outdoor thermostat will have to be replaced to restore the unit to normal operation.

- WARNING

HIGH VOLTAGE!

Disconnect ALL power before servicing or installing. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



TROUBLESHOOTING CHART

COOLING/HP ANALYSIS CHART

Complaint			No	Coo	ling						atis		•	I .		c	Ope	te m ratin s u re	g		
POSSIBLE CAUSE DOTS IN ANALYSIS GUIDE INDICATE "POSSIBLE CAUSE"	System will not start	Compressor will not start - fan runs	Comp. and Cond. Fan will not start	Evaporator fan will not start	Condenser fan will not start	Compressor runs - goes off on overload	Compressor cycles on overload	System runs continuously - little cooling/htg	Too cool and then too warm	Not cool enough on warm days	Certain areas too cool, others too warm	Compressor is noisy	System runs - blows cold air in heating	Unit will not terminate defrost	Unit will not defrost	Low suction pressure	Low head pressure	High suction pressure	High head pressure	Test Method Remedy	See Service Procedure Ref.
Pow er Failure	•		•	•	•		<u></u>		ļ		<u> </u>	<u> </u>	<u> </u>	ļ	L		<u> </u>	ļ	ļ	Test Voltage	S-1
Blown Fuse	•	•	Ŀ	·	•				ļ	<u> </u>	<u> </u>	-	-	-	<u> </u>	-	<u> </u>	-	ļ	Inspect Fuse Size & Type	S-1 S-1
Unbalanced Pow er, 3PH Loose Connection	•	:	•		•	:	Ľ				-	-	-	-	-	-	-	-	-	Test Voltage Inspect Connection - Tighten	S-1 S-2, S-3
Shorted or Broken Wires	÷	•	•	•	•	•	-		-	-	-	-	\vdash	-	-		-	-	-	Test Circuits With Ohmmeter	S-2, S-3
Open Fan Overload	Ť	Ť	Ť	•	•	•	•			•			Н					 	•	Test Continuity of Overload	S-17A
Faulty Thermostat	•		•	•	•				•		m		m	\vdash	-		<u> </u>	1	<u> </u>	Test Continuity of Thermostat & Wiring	S-3
Faulty Transformer	•		•	•	•							1	1	1				T		Check Control Circuit w ith Voltmeter	S-4
Shorted or Open Capacitor		•	•	•	•	•	•													Test Capacitor	S-15
Internal Compressor Overload Open		•											•							Test Continuity of Overload	S-17A
Shorted or Grounded Compressor		•				•								Ī				1		Test Motor Windings	S-17B
Compressor Stuck		•				•	•						•							Use Test Cord	S-17D
Faulty Compressor Contactor			•		•	•														Test Continuity of Coil & Contacts	S-7, S-8
Faulty Fan Relay				•																Test Continuity of Coil And Contacts	S-7
Open Control Circuit			Ļ	•			<u> </u>				ļ		_	ļ				<u> </u>		Test Control Circuit w ith Voltmeter	S-4
Low Voltage		•	ļ			•	•			ļ	ļ		ļ	ļ			ļ	ļ		Test Voltage	S-1
Faulty Evap. Fan Motor				•						_						•		_	•	Repair or Replace	S-16
Shorted or Grounded Fan Motor		ļ	ļ	ļ	•		<u> </u>		<u> </u>	ļ	ļ	-	-	↓	ļ		ļ	ļ	•	Test Motor Windings	S-16
Improper Cooling Anticipator			┡	┡			Ŀ		•		<u> </u>	-		-			Ļ	₩		Check Resistance of Anticipator	S-3B
Shortage of Refrigerant Restricted Liquid Line		-	├	-	-		÷	•	-		<u> </u>	-	•	-		•	•	₩	•	Test For Leaks, Add Refrigerant Remove Restriction, Replace Restricted Part	S-101,103 S-112
Open Element or Limit on Elec. Heater							-			_						•	•		•	Test Heater Element and Controls	S-112 S-26,S-27
Dirty Air Filter		-	-	-	-	-		:	-	•	١.	-	•	┢──		•	├	┼─	•	Inspect Filter-Clean or Replace	3-20,3-27
Dirty Indoor Coil			\vdash	┢	-		-	•	-	•	i	-	 	╁	_	•	-	\vdash	•	Inspect Coil - Clean	
Not enough air across Indoor Coil								•		•	•					•			•	Check Blow er Speed, Duct Static Press, Filter	S-200
Too much air across Indoor Coil			t		1						m	 	1	†	-		•	•		Reduce Blow er Speed	S-200
Overcharge of Refrigerant			m	m		•	•				m	•	•	m			Ė	•	•	Recover Part of Charge	S-113
Dirty Outdoor Coil			T			•	•			•						•			•	Inspect Coil - Clean	
Noncondensibles							•			•			•						•	Recover Charge, Evacuate, Recharge	S-114
Recirculation of Condensing Air							•			•									•	Remove Obstruction to Air Flow	
Infiltration of Outdoor Air								•		•	•									Check Windows, Doors, Vent Fans, Etc.	
Improperly Located Thermostat						•		<u> </u>	•							Ш				Relocate Thermostat	
Air Flow Unbalanced		ļ	<u> </u>	<u> </u>	-		<u> </u>		•	<u></u>	•	<u> </u>	<u> </u>	<u> </u>	ļ		<u> </u>	ļ	<u> </u>	Readjust Air Volume Dampers	
System Undersized		-	<u> </u>	-	-	-	<u> </u>	•	-	•	<u> </u>	l-	-	-	<u> </u>	H	<u> </u>	-	<u> </u>	Refigure Cooling Load	0 445
Broken Internal Parts Broken Valves		-	├	-	-	-		-	-	-	-	÷	•	-	-	-	•	•		Replace Compressor Test Compressor Efficiency	S-115 S-104
Inefficient Compressor		-	-	-	-		-	•	-	-	-	⊦-	•	-	-	\vdash	.	H		Test Compressor Efficiency	S-104 S-104
Wrong Type Expansion Valve						•	•	•		•			•			•	÷	Ť	•	Replace Valve	S-104 S-110
Expansion Device Restricted		-	\vdash	-		•	•	•	-	•	<u> </u>	-	-	-		•	•	+	•	Remove Restriction or Replace Expansion Device	S-110
Oversized Expansion Valve								•								Н			•	Replace Valve	
Undersized Expansion Valve			T	T		•	•	•		•	T			T		•	m	T		Replace Valve	
Expansion Valve Bulb Loose												•				П		•		Tighten Bulb Bracket	S-105
Inoperative Expansion Valve						•		•								•				Check Valve Operation	S-110
Loose Hold-dow n Bolts												•								Tighten Bolts	
Faulty Reversing Valve						•							•	•	•		•	•	•	Replace Valve or Solenoid	S-21, 122
Faulty Defrost Control			<u> </u>	L	•							_	•		•	•	•	_	•	Test Control	S-24
Faulty Defrost Thermostat			<u> </u>	_			_	<u> </u>		_			•	•	•	٠	•	•	•	Test Defrost Thermostat	S-25
Flow rator Not Seating Properly					Heat			•								ш	•	•		Check Flow rator & Seat or Replace Flow rator (He at Pump)	S-111

Cooling or Heating Cycle (Heat Pump)

[♦] Heating Cycle Only (Heat Pump)

Table of Contents

S-1	CHECKING VOLTAGE	. 36	S-41	AEP* & MBE WITH SINGLE STAGE	
S-2	CHECKING WIRING	. 36		CONDENSERS	51
S-3	CHECKING THERMOSTAT, WIRING,		S-41A	AAEP* & MBE WITH SINGLE STAGE	
	AND ANTICIPATOR	. 36		HEAT PUMPS	52
S-3A	THERMOSTAT AND WIRING	. 36	S-60	ELECTRIC HEATER (OPTIONAL ITEM)	53
S-3B	COOLING ANTICIPATOR	. 37	S-61A	CHECKING HEATER LIMIT CONTROL(S)	54
S-3C	HEATING ANTICIPATOR	. 37	S-61B	CHECKING HEATER FUSE LINK (OPTIONAL	
S-4	CHECKING TRANSFORMER AND			ELECTRIC HEATERS)	54
	CONTROL CIRCUIT	. 37	S-62	CHECKING HEATER ELEMENTS	54
S-5	CHECKING CYCLE PROTECTOR	. 37	S-100	REFRIGERATION REPAIR PRACTICE	55
S-6	CHECKING TIME DELAY RELAY	. 38	S-101	LEAK TESTING (NITROGEN OR	
S-7	CHECKING CONTACTOR AND/OR RELAYS	. 38		NITROGEN-TRACED)	55
S-8	CHECKING CONTACTOR CONTACTS	. 38	S-102	EVACUATION	55
S-9	CHECKING FAN RELAY CONTACTS	. 38	S-103	CHARGING	56
S-10	COPELAND COMFORTALERT™	. 39	S-104	CHECKING COMPRESSOR EFFICIENCY	57
S-11	CHECKING LOSS OF CHARGE PROTECTOR	. 41	S-105	A PISTON KIT CHART FOR ASC13, GSC13, VSC13	3,
S-15	CHECKING CAPACITOR	. 41		GSC14, ASH13, GSH13, VSH14, GSH14 UNITS	58
S-15A	RESISTANCE CHECK	. 41	S-105E	3 THERMOSTATIC EXPANSION VALVE	58
S-15B	CAPACITANCE CHECK	. 42	S-106	OVERFEEDING	59
S-16A	CHECKING FAN AND BLOWER		S-107	UNDERFEEDING	59
	MOTOR WINDINGS		S-108	SUPERHEAT	59
	(PSC MOTORS)	.42	S-109	CHECKING SUBCOOLING	60
S-16B	CHECKING FAN AND		S-110	CHECKING EXPANSION VALVE OPERATION	60
	BLOWER MOTOR (ECM MOTORS)	42	S-111	FIXED ORIFICE RESTRICTOR DEVICES	61
S-16C	CHECKING ECM MOTOR WINDINGS	. 43	S-112	CHECKING RESTRICTED LIQUID LINE	61
S-16D	ECM CFM ADJUSTMENTS	. 43	S-113	OVERCHARGE OF REFRIGERANT	61
S-16E	CHECKING GE X13TM MOTORS	. 47	S-114	NON-CONDENSABLES	61
S-17	CHECKING COMPRESSOR	. 47	S-115	COMPRESSOR BURNOUT	61
S-17A	RESISTANCE TEST	. 47	S-120	REFRIGERANT PIPING	62
S-17B	GROUND TEST	. 48	S-122	REVERSING VALVE REPLACEMENT	64
S-17D	OPERATION TEST	. 48	S-202	DUCT STATIC PRESSURES AND/OR	
S-18	TESTING CRANKCASE HEATER			STATIC PRESSURE DROP ACROSS COILS	64
	(OPTIONAL ITEM)	. 49	S-203	AIR HANDLER EXTERNAL STATIC	64
S-21	CHECKING REVERSING VALVE AND SOLENOID	. 49	S-204	COIL STATIC PRESSURE DROP	65
S-24	TESTING DEFROST CONTROL	. 49			
S-25	TESTING DEFROST THERMOSTAT	49			
S-40	AR*F & MBR ELECTRONIC BLOWERS				
	TIME DELAY RELAY	. 50			



HIGH VOLTAGE!

DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

S-1 CHECKING VOLTAGE

1. Remove outer case, control panel cover, etc., from unit being tested.

With power ON:



- 2. Using a voltmeter, measure the voltage across terminals L1 and L2 of the contactor for the condensing unit or at the field connections for the air handler or heaters.
- 3. No reading indicates open wiring, open fuse(s) no power or etc., from unit to fused disconnect service. Repair as needed.
- 4. With ample voltage at line voltage connectors, energize the unit.
- Measure the voltage with the unit starting and operating, and determine the unit <u>Locked Rotor Voltage</u>. **NOTE**: If checking heaters, be sure all heating elements are energized.

Locked Rotor Voltage is the actual voltage available at the compressor during starting, locked rotor, or a stalled condition. Measured voltage should be above minimum listed in chart below.

To measure Locked Rotor Voltage attach a voltmeter to the run "R" and common "C" terminals of the compressor, or to the T_1 and T_2 terminals of the contactor. Start the unit and allow the compressor to run for several seconds, then shut down the unit. Immediately attempt to restart the unit while measuring the Locked Rotor Voltage.

Lock rotor voltage should read within the voltage tabulation as shown. If the voltage falls below the minimum voltage, check the line wire size. Long runs of undersized wire can cause low voltage. If wire size is adequate, notify the local power company in regard to either low or high voltage.

	CONDENSIN OWER COIL	
VOLTAGE	MIN.	MAX.
208/230	198	253
115	104	127

NOTE: When operating electric heaters on voltages other than 240 volts, refer to the System Operation section on electric heaters to calculate temperature rise and air flow. Low voltage may cause insufficient heating.

S-2 CHECKING WIRING



WARNING

HIGH VOLTAGE

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



- Check wiring visually for signs of overheating, damaged insulation and loose connections.
- 2. Use an ohmmeter to check continuity of any suspected open wires.
- 3. If any wires must be replaced, replace with comparable gauge and insulation thickness.

S-3 CHECKING THERMOSTAT, WIRING, AND ANTICIPATOR

THERMOSTAT WI	RE SIZING CHART
LENGTH OF RUN	MIN. COPPER WIRE GAUGE (AWG)
25 feet	18
50 feet	16
75 feet	14
100 feet	14
125 feet	12
150 feet	12

S-3A THERMOSTAT AND WIRING



WARNING

Line Voltage now present.

With power ON, thermostat calling for cooling

- 1. Use a voltmeter to check for 24 volts at thermostat wires C and Y in the condensing unit control panel.
- 2. No voltage indicates trouble in the thermostat, wiring or external transformer source.
- 3. Check the continuity of the thermostat and wiring. Repair or replace as necessary.

Indoor Blower Motor

With power ON:



- 1. Set fan selector switch at thermostat to "ON" position.
- 2. With voltmeter, check for 24 volts at wires C and G.

- No voltage indicates the trouble is in the thermostat or wiring.
- 4. Check the continuity of the thermostat and wiring. Repair or replace as necessary.

Resistance Heaters

- 1. Set room thermostat setpoint to a higher temperature than room temperature to assure both stages call for heat.
- 2. With voltmeter, check for 24 volts at each heater relay. Note: BBA/BBC heater relays are DC voltage.
- No voltage indicates the trouble is in the thermostat or wiring.
- 4. Check the continuity of the thermostat and wiring. Repair or replace as necessary.

NOTE: Consideration must be given to how the heaters are wired (O.D.T. and etc.). Also safety devices must be checked for continuity.

S-3B COOLING ANTICIPATOR

The cooling anticipator is a small heater (resistor) in the thermostat. During the "off" cycle, it heats the bimetal element helping the thermostat call for the next cooling cycle. This prevents the room temperature from rising too high before the system is restarted. A properly sized anticipator should maintain room temperature within 1 1/2 to 2 degree range.

The anticipator is supplied in the thermostat and is not to be replaced. If the anticipator should fail for any reason, the thermostat must be changed.

S-3C HEATING ANTICIPATOR

The heating anticipator is a wire wound adjustable heater which is energized during the "ON" cycle to help prevent overheating of the conditioned space.

The anticipator is a part of the thermostat and if it should fail for any reason, the thermostat must be replaced. See the following tables for recommended heater anticipator setting in accordance to the number of electric heaters installed.

problems that may be relayed to the output response of the B13682-74 VSTM control.

S-4 CHECKING TRANSFORMER AND CONTROL CIRCUIT



HIGH VOLTAGE

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



A step-down transformer (208/240 volt primary to 24 volt secondary) is provided with each indoor unit. This allows ample capacity for use with resistance heaters. The outdoor sections do not contain a transformer.



Disconnect ALL power before servicing.

 Remove control panel cover, or etc., to gain access to transformer.

With power ON:



- 2. Using a voltmeter, check voltage across secondary voltage side of transformer (R to C).
- 3. No voltage indicates faulty transformer, bad wiring, or bad splices.
- Check transformer primary voltage at incoming line voltage connections and/or splices.
- 5 If line voltage available at primary voltage side of transformer and wiring and splices good, transformer is inoperative. Replace.

S-5 CHECKING CYCLE PROTECTOR

Some models feature a solid state, delay-on make after break time delay relay installed in the low voltage circuit. This control is used to prevent short cycling of the compressor under certain operating conditions.

The component is normally closed (R_1 to Y_1). A power interruption will break circuit (R_1 to Y_1) for approximately three minutes before resetting.

- Remove wire from Y₁ terminal.
- 2. Wait for approximately four (4) minutes if machine was running.

With power ON:



- 1. Apply 24 VAC to terminals R₁ and R₂.
- 2. Should read 24 VAC at terminals Y₁ and Y₂.

- 3. Remove 24 VAC at terminals R₁ and R₂.
- 4. Should read 0 VAC at Y₁ and Y₂.
- Reapply 24 VAC to R1 and R2 within approximately three (3) to four (4) minutes should read 24 VAC at Y₁ and Y₂.

If not as above - replace relay.

S-6 CHECKING TIME DELAY RELAY

Time delay relays are used in some of the blower cabinets to improve efficiency by delaying the blower off time. Time delays are also used in electric heaters to sequence in multiple electric heaters.




WARNING -

Disconnect ALL power before servicing.

- Tag and disconnect all wires from male spade connections of relay.
- Using an ohmmeter, measure the resistance across terminals H1 and H2. Should read approximately 150 ohms.
- 3. Using an ohmmeter, check for continuity across terminals 3 and 1, and 4 and 5.
- Apply 24 volts to terminals H1 and H2. Check for continuity across other terminals - should test continuous. If not as above - replace.

NOTE: The time delay for the contacts to make will be approximately 20 to 50 seconds and to open after the coil is de-energized is approximately 40 to 90 seconds.



TESTING COIL CIRCUIT

S-7 CHECKING CONTACTOR AND/OR RELAYS



WARNING -

HIGH VOLTAGE!

Disconnect ALL power before servicing or installing. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.

The compressor contactor and other relay holding coils are wired into the low or line voltage circuits. When the control circuit is energized, the coil pulls in the normally open

contacts or opens the normally closed contacts. When the coil is de-energized, springs return the contacts to their normal position.

NOTE: Most single phase contactors break only one side of the line (L1), leaving 115 volts to ground present at most internal components.

- 1. Remove the leads from the holding coil.
- 2. Using an ohmmeter, test across the coil terminals.

If the coil does not test continuous, replace the relay or contactor.

S-8 CHECKING CONTACTOR CONTACTS



DISCONNECT ELECTRICAL POWER SUPPLY.

Disconnect Electrical Power Supply:


- Disconnect the wire leads from the terminal (T) side of the contactor.
- 2. With power ON, energize the contactor.



3. Using a voltmeter, test across terminals.

A. L2 - T1 - No voltage indicates CC1 contacts open.

If a no voltage reading is obtained - replace the contactor.



TESTING COMPRESSOR CONTACTOR

S-9 CHECKING FAN RELAY CONTACTS




WARNING

HIGH VOLTAGE

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



- 1. Disconnect wires leads from terminals 2 and 4 of Fan Relay Cooling and 2 and 4.5 and 6 of Fan Relay Heating.
- 2. Using an ohmmeter, test between 2 and 4 should read open. Test between 5 and 4 should read continuous.
- 3. With power ON, energize the relays.



TESTING FAN RELAY

- 4. Using an ohmmeter, test between 2 and 4 should read continuous. Test between 5 and 4 should read open.
- 5. If not as above, replace the relay.

S-10 COPELAND COMFORT ALERT™

DIAGNOSTICS

Applies to ASC13 & ASH13




HIGH VOLTAGE

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



Comfort Alert™ is self-contained with no required external sensors and is designed to install directly into the electrical box of any residential condensing unit that has a Copeland Scroll™ compressor inside.

Once attached, Comfort Alert™ provides around-the-clock monitoring for common electrical problems, compressor defects and broad system faults. If a glitch is detected, an LED indicator flashes the proper alert codes to help you quickly pinpoint the problem. See Diagnostic Table on following page.)




Green power LED indicates voltage is present at the power connection of the module.



DIAGNOSTICS TABLE

Status LED	Status LED Description	Status LED Troubleshooting Information
Green "POWER"	Module has power	Supply voltage is present at module terminals
Red "TRIP"	Thermostat demand signal	Compressor protector is open
	Y1 is present, but the	2. Outdoor unit power disconnect is open
	compressor is not	3. Compressor circuit breaker or fuse(s) is open
	running	4. Broken wire or connector is not making contact
		5. Low pressure switch open if present in system
		6. Compressor contactor has failed open
Yellow "ALERT"	Long Run Time	1. Low refrigerant charge
Flash Code 1	Compressor is	2. Evaporator blower is not running
	running extremely	3. Evaporator coil is frozen
	long run cycles	4. Faulty metering device
		5. Condenser coil is dirty
		6. Liquid line restriction (filter drier blocked if present in system)
		7. Thermostat is malfunctioning
Yellow "ALERT"	System Pressure Trip	1. High head pressure
Flash Code 2	Discharge or suction	2. Condenser coil poor air circulation (dirty, blocked, damaged)
	pressure out of limits or	3. Condenser fan is not running
	compressor overloaded	4. Return air duct has substantial leakage
		5. If low pressure switch present in system,
		check Flash Code 1 information
Yellow "ALERT"	Short Cycling	Thermostat demand signal is intermittent
Flash Code 3	Compressor is running	2. Time delay relay or control board defective
	only briefly	3. If high pressure switch present go to Flash Code 2 information
		4. If low pressure switch present go to Flash Code 1 information
Yellow "ALERT"	Locked Rotor	1. Run capacitor has failed
Flash Code 4		2. Low line voltage (contact utility if voltage at disconnect is low)
		3. Excessive liquid refrigerant in compressor
		4. Compressor bearings are seized
Yellow "ALERT"	Open Circuit	Outdoor unit power disconnect is open
Flash Code 5		2. Compressor circuit breaker or fuse(s) is open
		3. Compressor contactor has failed open
		4. High pressure switch is open and requires manual reset
		5. Open circuit in compressor supply wiring or connections
		6. Unusually long compressor protector reset time
		due to extreme ambient temperature
		7. Compressor windings are damaged
Yellow "ALERT"	Open Start Circuit	1. Run capacitor has failed
Flash Code 6	Current only in run circuit	Open circuit in compressor start wiring or connections
		3. Compressor start winding is damaged
Yellow "ALERT"	Open Run Circuit	Open circuit in compressor run wiring or connections
Flash Code 7	Current only in start circuit	2. Compressor run winding is damaged
Yellow "ALERT"	Welded Contactor	Compressor contactor has failed closed
Flash Code 8	Compressor always runs	Thermostat demand signal not connected to module
Yellow "ALERT"	Low Voltage	Control circuit transformer is overloaded
Flash Code 9	Control circuit < 17VAC	2. Low line voltage (contact utility if voltage at disconnect is low)

- Flash Code number corresponds to a number of LED flashes, followed by a pause and then repeated
- TRIP and ALERT LEDs flashing at same time means control circuit voltage is too low for operation.
- Reset ALERT Flash code by removing 24VAC power from module
- Last ALERT Flash code is displayed for 1 minute after module is powered on.



S-11 CHECKING LOSS OF CHARGE PROTECTOR

(Heat Pump Models)

The loss of charge protector senses the pressure in the liquid line and will open its contacts on a drop in pressure. The low pressure control will automatically reset itself with a rise in pressure.

The low pressure control is designed to cut-out (open) at approximately 7 PSIG. It will automatically cut-in (close) at approximately 25 PSIG.

Test for continuity using a VOM and if not as above, replace the control.

S-15 CHECKING CAPACITOR CAPACITOR, RUN

A run capacitor is wired across the auxiliary and main windings of a single phase permanent split capacitor motor. The capacitors primary function is to reduce the line current while greatly improving the torque characteristics of a motor. This is accomplished by using the 90° phase relationship between the capacitor current and voltage in conjunction with the motor windings, so that the motor will give two phase operation when connected to a single phase circuit. The capacitor also reduces the line current to the motor by improving the power factor.

The line side of this capacitor is marked with "COM" and is wired to the line side of the circuit.

CAPACITOR, START

SCROLL COMPRESSOR MODELS

In most cases hard start components are not required on Scroll compressor equipped units due to a non-replaceable check valve located in the discharge line of the compressor. However, in installations that encounter low lock rotor voltage, a hard start kit can improve starting characteristics and

reduce light dimming within the home. Only hard start kits approved by Amana® brand or Copeland should be used. "Kick Start" and/or "Super Boost" kits are not approved start assist devices.


The discharge check valve closes off high side pressure to the compressor after shut down allowing equalization through the scroll flanks. Equalization requires only about ½ second.

To prevent the compressor from short cycling, a Time Delay Relay (Cycle Protector) has been added to the low voltage circuit.

RELAY, START


A potential or voltage type relay is used to take the start capacitor out of the circuit once the motor comes up to speed. This type of relay is position sensitive. The normally closed contacts are wired in series with the start capacitor and the relay holding coil is wired parallel with the start winding. As the motor starts and comes up to speed, the increase in voltage across the start winding will energize the start relay holding coil and open the contacts to the start capacitor.

Two quick ways to test a capacitor are a resistance and a capacitance check.



HARD START KIT WIRING

S-15A RESISTANCE CHECK



HIGH VOLTAGE

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.




1. Discharge capacitor and remove wire leads.



WARNING

Discharge capacitor through a 20 to 30 OHM resistor before handling.




TESTING CAPACITOR RESISTANCE

- 2. Set an ohmmeter on its highest ohm scale and connect the leads to the capacitor -
 - A. Good Condition indicator swings to zero and slowly returns to infinity. (Start capacitor with bleed resistor will not return to infinity. It will still read the resistance of the resistor).
 - B. Shorted indicator swings to zero and stops there replace.
 - C. Open no reading replace. (Start capacitor would read resistor resistance.)

S-15B CAPACITANCE CHECK

Using a hookup as shown below, take the amperage and voltage readings and use them in the formula:





WARNING -

Discharge capacitor through a 20 to 30 OHM resistor before handling.

Capacitance (MFD) = 2650 X Amperage

Voltage

S-16A CHECKING FAN AND BLOWER MOTOR WINDINGS (PSC MOTORS)

The auto reset fan motor overload is designed to protect the motor against high temperature and high amperage conditions by breaking the common circuit within the motor, similar to the compressor internal overload. However, heat generated within the motor is faster to dissipate than the compressor, allow at least 45 minutes for the overload to reset, then retest.



WARNING

HIGH VOLTAGE

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



- 1. Remove the motor leads from its respective connection points and capacitor (if applicable).
- 2. Check the continuity between each of the motor leads.
- 3. Touch one probe of the ohmmeter to the motor frame (ground) and the other probe in turn to each lead.


If the windings do not test continuous or a reading is obtained from lead to ground, replace the motor.


S-16B CHECKING FAN AND BLOWER MOTOR (ECM MOTORS)

An ECM is an *Electronically Commutated Motor* which offers many significant advantages over PSC motors. The ECM has near zero rotor loss, synchronous machine operation, variable speed, low noise, and programmable air flow. Because of the sophisticated electronics within the ECM motor, some technicians are intimated by the ECM motor; however, these fears are unfounded. GE offers two ECM motor testers, and with a VOM meter, one can easily perform basic troubleshooting on ECM motors. An ECM motor requires power (line voltage) and a signal (24 volts) to operate. The ECM motor stator contains permanent magnet. As a result, the shaft feels "rough" when turned by hand. This is a characteristic of the motor, not an indication of defective bearings.



- 1. Disconnect the 5-pin connector from the motor.
- 2. Using a volt meter, check for line voltage at terminals #4 & #5 at the power connector. If no voltage is present:
- 3. Check the unit for incoming power See section S-1.
- 4. Check the control board, See section S-40.
- 5. If line voltage is present, reinsert the 5-pin connector and remove the 16-pin connector.
- 6. Check for signal (24 volts) at the transformer.
- 7. Check for signal (24 volts) from the thermostat to the "G" terminal at the 16-pin connector.
- 8. Using an ohmmeter, check for continuity from the #1 & #3 (common pins) to the transformer neutral or "C" thermostat terminal. If you do not have continuity, the motor may function erratically. Trace the common circuits, locate and repair the open neutral.
- 9. Set the thermostat to "Fan-On". Using a voltmeter, check for 24 volts between pin # 15 (G) and common.
- Disconnect power to compressor. Set thermostat to call for cooling. Using a voltmeter, check for 24 volts at pin # 6 and/or #14.
- 11. Set the thermostat to a call for heating. Using a voltmeter, check for 24 volts at pin #2 and/or #11.





16-PIN ECM HARNESS CONNECTOR

If you do not read voltage and continuity as described, the problem is in the control or interface board, but not the motor. If you register voltage as described, the ECM power head is defective and must be replaced.

S-16C CHECKING ECM MOTOR WINDINGS



HIGH VOLTAGE

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



- 1. Disconnect the 5-pin and the 16-pin connectors from the ECM power head.
- 2. Remove the 2 screws securing the ECM power head and separate it from the motor.
- 3. Disconnect the 3-pin motor connector from the power head and lay it aside.
- 4. Using an ohmmeter, check the motor windings for continuity to ground (pins to motor shell). If the ohmmeter indicates continuity to ground, the motor is defective and must be replaced.
- 5. Using an ohmmeter, check the windings for continuity (pin to pin). If no continuity is indicated, the thermal limit (overload) device may be open. Allow motor to cool and retest.

	Trouble	shooting Chart for ECM Variable	Troubleshooting Chart for ECM Variable Speed Air Circulator Blower Motors	S
Symptom	Fault Description(s)	Possible Causes	Corrective Action	Cautions and Notes
- Motor rocks slightly when starting.	- This is normal start-up for variable speed motor.	_		
- Motor won't start.	- No movement.	- Manual disconnect switch off or door switch open Blown fuse or circuit breaker 24 Vac wires miswired Unseated pins in wiring harness connectors Bad motor/control module Moisture present in motor or control module.	- Check 230 Vac power at motor Check low voltage (24 Vac R to C) at motor Check low voltage connections (G, Y, W, R, C) at motor Check for unseated pins in connectors on motor harness Test with a temporary jumper between R - G.	- Tum power OFF prior to repair. Wait 5 minutes after disconnecting power before opening motor. - Handle electronic motor/control with care.
	- Motor rocks, but won't start.	- Loose motor mount. - Blower wheel not tight on motor shaft. - Bad motor/control module.	 Check for loose motor mount. Make sure blower wheel is tight on shaft. Perform motor/control replacement check, ECM motors only. 	- Turn power OFF prior to repair. Wait 5 minutes after disconnecting power before opening motor Handle electronic motor/control with care.
- Motor oscillates up & down while being tested off of blower.	- It is normal for motor to oscillate with no load on shaft.			
- Motor starts, but runs erratically.	- Varies up and down or intermittent.	- Variation in 230 Vac to motor Unseated pins in wiring harness connectors Erratic CFM command from "BK" terminal Improper thermostat connection or setting.	- Check line voltage for variation or "sag" Check low voltage connections (G, Y, W, R, C) at motor, unseated pins in motor harmess connectors Check-out system controls - Thermostat.	- Tum power OFF prior to repair.
	- "Hunts" or "puffs" at high CFM (speed).	 Incorrect or dirty filter(s). Incorrect supply or return ductwork. Incorrect blower speed setting. 	 Does removing panel or filter reduce "puffing"? Check/replace filter. Check/correct duct restrictions. Adjust to correct blower speed setting. 	- Tum power OFF prior to repair.

- Connectors are oriented "down" (or as recommended by equipment manufacturer).
 is condensate drain plugged?
 Check for undergranged condition.

Note: You must use the correct replacement control/motor module since they are factory programmed for specific operating modes. Even though they look alike, different modules may have completely different functionality. The ECM variable speed motors are c Important Note: Using the wrong motor/control module voids all product warranties and may produce unexpected results. - Arrange harnesses with "drip loop" under motor. - Cneck for low arraow (too much latent capacity). - Cneck and plug leaks in return ducts, cabinet.

CHART CONTINUED ON NEXT PAGE

CHART CONTINUED FROM PREVIOUS PAGE

Symptom	Trouble Fault Description(s)	shooting Chart for ECM Variable Possible Causes	Troubleshooting Chart for ECM Variable Speed Air Circulator Blower Motors	S Cautions and Notes
	- Stays at low CFM despite system call for cool or heat CFM.	- 24 Vac wires miswired or loose. - "R" missing/not connected at motor. - Fan in delay mode.	- Check low voltage (Thermostat) wires and connections Verify fan is not in delay mode - wait until delay complete Perform motor/control replacement check, ECM motors only.	- Turn power OFF prior to repair. Wait 5 minutes after disconnecting power before opening motor Handle electronic motor/control with care.
- Motor starts, but runs erratically.	- Stays at high CFM.	- "R" missing/not connected at motor. - Fan in delay mode.	 Is fan in delay mode? - wait until delay time complete. Perform motor/control replacement check, ECM motors only. 	- Turn power OFF prior to repair. Wait 5 minutes after disconnecting power before opening motor Handle electronic motor/control with care.
	- Blower won't shut off.	- Current leakage from controls into G, Y, or W.	- Check for Triac switched t'stat or solid state relay.	- Tum power OFF prior to repair.
	- Air noise.	 High static creating high blower speed. Incorrect supply or return ductwork. Incorrect or dirty filter(s). Incorrect blower speed setting. 	 Check/replace filter. Check/correct duct restrictions. Adjust to correct blower speed setting. 	- Tum power OFF prior to repair.
- Excessive noise.	- Noisy blower or cabinet.	 Loose blower housing, panels, etc. High static creating high blower speed. Air leaks in ductwork, cabinets, or panels. 	- Check for loose blower housing, panels, etc Check for air whistling thru seams in ducts, cabinets or panels Check for cabinet/duct deformation.	- Tum power OFF prior to repair.
	- "Hunts" or "puffs" at high CFM (speed).	 High static creating high blower speed. Incorrect or dirty filter(s). Incorrect supply or return ductwork. Incorrect blower speed setting. 	 Does removing panel or filter reduce "puffing"? Check/replace filter. Check/correct duct restrictions. Adjust to correct blower speed setting. 	- Tum power OFF prior to repair.
- Evidence of Moisture.	- Motor failure or maifunction has occurred and moisture is present.	- Moisture in motor/control module.	- Replace motor and perform Moisture Check.*	- Tum power OFF prior to repair. Wait 5 minutes after disconnecting power before opening motor Handle electronic motor/control with care.

- Connectors are oriented "down" (or as recommended by equipment manufacturer).
 Is condensate drain plugged?
 Oneck for undercharged condition.

Note: You must use the correct replacement control/motor module since they are factory programmed for specific operating modes. Even though they look alike, different modules may have completely different functionality. The ECM variable speed motors are c Important Note: Using the wrong motor/control module voids all product warranties and may produce unexpected results.

Arrange hamesses with "drip loop" under motor.
 Cneck for low airflow (too much latent capacity).
 Cneck and plug leaks in return ducts, capinet.



S-16D ECM CFM ADJUSTMENTS

MBE MOTOR

This section references the operation characteristics of the MBE model motor only. The ECM control board is factory set with the dipswitch #4 in the "ON" position and all other dipswitches are factory set in the "OFF" position. When MBE is used with 2-stage cooling units, dipswitch #4 should be in the "OFF" position.

For most applications, the settings are to be changed according to the electric heat size and the outdoor unit selection.

The MBE product uses a General Electric ECM™ motor. This motor provides many features not available on the traditional PSC motor. These features include:

- Improved Efficiency
- Constant CFM
- Soft Start and Stop
- Improved Humidity Control

MOTOR SPEED ADJUSTMENT

Each ECM™ blower motor has been preprogrammed for operation at 4 distinct airflow levels when operating in Cooling/Heat Pump mode or Electric Heat mode. These 4 distinct levels may also be adjusted slightly lower or higher if desired. The adjustment between levels and the trim adjustments are made by changing the dipswitch(s) either to an "OFF" or "ON" position.

DIPSWITCH FUNCTIONS

The MBE air handler motor has an electronic control that contains an eight (8) position dip switch. The function of these dipswitches are shown in **Table 1**.

Dipswitch Number	Function					
1	Electric Heat					
2	Electric Fredt					
3	N/A					
4	Indoor Thermostat					
5	Cooling & Hoot Dump CEM					
6	Cooling & Heat Pump CFM					
7	CFM Trim Adjust					
8	Or W. Trilli Aujust					

Table 1

CFM DELIVERY

Tables 2, 2A and **3, 3A** show the CFM output for dipswitch combinations 1-2, 5-6 and 7-8.

Electric Heat Operation

Model	Switch 1	Switch 2	CFM
	OFF	OFF	1,200
MBE1200	ON	OFF	1,000
WIBLIZOO	OFF	ON	800
	ON	ON	600
	OFF	OFF	1,600
MBE1600	ON	OFF	1,400
WIBE1000	OFF	ON	1,200
	ON	ON	1,000
	OFF	OFF	2,000
MBE2000	ON	OFF	1,800
WIBE2000	OFF	ON	1,600
	ON	ON	1,200

Table 2

Cooling/Heat Pump Operation

Model	Switch 5	Switch 6	CFM
	OFF	OFF	1,200
MBE1200	ON	OFF	1,000
WIDE 1200	OFF	ON	800
	ON	ON	600
	OFF	OFF	1,600
MBE1600	ON	OFF	1,400
WIDE 1000	OFF	ON	1,200
	ON	ON	1,000
	OFF	OFF	1,600
MBE2000	ON	OFF	1,400
WIDEZUUU	OFF	ON	1,200
	ON	ON	1,000

Table 2A

Dipswitch 1/2 & 7/8 AEPF 1830

Heating Element	Switch Position		Sw i Posi		Emergency Backup	Heat Pump With
(kw)	1	2	7	8	Баскир	Backup
UP TO 10	OFF	OFF	OFF	OFF	1100	1210
UP TO 10	ON	OFF	OFF	OFF	890	935
5	OFF	ON	OFF	OFF	700	770

AEPF3036 / 3137 / 4260

Heating Element	Swi Posi		Swi Posi		Emergency Backup	Heat Pump With
(kw)	1	2	7	8	Баскир	Backup
UP TO 20	OFF	OFF	OFF	OFF	2050	2150
UP TO 20	ON	0 FF	OFF	OFF	1750	1835
UP TO 15	OFF	ON	OFF	OFF	1600	1680
UP TO 10	ON	ON	OFF	OFF	1200	1260
UP TO 10	ON	ON	OFF	ON	1020	1070

Table 3

Dipswitch 5/6 & 7/8

AEPF 1830

	itch ition	Swi Posi		Indoor	Airflow
5	6	7	8	Cooling	Heat Pump
OFF	OFF	OFF	OFF	1100	1100
ON	OFF	OFF	OFF	800	800
OFF	ON	OFF	OFF	600	600

AEPF3036 / 3137 / 4260

	itch tion	Switch Position		Indoor Airflow	
5	6	7	8	Cooling	Heat Pump
OFF	OFF	OFF	OFF	1800	1800
ON	OFF	OFF	OFF	1580	1580
OFF	ON	OFF	OFF	1480	1480
ON	ON	OFF	OFF	1200	1200
ON	ON	OFF	ON	1020	1020

Table 3A

THERMOSTAT "FAN ONLY" MODE

CFM TRIM ADJUST

Minor adjustments can be made through the dip switch combination of 7-8. **Table 4** shows the switch position for this feature.

NOTE: The airflow will not make the decreasing adjustment in Electric Heat mode.

CFM	Switch 7	Switch 8
+10%	ON	OFF
-15%	OFF	ON

Table 4

HUMIDITY CONTROL

When using a Humidstat (normally closed), cut jumper PJ6 on the control board. The Humidstat will only affect cooling airflow by adjusting the Airflow to 85%.

TWO STAGE HEATING

When using staged electric heat, cut jumper PJ4 on the control board.


S-16E CHECKING GE X13™ MOTORS

The GE X13TM Motor is a one piece, fully encapsulated, 3 phase brushless DC (single phase AC input) motor with ball bearing construction. Unlike the ECM 2.3/2.5 motors, the GE X13TM features an integral control module.

Note: The GE TECMate will not currently operate the GE X13™ motor.

- 1. Using a voltmeter, check for 230 volts to the motor connections L and N. If 230 volts is present, proceed to step 2. If 230 volts is not present, check the line voltage circuit to the motor.
- 2. Using a voltmeter, check for 24 volts from terminal C to either terminal 1, 2, 3, 4, or 5, depending on which tap is being used, at the motor. If voltage present, proceed to step 3. If no voltage, check 24 volt circuit to motor.
- 3. If voltage was present in steps 1 and 2, the motor has failed and will need to be replaced.

Note: When replacing motor, ensure the belly band is between the vents on the motor and the wiring has the proper drip loop to prevent condensate from entering the motor.



GE X13™ MOTOR CONNECTIONS

S-17 CHECKING COMPRESSOR



WARNING

Hermetic compressor electrical terminal venting can be dangerous. When insulating material which supports a hermetic compressor or electrical terminal suddenly disintegrates due to physical abuse or as a result of an electrical short between the terminal and the compressor housing, the terminal may be expelled, venting the vapor and liquid contents of the compressor housing and system.

If the compressor terminal PROTECTIVE COVER and gasket (if required) are not properly in place and secured, there is a remote possibility if a terminal vents, that the vaporous and liquid discharge can be ignited, spouting flames several feet, causing potentially severe or fatal injury to anyone in its path.

This discharge can be ignited external to the compressor if the terminal cover is not properly in place and if the discharge impinges on a sufficient heat source.

Ignition of the discharge can also occur at the venting terminal or inside the compressor, if there is sufficient contaminant air present in the system and an electrical arc occurs as the terminal vents.

Ignition cannot occur at the venting terminal without the presence of contaminant air, and cannot occur externally from the venting terminal without the presence of an external ignition source.

Therefore, proper evacuation of a hermetic system is essential at the time of manufacture and during servicing.

To reduce the possibility of external ignition, all open flame, electrical power, and other heat sources should be extinguished or turned off prior to servicing a system.

If the following test indicates shorted, grounded or open windings, see procedures S-19 for the next steps to be taken.

S-17A RESISTANCE TEST

Each compressor is equipped with an internal overload.

The line break internal overload senses both motor amperage and winding temperature. High motor temperature or amperage heats the disc causing it to open, breaking the common circuit within the compressor on single phase units.

Heat generated within the compressor shell, usually due to recycling of the motor, high amperage or insufficient gas to cool the motor, is slow to dissipate. Allow at least three to four hours for it to cool and reset, then retest.

Fuse, circuit breaker, ground fault protective device, etc. has not tripped -



WARNING

HIGH VOLTAGE

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.




1. Remove the leads from the compressor terminals.



WARNING -

See warnings S-17 before removing compressor terminal cover.

2. Using an ohmmeter, test continuity between terminals S-R, C-R, and C-S, on single phase units or terminals T2, T2 and T3, on 3 phase units.



TESTING COMPRESSOR WINDINGS

If either winding does not test continuous, replace the compressor.

NOTE: If an open compressor is indicated, allow ample time for the internal overload to reset before replacing compressor.


S-17B GROUND TEST

If fuse, circuit breaker, ground fault protective device, etc., has tripped, this is a strong indication that an electrical problem exists and must be found and corrected. The circuit protective device rating must be checked, and its maximum rating should coincide with that marked on the equipment nameplate.

With the terminal protective cover in place, it is acceptable to replace the fuse or reset the circuit breaker <u>ONE TIME ONLY</u> to see if it was just a nuisance opening. If it opens again, <u>DO</u> NOT continue to reset.

Disconnect all power to unit, making sure that <u>all</u> power legs are open.

- 1. DO NOT remove protective terminal cover. Disconnect the three leads going to the compressor terminals at the nearest point to the compressor.
- Identify the leads and using a Megger, Hi-Potential Ground Tester, or other suitable instrument which puts out a voltage between 300 and 1500 volts, check for a ground separately between each of the three leads and ground (such as an unpainted tube on the compressor).
 Do not use a low voltage output instrument such as a voltohmmeter.



COMPRESSOR GROUND TEST

- 3. If a ground is indicated, then carefully remove the compressor terminal protective cover and inspect for loose leads or insulation breaks in the lead wires.
- 4. If no visual problems indicated, carefully remove the leads at the compressor terminals.



WARNING -

Damage can occur to the glass embedded terminals if the leads are not properly removed. This can result in terminal and hot oil discharging.

Carefully retest for ground, directly between compressor terminals and ground.

5. If ground is indicated, replace the compressor.

S-17D OPERATION TEST

If the voltage, capacitor, overload and motor winding test fail to show the cause for failure:



WARNING

HIGH VOLTAGE


Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



1. Remove unit wiring from disconnect switch and wire a test cord to the disconnect switch.


NOTE: The wire size of the test cord must equal the line wire size and the fuse must be of the proper size and type.

- With the protective terminal cover in place, use the three leads to the compressor terminals that were disconnected at the nearest point to the compressor and connect the common, start and run clips to the respective leads.
- 3. Connect good capacitors of the right MFD and voltage rating into the circuit as shown.
- 4. With power ON, close the switch.



- A. If the compressor starts and continues to run, the cause for failure is somewhere else in the system.
- B. If the compressor fails to start replace.

COPELAND COMPRESSOR



S-18 TESTING CRANKCASE HEATER (OP-TIONAL ITEM)

The crankcase heater must be energized a minimum of four (4) hours before the condensing unit is operated.

Crankcase heaters are used to prevent migration or accumulation of refrigerant in the compressor crankcase during the off cycles and prevents liquid slugging or oil pumping on start up.

A crankcase heater will not prevent compressor damage due to a floodback or over charge condition.

–**⚠** WARNING *–*

Disconnect ALL power before servicing.

- 1. Disconnect the heater lead in wires.
- 2. Using an ohmmeter, check heater continuity should test continuous. If not, replace.

NOTE: The positive temperature coefficient crankcase heater is a 40 watt 265 voltage heater. The cool resistance of the heater will be approximately 1800 ohms. The resistance will become greater as the temperature of the compressor shell increases.

S-21 CHECKING REVERSING VALVE AND SO-LENOID

Occasionally the reversing valve may stick in the heating or cooling position or in the mid-position.

When stuck in the mid-position, part of the discharge gas from the compressor is directed back to the suction side, resulting in excessively high suction pressure. An increase in the suction line temperature through the reversing valve can also be measured. Check operation of the valve by starting the system and switching the operation from COOLING to HEATING cycle.

If the valve fails to change its position, test the voltage (24V) at the valve coil terminals, while the system is on the COOLING cycle.

If no voltage is registered at the coil terminals, check the operation of the thermostat and the continuity of the connecting wiring from the "O" terminal of the thermostat to the unit.

If voltage is registered at the coil, tap the valve body lightly while switching the system from HEATING to COOLING, etc. If this fails to cause the valve to switch positions, remove the coil connector cap and test the continuity of the reversing valve solenoid coil. If the coil does not test continuous replace it.

If the coil test continuous and 24 volts is present at the coil terminals, the valve is inoperative - replace it.

S-24 TESTING DEFROST CONTROL

To check the defrost control for proper sequencing, proceed as follows: With power ON; unit not running. Make sure unit running heating mode, O is deenergized and Low pressure Switch is closed.

- 1. Jumper defrost thermostat by placing a jumper wire across the terminals "DFT" and "R"/"R-DFT" at defrost control board.
- 2. Connect jumper across test pins on defrost control board.
- 3. Set thermostat to call for heating. System should go into defrost within 21 seconds.
- 4. Immediately remove jumper from test pins.
- 5. Using VOM check for voltage across terminals "C & O". Meter should read 24 volts.
- 6. Using VOM check for continuity voltage across fan terminals DF1 and DF2 on the board. You should read 0 Ohms indicating the relay is open in the defrost mode.

NOTE: You will need to remove fan wires if ou are checking for continuity between DF1 and DF2 if not you will short your meter.

- 7. Using VOM check for voltage across "W & C" terminals on the board. You should read 24 volts.
- 8. If not as above, replace control board.
- 9. Set thermostat to off position and disconnect power before removing any jumpers or wires.

NOTE: Remove jumper across defrost thermostat before returning system to service.

S-25 TESTING DEFROST THERMOSTAT

- Install a thermocouple type temperature test lead on the tube adjacent to the defrost control. Insulate the lead point of contact.
- Check the temperature at which the control closes its contacts by lowering the temperature of the control. Part # 0130M00009P which is used on 2 and 2.5 ton units should close at 34°F ± 5°F. Part # 0130M00001P which is used on 3 thru 5 ton units should close at 31°F ± 3°F.
- Check the temperature at which the control opens its contacts by raising the temperature of the control. Part # 0130M00009P which is used on 2 and 2.5 ton units

- should open at $60^{\circ}F \pm 5^{\circ}F$. Part # 0130M00001P which is used on 3 thru 5 ton units should open at $75^{\circ}F \pm 6^{\circ}F$.
- 4. If not as above, replace control.

S-40 AR*F & MBR ELECTRONIC BLOWERS TIME DELAY RELAY

The MBR contains an Electronic Blower Time Delay Relay board, PCBFM103. This board provides on/off time delays for the blower motor in cooling and heat pump heating demands when "G" is energized.

During a cooling or heat pump heating demand, 24Vac is supplied to terminal "G" of the EBTDR to turn on the blower motor. The EBTDR initiates a 7 second delay on and then energizes it's onboard relay. The relay on the EBTDR board closes it's normally open contacts and supplies power to the blower motor. When the "G" input is removed, the EBTDR initiates a 65 second delay off. When the 65 seconds delay expires the onboard relay is de-energized and it's contacts open and remove power from the blower motor.

During an electric heat only demand, "W1" is energized but "G" is not. The blower motor is connected to the normally closed contacts of the relay on the EBTDR board. The other side of this set of contacts is connected to the heat sequencer on the heater assembly that provides power to the 1st stage of heat. When "W1" is energized, and the blower motor is powered through the normally closed contacts on the relay of the EBTDR. There maybe delay on activation or deactivating heater elements.

The EBTDR also contains a speedup terminal to reduce the delays during troubleshooting of the unit. When this terminal is shorted to the common terminal, "C", on the EBTDR board, the delay ON time is reduced to 3 seconds and the delay OFF time is reduced to 5 second.

Two additional terminals, M1 and M2, are on the EBTDR board. These terminals are used to connect the unused leads from the blower motor and have no affect on the board's operation.

SEQUENCE OF OPERATION

This document covers the basic sequence of operation for a typical application with a mercury bulb thermostat. When a digital/electronic thermostat is used, the on/off staging of the auxiliary heat will vary. Refer to the installation instructions and wiring diagrams provided with the MBR and AR*F for specific wiring connections and system configuration.

AR*F & MBR

WITH SINGLE STAGE CONDENSERS

1.0 Cooling Operation

- **1.1** On a demand for cooling, the room thermostat energizes "G" and "Y" and 24Vac is supplied to "Y" at the condensing unit and the "G" terminal on the EBTDR board.
- 1.2 The compressor and condenser fan are turned on and

- after a 7 second on delay, the relay on the EBTDR board is energized and the blower motor starts.
- **1.3** When the cooling demand "Y" is satisfied, the room thermostat removes the 24Vac from "G" and "Y".
- 1.4 The compressor and condenser fan are turned off and after a 65 second delay off, the relay on the EBTDR board is deenergized and the blower is turned off.

2.0 Heating Operation

- 2.1 On a demand for heat, the room thermostat energizes "W1" and 24Vac is supplied to turn on the 1st stage of heat. If W2 is energized, then the 2nd stage will be turned on. This may be turning on contractor(s) or sequencer(s).
- 2.2 In order to make sure the blower is running when heat is on, the normally closed contacts on the EBTDR will power motor the blower motor if no G signal is received.

AR*F & MBR

WITH SINGLE STAGE HEAT PUMPS

3.0 Cooling Operation

On heat pump units, when the room thermostat set to the cooling mode, 24Vac is supplied to "O" which energizes the reversing valve. As long as the thermostat is set for cooling, the reversing valve will be in the energized position for cooling.

- **3.1** On a demand for cooling, the room thermostat energizes "G" and "Y" and 24Vac is supplied to "Y" at the heat pump and the "G" terminal on the EBTDR board.
- 3.2 The heat pump turned on in the cooling mode and after a 7 second on delay, the relay on the EBTDR board is energized and the blower motor starts.
- **3.3** When the cooling demand is satisfied, the room thermostat removes the 24Vac from "G" and "Y".
- **3.4** The heat pump is turned off and after a 65 second delay off, the relay on the EBTDR board is de-energized and the blower motor is turned off.

4.0 Heating Operation

On heat pump units, when the room thermostat set to the heating mode, the reversing valve is not energized. As long as the thermostat is set for heating, the reversing valve will be in the de-energized position for heating except during a defrost cycle. Some installations may use one or more outdoor thermostats to restrict the amount of electric heat that is available above a preset ambient temperature. Use of optional controls such as these can change the operation of the electric heaters during the heating mode. This sequence of operation does not cover those applications.

- **4.1** On a demand for first stage of heat with heat pump units, the room thermostat energizes "G" and "Y" and 24Vac is supplied to "Y" at the heat pump unit and the "G" terminal on the EBTDR board. The heat pump is turned on in the heating mode and the blower motor starts after a 7 second on delay.
- **4.2** If the first stage of heat is not satisfied by the heat pump,

- then some thermostats may call for 2nd or 3rd stage of heat (1st and 2nd stage of electric heat).
- **4.3** On demand for heat, the room thermostat energizes "W1" and 24 Vac is supplied to turn on the 1st stage of heat. If W2 is energized, then the 2nd stage will be turned on. this may be turning on contractor(s) or sequencer(s).
- **4.4** In order to make sure the blower is running when heat is on, the normally closed contacts on the EBTDR will power the blower motor if no G signal is received.
- **4.5** There may be delay on activation or deactivating heater elements.

5.0 Defrost Operation

On heat pump units, when the room thermostat is set to the heating mode, the reversing valve is not energized. As long as the thermostat is set for heating, the reversing valve will be in the de-energized position for heating except during a defrost cycle.

- **5.1** The heat pump will be on and operating in the heating mode as described the Heating Operation in section 4.
- 5.2 The defrost control in the heat pump unit checks to see if a defrost is needed every 30, 60 or 90 accumulated of compressor runtime minutes of heat pump operation depending on the selectable setting by monitoring the state of the defrost thermostat attached to the outdoor coil.
- 5.3 If the temperature of the outdoor coil is low enough to cause the defrost thermostat to be closed when the defrost board checks it, and if accumulated compressor runtime of 30, 60 or 90 minutes expires the board will initiate a defrost cycle.
- 5.4 When a defrost cycle is initiated, the contacts of the HVDR relay on the defrost board open and turns off the outdoor fan. The contacts of the LVDR relay on the defrost board closes and supplies 24Vac to "O" and "W2". The reversing valve is energized and 1st stage of electronic heat is energized. The unit will continue to run in this mode until the defrost cycle is completed, or maximum defrost time of 12 minutes expires.
 - a. For models with defrost control PCBDM133, a 30 second compressor delay at defrost initiation/termination is optional. As shipped from the factory, the control is set for the delay ("DLY"), which will turn the compressor off for 30 seconds at entering and exiting defrost operation while the reversing valve shifts to/ from the cooling mode position. To bypass the delay, which typically reduces sound levels during defrost mode, change the pin settings from "DLY" to "NORM".
- 5.5 When the temperature of the outdoor coil rises high enough to causes the defrost thermostat to open, the defrost cycle will be terminated. If at the end of the programmed 10 minute override time the defrost thermostat is still closed, the defrost board will automatically terminate the defrost cycle.

S-41 AEP* & MBE WITH SINGLE STAGE CON-DENSERS

AEP* & MBE ELECTRONIC BLOWER TIME DELAY RELAY SEQUENCE OF OPERATION

This document covers the basic sequence of operation for a typical application with a mercury bulb thermostat. When a digital/electronic thermostat is used, the on/off staging of the auxiliary heat will vary. Refer to the installation instructions and wiring diagrams provided with the MBE for specific wiring connections, dip switch settings and system configuration.

AEP* & MBE WITH SINGLE STAGE CONDENSERS

When used with a single stage condenser, dip switch #4 must be set to the on position on the VSTB inside the MBE. The "Y" output from the indoor thermostat must be connected to the yellow wire labeled "Y/Y2" inside the wire bundle marked "Thermostat" and the yellow wire labeled "Y/Y2" inside the wire bundle marked "Outdoor Unit" must be connected to "Y" at the condenser. The orange jumper wire from terminal "Y1" to terminal "O" on the VSTB inside the MBE must remain connected.

1.0 Cooling Operation

- 1.1 On a demand for cooling, the room thermostat energizes "G" and "Y" and 24Vac is supplied to "G" and "Y/Y2" of the MBE unit. The VSTB inside the MBE will turn on the blower motor and the motor will ramp up to the speed programmed in the motor based on the settings for dip switch 5 and 6. The VSTB will supply 24Vac to "Y" at the condenser and the compressor and condenser are turned on.
- 1.2 When the cooling demand is satisfied, the room thermostat removes the 24Vac from "G" and "Y". The MBEand AEP* remove the 24Vac from "Y' at the condenser and the compressor and condenser fan are turned off. The blower motor will ramp down to a complete stop based on the time and rate programmed in the motor.

2.0 Heating Operation

- 2.1 On a demand for heat, the room thermostat energizes "W1" and 24Vac is supplied to terminal "E/W1" of the VSTB inside the MBEand AEP* units. The VSTB will turn on the blower motor and the motor will ramp up to the speed programmed in the motor based on the settings for dip switch 1 and 2. The VSTB will supply 24Vac to heat sequencer HR1 on the electric heater assembly.
- 2.2 HR1 contacts M1 and M2 will close within 10 to 20 seconds and turn on heater element #1. At the same time, if the heater assembly contains a second heater element, HR1 will contain a second set of contacts, M3 and M4, which will close and turn on heater element #2.
- Note: If more than two heater elements are on the heater assembly, it will contain a second heat sequencer, HR2, which will control the 3rd and 4th heater elements if available. For the 3rd and 4th heater elements to operate on a second stage heat demand, the PJ4 jumper on the VSTB inside the MBE and AEP* must be cut. With the PJ4 jumper cut, the VSTB will run the

- blower motor on low speed on a "W1" only demand. If the first stage heat demand, "W1" cannot be satisfied by the heat pump, the temperature indoors will continue to drop. The room thermostat will then energize "W2" and 24Vac will be supplied to HR2 on the heater assembly and the blower motor will change to high speed. When the "W2" demand is satisfied, the room thermostat will remove the 24Vac from "W2" and the VSTB will remove the 24Vac from HR2. The contacts on HR2 will open between 30 to 70 seconds and heater elements #3 and #4 will be turned off and the blower motor will change to low speed. On most digital/electronic thermostats, "W2" will remain energized until the first stage demand "W1" is satisfied and then the "W1" and "W2" demands will be removed.
- 2.3 When the "W1" heat demand is satisfied, the room thermostat will remove the 24Vac from "E/W1" and the VSTB removes the 24Vac from HR1. The contacts on HR1 will open between 30 to 70 seconds and turn off the heater element(s) and the blower motor ramps down to a complete stop.

S-41A AEP* & MBE WITH SINGLE STAGE HEAT PUMPS

When used with a single stage heat pump, dip switch #4 must be set to the ON position on the VSTB inside the MBE. The "Y" output from the indoor thermostat must be connected to the yellow wire labeled "Y/Y2" inside the wire bundle marked "Thermostat" and the yellow wire labeled "Y/Y2" inside the wire bundle marked "Outdoor Unit" must be connected to "Y" at the heat pump. The orange jumper wire from terminal "Y1" to terminal "O" on the VSTB inside the MBE must be removed.

3.0 Cooling Operation

On heat pump units, when the room thermostat is set to the cooling mode, 24Vac is supplied to terminal "O" of the VSTB inside the MBE unit. The VSTB will supply 24Vac to "O" at the heat pump to energize the reversing valve. As long as the thermostat is set for cooling, the reversing valve will be in the energized position for cooling.

- 3.1 On a demand for cooling, the room thermostat energizes "G" and "Y" and 24Vac is supplied to terminals "G" and "Y/Y2" of the MBE unit. The VSTB will turn on the blower motor and the motor will ramp up to the speed programmed in the motor based on the settings of dip switch 5 and 6. The VSTB will supply 24Vac to "Y" at the heat pump.
- **3.2** The heat pump is turned on in the cooling mode.
- 3.3 When the cooling demand is satisfied, the room thermostat removes the 24Vac from "G" and "Y/Y2" of the MBE and the VSTB removes the 24Vac from "Y" at the heat pump. The heat pump is turned off and the blower motor will ramp down to a complete stop based on the time and rate programmed in the motor.

4.0 Heating Operation

On heat pump units, when the room thermostat is set to the heating mode, the reversing valve is not energized. As long as the thermostat is set for heating, the reversing valve will be in the de-energized position for heating except during a defrost cycle. Some installations may use one or more outdoor thermostats to restrict the amount of electric heat that is available above a preset ambient temperature. Use of optional controls such as these can change the operation of the electric heaters during the heating mode. This sequence of operation does not cover those applications.

- **4.1** On a demand for first stage heat with heat pump units, the room thermostat energizes "Y" and "G" and 24Vac is supplied to "G" and "Y/Y2" of the MBE. The VSTB will turn on the blower motor and the motor will ramp up to the speed programmed in the motor based on the settings of dip switch 1 and 2. The VSTB will supply 24Vac to "Y" at the heat pump and the heat pump is turned on in the heating mode.
- 4.2 If the first stage heat demand cannot be satisfied by the heat pump, the temperature indoors will continue to drop. The room thermostat will then energize terminal "W2" for second stage heat and 24Vac will be supplied to "E/W1" of the MBE. The VSTB will supply 24Vac to heat sequencer, HR1, on the electric heater assembly.
- 4.3 HR1 contacts M1 and M2 will close within 10 to 20 seconds and turn on heater element #1. At the same time, if the heater assembly contains a second heater element, HR1 will contain a second set of contacts, M3 and M4, which will close to turn on heater element #2.

Note: If more than two heater elements are on the heater assembly, it will contain a second heat sequencer, HR2, which will control the 3rd and 4th heater elements if available. For the 3rd and 4th heater elements to operate on a third stage heat demand, the PJ4 jumper on the VSTB inside the MBE and AEP* must be cut. If the second stage heat demand, "W2", cannot be satisfied by the heat pump, the temperature indoors will continue to drop. The room thermostat will then energize "W3" and 24Vac will be supplied to "W/ W2" of the MBE. The VSTB will supply 24Vac to HR2 on the electric heater assembly. When the "W3" demand is satisfied, the room thermostat will remove the 24Vac from "W/W2" of the MBE and AEP*. The contacts on HR2 will open between 30 to 70 seconds and heater elements #3 and #4 will be turned off. On most digital/electronic thermostats, "W3" will remain energized until the first stage demand "Y" is satisfied and then the "G", "Y", "W2" and "W3" demands will be removed.

4.4 As the temperature indoors increase, it will reach a point where the second stage heat demand, "W2", is satisfied. When this happens, the room thermostat will remove the 24Vac from "E/W1" of the MBE. The contacts on HR1 will open between 30 to 70 seconds and turn off both heater element(s). The heat pump remains on along with the blower motor because the "Y" demand for first stage heat will still be present.

4.5 When the first stage heat demand "Y" is satisfied, the room thermostat will remove the 24Vac from "G" and "Y/Y2" of the MBE and AEP*. The VSTB removes the 24Vac from "Y" at the heat pump and the heat pump is turned off. The blower motor will ramp down to a complete stop based on the time and rate programmed in the motor control.

5.0 Defrost Operation

On heat pump units, when the room thermostat is set to the heating mode, the reversing valve is not energized. As long as the thermostat is set for heating, the reversing valve will be in the de-energized position for heating except during a defrost cycle.

- **5.1** The heat pump will be on and operating in the heating mode as described the Heating Operation in section 4.
- 5.2 The defrost control in the heat pump unit checks to see if a defrost is needed every 30, 60 or 90 minutes of heat pump operation depending on the selectable setting by monitoring the state of the defrost thermostat attached to the outdoor coil.
- 5.3 If the temperature of the outdoor coil is low enough to cause the defrost thermostat to be closed when the defrost board checks it, the board will initiate a defrost cycle.
- 5.4 When a defrost cycle is initiated, the contacts of the HVDR relay on the defrost board open and turns off the outdoor fan. The contacts of the LVDR relay on the defrost board closes and supplies 24Vac to "O" and "W2". The reversing valve is energized and the contacts on HR1 close and turns on the electric heater(s). The unit will continue to run in this mode until the defrost cycle is completed.
 - a. For models with defrost control PCBDM133, a 30 second compressor delay at defrost initiation/termination is optional. As shipped from the factory, the control is set for the delay ("DLY"), which will turn the compressor off for 30 seconds while the reversing valve shifts to/from the cooling mode position. To bypass the delay, which typically reduces sound levels during defrost mode, change the pin settings from "DLY" to "NORM".
- **5.5** When the temperature of the outdoor coil rises high enough to causes the defrost thermostat to open, the defrost cycle will be terminated. If at the end of the programmed 10 minute override time the defrost thermostat is still closed, the defrost board will automatically terminate the defrost cycle.
- **5.6** When the defrost cycle is terminated, the contacts of the HVDR relay on the defrost board will close to start the outdoor fan and the contacts of the LVDR relay will open and turn off the reversing valve and electric heater(s). The unit will now be back in a normal heating mode with a heat pump demand for heating as described in the Heating Operation in section 4. See section 5.4a.

S-60 ELECTRIC HEATER (OPTIONAL ITEM)

Optional electric heaters may be added, in the quantities shown in the specifications section, to provide electric resistance heating. Under no condition shall more heaters than the quantity shown be installed.

The low voltage circuit in the air handler is factory wired and terminates at the location provided for the electric heater(s). A minimum of field wiring is required to complete the installation.

Other components such as a Heating/Cooling Thermostat and Outdoor Thermostats are available to complete the installation.

The system CFM can be determined by measuring the static pressure external to the unit. The installation manual supplied with the blower coil, or the blower performance table in the service manual, shows the CFM for the static measured.

Alternately, the system CFM can be determined by operating the electric heaters and indoor blower WITHOUT having the compressor in operation. Measure the temperature rise as close to the blower inlet and outlet as possible.

If other than a 240V power supply is used, refer to the **BTUH CAPACITY CORRECTION FACTOR** chart below.

BTUH CAPACITY CORRECTION FACTOR					
SUPPLY VOLTAGE	250	230	220	208	
MULTIPLICATION FACTOR	1.08	.92	.84	.75	

EXAMPLE: Five (5) heaters provide 24.0 KW at the rated 240V. Our actual measured voltage is 220V, and our measured temperature rise is 42°F. Find the actual CFM:

Answer: 24.0KW, 42°F Rise, 240 V = 1800 CFM from the **TEMPERATURE RISE** CHART, Table 5.

Heating output at 220 V = 24.0KW x 3.413 x .84 = 68.8 MBH.

Actual CFM = $1800 \times .84 \text{ Corr. Factor} = 1400 \text{ CFM}.$

NOTE: The temperature rise table is for sea level installations. The temperature rise at a particular KW and CFM will be greater at high altitudes, while the external static pressure at a particular CFM will be less.

	TEMPERATURE RISE (F°) @ 240V								
CFM	3	4.8	7.2	9.6	14.4	19.2	24	28.8	
CI W	KW	KW	KW	KW	KW	KW	KW	KW	
600	16	25	38	51					
700	14	22	33	43					
800	12	19	29	38	57				
900	11	17	26	34	51				
1000	10	15	23	30	46				
1100	9	14	21	27	41	55			
1200	8	13	19	25	38	50			
1300	7	12	18	23	35	46			
1400	7	11	16	22	32	43	54	65	
1500	6	10	15	20	30	40	50	60	
1600	6	9	14	19	28	38	47	57	
1700	6	9	14	18	27	36	44	53	
1800	5	8	13	17	25	34	42	50	
1900	5	8	12	16	24	32	40	48	
2000	5	8	12	15	23	30	38	45	
2100	5	7	11	14	22	29	36	43	
2200	4	7	11	14	21	27	34	41	
2300	4	7	10	13	20	26	33	39	

Table 5

ELECTRIC HEATER CAPACITY BTUH								
HTR KW	3.0 KW	4.7 KW	6.0 KW	7.0 KW	9.5 KW	14.2 KW	19.5 KW	21.0 KW
BTUH	10200	16200	20400	23800	32400	48600	66500	71600

Table 6

FORMULAS:

Heating Output = KW x 3413 x Corr. Factor

Actual CFM = CFM (from table) x Corr. Factor

BTUH = KW x 3413

BTUH = CFM x 1.08 x Temperature Rise (T)

 $CFM = KW \times 3413$ 1.08 x T

 $T = \underline{BTUH}$ $CFM \times 1.08$

S-61A CHECKING HEATER LIMIT CONTROL(S)

Each individual heater element is protected with a limit control device connected in series with each element to prevent overheating of components in case of low airflow. This limit control will open its circuit at approximately 150°F.



WARNING

HIGH VOLTAGE

Disconnect ALL power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury or death.



- 1. Remove the wiring from the control terminals.
- 2. Using an ohmmeter, test for continuity across the normally closed contacts. No reading indicates the control is open replace if necessary.

IF FOUND OPEN - REPLACE - DO NOT WIRE AROUND.

S-61B CHECKING HEATER FUSE LINK (OP-TIONAL ELECTRIC HEATERS)

Each individual heater element is protected with a one time fuse link which is connected in series with the element. The fuse link will open at approximately 333°.



WARNING -

Disconnect ALL power before servicing.

- Remove heater element assembly so as to expose fuse link.
- 2. Using an ohmmeter, test across the fuse link for continuity no reading indicates the link is open. Replace as necessary.

NOTE: The link is designed to open at approximately 333°F. DO NOT WIRE AROUND - determine reason for failure.

S-62 CHECKING HEATER ELEMENTS



WARNING -

Disconnect ALL power before servicing.

- 1. Disassemble and remove the heating element.
- 2. Visually inspect the heater assembly for any breaks in the wire or broken insulators.
- 3. Using an ohmmeter, test the element for continuity no reading indicates the element is open. Replace as necessary.

S-100 REFRIGERATION REPAIR PRACTICE



DANGER

Always remove the refrigerant charge in a proper manner before applying heat to the system.

When repairing the refrigeration system:



WARNING -

Disconnect ALL power before servicing.

- 1. Never open a system that is under vacuum. Air and moisture will be drawn in.
- 2. Plug or cap all openings.
- 3. Remove all burrs and clean the brazing surfaces of the tubing with sand cloth or paper. Brazing materials do not flow well on oxidized or oily surfaces.
- 4. Clean the inside of all new tubing to remove oils and pipe chips.
- 5. When brazing, sweep the tubing with dry nitrogen to prevent the formation of oxides on the inside surfaces.
- 6. Complete any repair by replacing the liquid line drier in the system, evacuate and charge.

BRAZING MATERIALS

IMPORTANT NOTE: Torch heat required to braze tubes of various sizes is proportional to the size of the tube. Tubes of smaller size require less heat to bring the tube to brazing temperature before adding brazing alloy. Applying too much heat to any tube can melt the tube. Service personnel must use the appropriate heat level for the size of the tube being brazed.

NOTE: The use of a heat shield when brazing is recommended to avoid burning the serial plate or the finish on the unit. Heat trap or wet rags should be used to protect heat sensitive components such as service valves and TXV valves.

Copper to Copper Joints - Sil-Fos used without flux (alloy of 15% silver, 80% copper, and 5% phosphorous). Recommended heat 1400°F.

Copper to Steel Joints - Silver Solder used without a flux (alloy of 30% silver, 38% copper, 32% zinc). Recommended heat - 1200°F.

S-101 LEAK TESTING (NITROGEN OR NITRO-GEN-TRACED)



WARNING

To avoid the risk of fire or explosion, never use oxygen, high pressure air or flammable gases for leak testing of a refrigeration system.



WARNING

To avoid possible explosion, the line from the nitrogen cylinder must include a pressure regulator and a pressure relief valve. The pressure relief valve must be set to open at no more than 150 psig.

Pressure test the system using dry nitrogen and soapy water to locate leaks. If you wish to use a leak detector, charge the system to 10 psi using the appropriate refrigerant then use nitrogen to finish charging the system to working pressure, then apply the detector to suspect areas. If leaks are found, repair them. After repair, repeat the pressure test. If no leaks exist, proceed to system evacuation.

S-102 EVACUATION



WARNING

REFRIGERANT UNDER PRESSURE! Failure to follow proper procedures may cause property damage, personal injury or death.

This is the most important part of the entire service procedure. The life and efficiency of the equipment is dependent upon the thoroughness exercised by the serviceman when evacuating air (non-condensables) and moisture from the system.

Air in a system causes high condensing temperature and pressure, resulting in increased power input and reduced performance.

Moisture chemically reacts with the refrigerant oil to form corrosive acids. These acids attack motor windings and parts, causing breakdown.

The equipment required to thoroughly evacuate the system is a high vacuum pump, capable of producing a vacuum equivalent to 25 microns absolute and a thermocouple vacuum gauge to give a true reading of the vacuum in the system


NOTE: Never use the system compressor as a vacuum pump or run when under a high vacuum. Motor damage could occur.



WARNING

Do not front seat the service valve(s) with the compressor open, with the suction line of the comprssor closed or severely restricted.

- Connect the vacuum pump, vacuum tight manifold set with high vacuum hoses, thermocouple vacuum gauge and charging cylinder as shown.
- 2. Start the vacuum pump and open the shut off valve to the high vacuum gauge manifold only. After the compound gauge (low side) has dropped to approximately 29 inches of vacuum, open the valve to the vacuum thermocouple gauge. See that the vacuum pump will blank-off to a maximum of 25 microns. A high vacuum pump can only produce a good vacuum if its oil is non-contaminated.



EVACUATION

- If the vacuum pump is working properly, close the valve to the vacuum thermocouple gauge and open the high and low side valves to the high vacuum manifold set. With the valve on the charging cylinder closed, open the manifold valve to the cylinder.
- 4. Evacuate the system to at least 29 inches gauge before opening valve to thermocouple vacuum gauge.
- 5. Continue to evacuate to a maximum of 250 microns. Close valve to vacuum pump and watch rate of rise. If vacuum does not rise above 1500 microns in three to five minutes, system can be considered properly evacuated.
- 6. If thermocouple vacuum gauge continues to rise and levels off at about 5000 microns, moisture and non-condensables are still present. If gauge continues to rise a leak is present. Repair and re-evacuate.
- 7. Close valve to thermocouple vacuum gauge and vacuum pump. Shut off pump and prepare to charge.

S-103 CHARGING



WARNING

REFRIGERANT UNDER PRESSURE!

- * Do not overcharge system with refrigerant.
- * Do not operate unit in a vacuum or at negative pressure.

Failure to follow proper procedures may cause property damage, personal injury or death.



CAUTION

Use refrigerant certified to AHRI standards. Used refrigerant may cause compressor damage and is not covered under the warranty. Most portable machines cannot clean used refrigerant to meet AHRI standards.



CAUTION

Damage to the unit caused by operating the compressor with the suction valve closed is not covered under the warranty and may cause serious compressor damage.

Charge the system with the exact amount of refrigerant.

Refer to the specification section or check the unit nameplates for the correct refrigerant charge.

An inaccurately charged system will cause future problems.

- When using an ambient compensated calibrated charging cylinder, allow liquid refrigerant only to enter the high side.
- 2. After the system will take all it will take, close the valve on the high side of the charging manifold.
- 3. Start the system and charge the balance of the refrigerant through the low side. DO NOT charge in a liquid form.
- 4. With the system still running, close the valve on the charging cylinder. At this time, you may still have some liquid refrigerant in the charging cylinder hose and will definitely have liquid in the liquid hose. Reseat the liquid line core. Slowly open the high side manifold valve and transfer the liquid refrigerant from the liquid line hose and charging cylinder hose into the suction service valve port. CAREFUL: Watch so that liquid refrigerant does not enter the compressor.
- 5. With the system still running, reseat the suction valve core, remove hose and reinstall both valve core caps.
- 6. Check system for leaks.

NOTE: This charging procedure can only be done in the cooling mode of operation. (Early production "a" models only.) All models with compressor process tube access valve can be processed in heating cycle if this valve is used.

When charging a remote condensing unit with a non-matching evaporator coil, or a system where the charge quantity is unknown, alternate charging methods must be used. These systems must be charged according to subcooling or superheat.

SYSTEM SUPERHEAT						
Ambient Condenser Inlet Temp. (°F Drybulb)	Return Air Temperature (°F Drybulb)					
(1 Digitally	65	70	75	80	85	
115					3	
100				5	5	
95			5	5	5	
90			7	12	18	
85		5	10	17	20	
80		5	12	21	26	
75	5	10	17	25	29	
70	5	14	20	28	32	
65	13	19	26	32	35	
60	17	25	30	33	37	

Table 7

Coils having flow control restrictors should be charged to match the System Superheat chart above. Coils with thermostatic expansion valves (TXV's) should be charged by subcooling. See "Checking Subcooling and Superheat" sections in this manual.

Due to their design, Scroll compressors are inherently more tolerant of liquid refrigerant.

NOTE: Even though the compressor section of a Scroll compressor is more tolerant of liquid refrigerant, continued floodback or flooded start conditions may wash oil from the bearing surfaces causing premature bearing failure.

If a restriction is located, replace the restricted part, replace drier, evacuate and recharge.

S-104 CHECKING COMPRESSOR EFFICIENCY

The reason for compressor inefficiency is broken or damaged suction and/or discharge valves, or scroll flanks on Scroll compressors, reducing the ability of the compressor to pump refrigerant vapor.

The condition of the valves or scroll flanks is checked in the following manner.

- 1. Attach gauges to the high and low side of the system.
- 2. Start the system and run a "Cooling Performance Test.

If the test shows:

- a. Below normal high side pressure.
- b. Above normal low side pressure.
- c. Low temperature difference across coil.
- d. Low amp draw at compressor.

and the charge is correct. The compressor is faulty - replace the compressor. **NOTE:** THIS TEST CANNOT BE DONE IN THE HEATING MODE

Verification of proper rotation of Scroll Compressors is made as follows.

NOTE: The compressor may run backwards (noisy operation) for 1 or 2 seconds at shutdown. This is normal and does not harm the compressor.

- 1. Install gauges and verify that the suction pressure drops while the discharge pressure increases.
- Listen for normal compressor sound levels. Reverse rotation results in elevated or unusual sound levels.
- 3. Reverse rotation will result in substantially reduced amp draw from tabulated values.


To correct improper rotation, switch any two power supply leads at the outdoor unit contactor.


The 3 phase Scroll Compressors are direction of rotation sensitive. They will rotate in either direction depending on the phasing of the power. There is no negative impact on durability caused by operating 3 phase compressors in reversed rotation. The compressors internal protector will trip, de-energizing the compressor. Continued operation of 3 phase scroll compressors with the rotation reversed will contribute to compressor failure. All 3 phase scroll compressors should be checked for correct phase rotation.

S-105B THERMOSTATIC EXPANSION VALVE

The expansion valve is designed to control the rate of liquid refrigerant flow into an evaporator coil in exact proportion to the rate of evaporation of the refrigerant in the coil. The amount of refrigerant entering the coil is regulated since the valve responds to temperature of the refrigerant gas leaving the coil (feeler bulb contact) and the pressure of the refrigerant in the coil. This regulation of the flow prevents the return of liquid refrigerant to the compressor.

The illustration below shows typical heat pump TXV/check valve operation in the heating and cooling modes.





THERMOSTATIC EXPANSION VALVES (TXV VALVES)

Goodman® brand TXV valves contain an internal check valve thus eliminating the need for an external check valve and bypass loop. The three forces which govern the operation of the valve are: (1) the pressure created in the power assembly by the feeler bulb, (2) evaporator pressure, and (3) the equivalent pressure of the superheat spring in the valve. 0% bleed type expansion valves are used on indoor and outdoor coils. The 0% bleed valve will not allow the system pressures (High and Low side) to equalize during the shut down period.

The TXV internal check valve will hold a pressure differential of 100 PSID.

The bulb must be securely fastened with two straps to a clean straight section of the suction line. Application of the bulb to a horizontal run of line is preferred. If a vertical installation cannot be avoided, the bulb must be mounted so that the capillary tubing comes out at the top.

THE VALVES PROVIDED BY GOODMAN® BRAND ARE DESIGNED TO MEET THE SPECIFICATION REQUIRE-MENTS FOR OPTIMUM PRODUCT OPERATION. DO NOT USE SUBSTITUTES.

S-106 OVERFEEDING

Overfeeding by the expansion valve results in high suction pressure, cold suction line, and possible liquid slugging of the compressor.

If these symptoms are observed:

- Check for an overcharged unit by referring to the cooling performance charts in the servicing section.
- 2. Check the operation of the power element in the valve as explained in S-110 Checking Expansion Valve Operation.
- 3. Check for restricted or plugged equalizer tube.

S-107 UNDERFEEDING

Underfeeding by the expansion valve results in low system capacity and low suction pressures.

If these symptoms are observed:

- 1. Check for a restricted liquid line or drier. A restriction will be indicated by a temperature drop across the drier.
- 2. Check the operation of the power element of the valve as described in S-110 Checking Expansion Valve Operation.

S-108 SUPERHEAT

The expansion valves are factory adjusted to maintain 12 to 18 degrees superheat of the suction gas. Before checking the superheat or replacing the valve, perform all the procedures outlined under Air Flow, Refrigerant Charge, Expansion Valve - Overfeeding, Underfeeding. These are the most common causes for evaporator malfunction.

CHECKING SUPERHEAT

Refrigerant gas is considered superheated when its temperature is higher than the saturation temperature corresponding to its pressure. The degree of superheat equals the degrees of temperature increase above the saturation temperature at existing pressure. See Temperature - Pressure Chart on following pages.

- 1. Run system at least 10 minutes to allow pressure to stabilize.
- 2. Temporarily install thermometer on suction (large) line near suction line service valve with adequate contact and insulate for best possible reading.

3. Refer to the superheat table provided for proper system superheat. Add charge to lower superheat or recover charge to raise superheat.

Superheat Formula = Suct. Line Temp. - Sat. Suct. Temp.

EXAMPLE:

- a. Suction Pressure = 98.7
- b. Corresponding Temp. °F. = 50
- c. Thermometer on Suction Line = 61°F.

To obtain the degrees temperature of superheat, subtract 50.0 from 61.0°F.

The difference is 11° Superheat. The 11° Superheat would fall in the ± range of allowable superheat.

NOTE: If superheat is measured for long line set or attic application, there may be a significant difference in the superheat from evaporator out to suction valve.

SUPERHEAT AND SUBCOOLING ADJUSTMENT ON TXV APPLICATIONS

- Run system at least 10 minutes to allow pressure to stabilize.
- 2. Temporarily install thermometer on liquid (small) line near liquid line service valve with adequate contact and insulate for best possible reading.
- 3. Check subcooling and superheat. Systems with TXV application should have a subcooling and superheat of 7 ± 2°F.
 - a. If subcooling and superheat are low, **adjust** TXV to 7 9°F then check subcooling.
 - b. If subcooling is low and superheat is high, **add** charge to raise subcooling to 7 ± 2°F then check superheat.
 - c. If subcooling and superheat are high, **adjust** TXV valve to $7 \pm 9^{\circ}F$ then check subcooling.
 - d. If subcooling is high and superheat is low, **adjust** TXV valve to 7 to $9^{\circ}F$ superheat and **remove** charge to lower the subcooling to $7 \pm 2^{\circ}F$.

The TXV should **NOT** be adjusted at light load conditions 55° to 60° F, under such conditions only the subcooling can be evaluated. This is because suction pressure is dependent on the indoor coil match, indoor airflow, and wet bulb temperature. **NOTE:** Do **NOT** adjust charge based on suction pressure unless there is a gross undercharge.

4. Disconnect manifold set. Installation is complete.

Temp. °F.	Gauge Pressure (PSIG) Freon-22	Temp. °F.	Gauge Pressure (PSIG) Freon-22
-40	0.61	60	102.5
-38	1.42	62	106.3
-36	2.27	64	110.2
-34	3.15	65	114.2
-32	4.07	68	118.3
-30	5.02	70	122.5
-28	6.01	72	126.8
-26	7.03	74	131.2
-24	8.09	76	135.7
-22	9.18	78	140.5
-20	10.31	80	145.0
-18	11.48	82	149.5
-16	12.61	84	154.7
-14	13.94	86	159.8
-12	15.24	88	164.9
-10	16.59	90	170.1
-8	17.99	92	175.4
-6	19.44	94	180.9
-4	20.94	96	186.5
-2	22.49	96	192.1
0	24.09	100	197.9
2	25.73	102	203.8
4	27.44	104	209.9
6	29.21	106	216.0
8	31.04	108	222.3
10	32.93	110	228.7
12	34.88	112	235.2
14	36.89	114	241.9
16	38.96	116	248.7
18	41.09	118	255.6
20	43.28	120	262.6
22	45.53	122	269.7
24	47.85	124	276.9
26	50.24	126	284.1
28	52.70	128	291.4
30	55.23	130	298.8
32	57.83	132	306.3
34	60.51	134	314.0
36	63.27	136	321.9
38	66.11	136	329.9
40	69.02	140	338.0
42	71.99	142	346.3
44	75.04	144	355.0
46	78.18	146	364.3
48	81.40	158	374.1
50	84.70	150	384.3
52	88.10	152	392.3
54	91.5	154	401.3
56	95.1	156	411.3
58	98.8	158	421.8
		160	433.3

S-109 CHECKING SUBCOOLING

Refrigerant liquid is considered subcooled when its temperature is lower than the saturation temperature corresponding to its pressure. The degree of subcooling equals the degrees of temperature decrease below the saturation temperature at the existing pressure.

- 1. Attach an accurate thermometer or preferably a thermocouple type temperature tester to the liquid line as it leaves the condensing unit.
- Install a high side pressure gauge on the high side (liquid) service valve at the front of the unit.
- 3. Record the gauge pressure and the temperature of the line.
- 4. Review the technical information manual or specification sheet for the model being serviced to obtain the design subcooling.
- 5. Obtain the Liquid Line Pressure gauge reading and convert the liquid line pressure gauge reading to temperature by finding the gauge reading in Temperature Pressure Chart and reading to the left, find the temperature in the °F. Column.
- 6. The difference between the thermometer reading and pressure to temperature conversion is the amount of subcooling.

Add charge to raise subcooling. Recover charge to lower subcooling.

Subcooling Formula = Sat. Liquid Temp. - Liquid Line Temp.

EXAMPLE:

- a. Liquid Line Pressure = 274.5
- b. Corresponding Temp. °F. = 120°
- c. Thermometer on Liquid line = 109°F.

To obtain the amount of subcooling subtract 109°F from 120°F.

The difference is 11° subcooling. See the specification sheet or technical information manual for the design subcooling range for your unit.

S-110 CHECKING EXPANSION VALVE OPERA-TION

- Remove the remote bulb of the expansion valve from the suction line.
- Start the system and cool the bulb in a container of ice water, closing the valve. As you cool the bulb, the suction pressure should fall and the suction temperature will rise.
- Next warm the bulb in your hand. As you warm the bulb, the suction pressure should rise and the suction temperature will fall.
- 4. If a temperature or pressure change is noticed, the expansion valve is operating. If no change is noticed, the valve is restricted, the power element is faulty, or the equalizer tube is plugged.

5. Capture the charge, replace the valve and drier, evacuate and recharge.

S-111 FIXED ORIFICE RESTRICTOR DEVICES

The fixed orifice restrictor device (flowrator) used in conjunction with the indoor coil is a predetermined bore (I.D.). It is designed to control the rate of liquid refrigerant flow into an evaporator coil.

The amount of refrigerant that flows through the fixed orifice restrictor device is regulated by the pressure difference between the high and low sides of the system. In the cooling cycle when the outdoor air temperature rises, the high side condensing pressure rises. At the same time, the cooling load on the indoor coil increases, causing the low side pressure to rise, but at a slower rate.

Since the high side pressure rises faster when the temperature increases, more refrigerant flows to the evaporator, increasing the cooling capacity of the system.

When the outdoor temperature falls, the reverse takes place. The condensing pressure falls, and the cooling loads on the indoor coil decreases, causing less refrigerant flow.

If a restriction should become evident, proceed as follows:

- 1. Recover refrigerant charge.
- 2. Remove the orifice assembly clean or replace.
- 3. Replace liquid line drier, evacuate and recharge.



Capillary Tubes/Orifice Assembly

CHECKING EQUALIZATION TIME

During the "OFF" cycle, the high side pressure bleeds to the low side through the fixed orifice restriction device. Check equalization time as follows:

- Attach a gauge manifold to the suction and liquid line dill valves.
- 2. Start the system and allow the pressures to stabilize.
- 3. Stop the system and check the time it takes for the high and low pressure gauge readings to equalize.

If it takes more than seven (7) minutes to equalize, the restrictor device is inoperative. Replace, install a liquid line drier, evacuate and recharge.

S-112 CHECKING RESTRICTED LIQUID LINE

When the system is operating, the liquid line is warm to the touch. If the liquid line is restricted, a definite temperature drop will be noticed at the point of restriction. In severe cases, frost will form at the restriction and extend down the line in the direction of the flow.

Discharge and suction pressures will be low, giving the

appearance of an undercharged unit. However, the unit will have normal to high subcooling.

Locate the restriction, replace the restricted part, replace drier, evacuate and recharge.

S-113 OVERCHARGE OF REFRIGERANT

An overcharge of refrigerant is normally indicated by an excessively high head pressure.

An evaporator coil, using an expansion valve metering device, will basically modulate and control a flooded evaporator and prevent liquid return to the compressor.

An evaporator coil, using a capillary tube metering device, could allow refrigerant to return to the compressor under extreme overcharge conditions. Also with a capillary tube metering device, extreme cases of insufficient indoor air can cause icing of the indoor coil and liquid return to the compressor, but the head pressure would be lower.

There are other causes for high head pressure which may be found in the "Service Problem Analysis Guide."

If other causes check out normal, an overcharge or a system containing non-condensables would be indicated.

If this system is observed:

- 1. Start the system.
- 2. Remove and capture small quantities of gas from the suction line dill valve until the head pressure is reduced to normal.
- 3. Observe the system while running a cooling performance test. If a shortage of refrigerant is indicated, then the system contains non-condensables.

S-114 NON-CONDENSABLES

If non-condensables are suspected, shut down the system and allow the pressures to equalize. Wait at least 15 minutes. Compare the pressure to the temperature of the coldest coil since this is where most of the refrigerant will be. If the pressure indicates a higher temperature than that of the coil temperature, non-condensables are present.

Non-condensables are removed from the system by first removing the refrigerant charge, replacing and/or installing liquid line drier, evacuating and recharging.

S-115 COMPRESSOR BURNOUT

When a compressor burns out, high temperature develops causing the refrigerant, oil and motor insulation to decompose forming acids and sludge.

If a compressor is suspected of being burned-out, attach a refrigerant hose to the liquid line dill valve and properly remove and dispose of the refrigerant.



NOTICE

Violation of EPA regulations may result in fines or other penalties.

Now determine if a burn out has actually occurred. Confirm by analyzing an oil sample using a Sporlan Acid Test Kit, AK-3 or its equivalent.

Remove the compressor and obtain an oil sample from the suction stub. If the oil is not acidic, either a burnout has not occurred or the burnout is so mild that a complete clean-up is not necessary.

If acid level is unacceptable, the system must be cleaned by using the clean-up drier method.



CAUTION

Do not allow the sludge or oil to contact the skin. Severe burns may result.

NOTE: The Flushing Method using R-11 refrigerant is no longer approved by Goodman Company, L.P.

Suction Line Drier Clean-Up Method

Use AMANA® brand part number RF000127 suction line filter drier kit. This drier should be installed as close to the compressor suction fitting as possible. The filter must be accessible and be rechecked for a pressure drop after the system has operated for a time. It may be necessary to use new tubing and form as required.

NOTE: At least twelve (12) inches of the suction line immediately out of the compressor stub must be discarded due to burned residue and contaminates.

- 1. Remove compressor discharge line strainer.
- 2. Remove the liquid line drier and expansion valve.
- Purge all remaining components with dry nitrogen or carbon dioxide until clean.
- 4. Install new components **including** liquid line drier.
- 5. Braze all joints, leak test, evacuate, and recharge system.
- 6. Start up the unit and record the pressure drop across the
- 7. Continue to run the system for a minimum of twelve (12) hours and recheck the pressure drop across the drier. Pressure drop should not exceed 6 PSIG.
- 8. Continue to run the system for several days, repeatedly checking pressure drop across the suction line drier. If the pressure drop never exceeds the 6 PSIG, the drier has trapped the contaminants. Remove the suction line drier from the system.
- 9. If the pressure drop becomes greater, then it must be replaced and steps 5 through 9 repeated until it does not exceed 6 PSIG.

NOTICE: Regardless, the cause for burnout must be determined and corrected before the new compressor is started.

S-120 REFRIGERANT PIPING

The piping of a refrigeration system is very important in relation to system capacity, proper oil return to compressor, pumping rate of compressor and cooling performance of the evaporator.

This long line set application guideline applies to all AHRI listed R22 air conditioner and heat pump split system matches of nominal capacity 18,000 to 60,000 Btuh. This guideline will cover installation requirements and additional accessories needed for split system installations where the line set exceeds 50 feet in actual length.

Additional Accessories:

- Crankcase Heater- a long line set application can critically increase the charge level needed for a system. As a result, the system is very prone to refrigerant migration during its off-cycle and a crankcase heater will help minimize this risk. A crankcase heater is recommended for any long line application (50 watt minimum).
- TXV Requirement: All line set applications over 50 ft will require a TXV.
- Hard Start Assist- increased charge level in long line applications can require extra work from the compressor at start-up. A hard start assist device may be required to overcome this.
- 4. Liquid Line Solenoid A long line set application can critically increase the charge level needed for a system. As a result, the system is very prone to refrigerant migration during its off-cycle and a liquid line solenoid will help minimize this. A liquid line solenoid is recommended for any long line application on straight cooling units.

Tube Sizina:

 In long line applications, the "equivalent line length" is the sum of the straight length portions of the suction line plus losses (in equivalent length) from 45 and 90 degree bends. Select the proper suction tube size based on equivalent length of the suction line (see Tables 9 & 10) and recalculated system capacity.

Equivalent length = Length horizontal + Length vertical + Losses from bends (see Table 11)

- For any residential split system installed with a long line set, the liquid line size must never exceed 3/8".
 Limiting the liquid line size to 3/8" is critical since an increased refrigerant charge level from having a larger liquid line could possibly shorten a compressor's lifespan.
- 3. **Single Stage Condensing Unit:** The maximum length of tubing <u>must not</u> exceed 150 feet.
 - 50 feet is the maximum recommended vertical difference between the condenser and evaporator when the evaporator is above the condenser. Equivalent length is not to exceed 150 feet.
 - The vertical difference between the condenser and evaporator when the evaporator is below the condenser can approach 150 feet, as long as the equivalent length

does not exceed 150 feet.

- The distance between the condenser and evaporator in a completely horizontal installation in which the indoor and outdoor unit do not differ more than 10 feet in vertical distance from each other can approach 150 feet, as long as the equivalent length does not exceed 150 feet.
- 4. **Two-Stage Condensing Unit:** The maximum length of tubing must not exceed 75 feet here indoor coil is located above the outdoor unit.

NOTE: When the outdoor unit is located above the indoor coil, the maximum vertical rise <u>must not</u> exceed 25 feet. If the maximum vertical rise exceeds 25 feet, premature compressor failure will occur due to inadequate oil return.

 Vibration and Noise: In long line applications, refrigerant tubing is highly prone to transmit noise and vibration to the structure it is fastened to. Use adequate vibrationisolating hardware when mounting line set to adjacent structure.

Most refrigerant tubing kits are supplied with 3/8"-thick insulation on the vapor line. For long line installations over 50 feet, especially if the line set passes through a high ambient temperature, ½"-thick suction line insulation is recommended to reduce loss of capacity. The liquid line should be insulated if passing through an area of 120°F or greater. Do not attach the liquid line to any non-insulated portion of the suction line.

Table 9 lists multiplier values to recalculate system-cooling capacity as a function of a system's equivalent line length (as calculated from the suction line) and the selected suction tube size. Table 10 lists the equivalent length gained from adding bends to the suction line. **Properly size the suction line to minimize capacity loss.**

	REFRIGERANT LINE LENGTH (Ft)							
Cond	0-	24	25-49		50-74***			
Unit			Line Diame	ter (In. OD)				
Tons	Suct	Liq	Suct	Liq	Suct	Liq		
1 1/2	5/8	1/4	3/4	3/8	3/4	3/8		
2	5/8	1/4	3/4	3/8	3/4	3/8		
2 1/2	3/4	3/8	3/4*	3/8	7/8	3/8		
3	3/4	3/8	3/4**	3/8	7/8**	3/8		
3 1/2	3/4	3/8	7/8**	3/8	1 1/8	3/8		
4	7/8	3/8	1 1/8	3/8	1 1/8	3/8		
5	7/8	3/8	1 1/8	3/8	1 1/8	3/8		

Table 9

TABLE 10. CAPACITY MULTIPLIERS AS A FUNCTION OF SUCTION LINE SIZE & EQUIVALENT LENGTH

^{*7/8&}quot; required for full ratings

^{**1 1/8&}quot; required for full ratings

^{***}Lines greater than 74 feet in length or vertical elevation changes more than 50 feet, refer to the long line set.

Nominal	Vapor line	EQUIVALENT LINE LENGTH (FT)						
capacity Btuh	diameter (in.)	50	75	100	125	150		
18,000	3/4	.99	.97	.96	.95	.95		
24,000	3/4	1	.99	.99	.98	.97		
30,000	3/4	.98	.97	.96	.95	.94		
36,000	3/4	.93	.90	.86	.83	.79		
36,000	7/8	.98	.96	.94	.92	.90		
	3/4	.93	.90	.87	.83	.80		
42,000	7/8	.97	.96	.94	.93	.92		
	1-1/8	1	1	.99	.99	.98		
	3/4	.90	.86	.82	.78	N/R		
48,000	7/8	.96	.94	.93	.91	.89		
	1-1/8	1	1	.99	.99	.98		
60,000	7/8	.93	.91	.89	.86	.84		
55,000	1-1/8	.99	.98	.98	.97	.97		

Table 10

NOTE: For a condenser with a liquid valve tube connection less than 3/8" diameter, use 3/8" liquid line tubing for a line set greater than 25 feet.

TABLE 11. LOSSES FROM SUCTION LINE ELBOWS (EQUIVALENT LENGTH, FT.)

Type of elbow fitting	I.D. (in.)				
Type of elbow fitting	3/4	7/8	1-1/8		
90° short radius	1.7	2	2.3		
90° long radius	1.5	1.7	1.6		
45°	0.7	0.8	1		

Table 11

Installation Requirements

- In a completely horizontal installation with a long line set where the evaporator is at the same altitude as (or slightly below) the condenser, the line set should be sloped towards the evaporator. This helps reduce refrigerant migration to the condenser during a system's off-cycle.
- 2. For a system installation where the <u>evaporator is above</u> the condenser, an inverted vapor line trap should be installed on the suction line just before the inlet to the evaporator (see Fig 6). The top of the inverted loop must be slightly above the top of the evaporator coil and can be created simply by brazing two 90° long radius elbows together, if a bending tool is unavailable. Properly support and secure the inverted loop to the nearest point on the indoor unit or adjacent structure.




Fig 6. Evaporator unit with inverted vapor loop

3. An oil trap is required at the evaporator only if the condenser is above the evaporator. Preformed oil traps are available at most HVAC supply houses, or oil traps may be created by brazing tubing elbows together (see diagram below). Remember to add the equivalent length from oil traps to the equivalent length calculation of the suction line. For example, if you construct an oil trap using two 45° elbows, one short and one long 90° elbow in a 3/4" diameter suction line, the additional equivalent length would be 0.7+0.7+1.7+1.5, which equals 4.6 feet (refer to table 9).




Fig 7. Oil Trap

4. Low voltage wiring. Verify low voltage wiring size is adequate for the length used since it will be increased in a long line application.

System Charging

R22 condensers are factory charged for 15 feet of line set. To calculate the amount of extra refrigerant (in ounces) needed for a line set over 15 feet, multiply the additional length of line set by 0.6 ounces. Note for the formula below, the linear feet of line set is the actual length of liquid line (or suction line, since both should be equal) used, not the equivalent length calculated for the suction line.

Extra refrigerant needed =
(Linear feet of line set – 15 ft) x **X** oz/ft.
Where **X** = **0.6** for 3/8" liquid tubing

Remember, for condensers with a liquid valve connection less than 3/8" diameter, 3/8" liquid tubing is required for a line set longer than 25 feet.

Follow the charging procedures in the outdoor unit I/O manual to ensure proper superheat and sub-cooling levels, especially on a system with a TXV installed in the indoor unit. Heat pumps should be checked in both heating and cooling mode for proper charge level. This guideline is meant to provide installation instructions based on most common long line set applications. Installation variables may affect system operation.

NO ADDITIONAL COMPRESSOR OIL IS NEEDED FOR LONG LINE SET APPLICATIONS ON RESIDENTIAL SPLIT SYSTEMS.

S-122 REVERSING VALVE REPLACEMENT

Remove the refrigerant charge from the system.

When brazing a reversing valve into the system, it is of extreme importance that the temperature of the valve **does not exceed 250° F.** at any time.

Wrap the reversing valve with a large rag saturated with water. "Re-wet" the rag and thoroughly cool the valve after each brazing operation of the four joints involved. The wet rag around the reversing valve will eliminate conducting of heat to the valve body when brazing the line connection.

The use of a wet rag sometimes can be a nuisance. There are commercial grades of heat absorbing paste that may be substituted.

After the valve has been installed leak test, evacuate and recharge.

S-202 DUCT STATIC PRESSURES AND/OR STATIC PRESSURE DROP ACROSS COILS

This minimum and maximum allowable duct static pressure for the indoor sections are found in the specifications section.


Tables are also provided for each coil, listing quantity of air (CFM) versus static pressure drop across the coil.

Too great an external static pressure will result in insufficient air that can cause icing of the coil. Too much air can cause poor humidity control and condensate to be pulled off the evaporator coil causing condensate leakage. Too much air can also cause motor overloading and in many cases this constitutes a poorly designed system.

S-203 AIR HANDLER EXTERNAL STATIC

To determine proper air movement, proceed as follows:

- 1. Using a draft gauge (inclined manometer), measure the static pressure of the return duct at the inlet of the unit, (Negative Pressure).
- 2. Measure the static pressure of the supply duct, (Positive Pressure).
- 3. Add the two readings together.




TOTAL EXTERNAL STATIC

NOTE: Both readings may be taken simultaneously and read directly on the manometer if so desired.

4. Consult proper table for quantity of air.


If external static pressure is being measured on a furnace to determine airflow, supply static must be taken between the "A" coil and the furnace.



TOTAL EXTERNAL STATIC

S-204 COIL STATIC PRESSURE DROP

- 1. Using a draft gauge (inclined manometer), connect the positive probe underneath the coil and the negative probe above the coil.
- 2. A direct reading can be taken of the static pressure drop across the coil.
- 3. Consult proper table for quantity of air.




STATIC PRESSURE DROP

If the total external static pressure and/or static pressure drop exceeds the maximum or minimum allowable statics, check for closed dampers, dirty filters, undersized or poorly laid out duct work.



DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

ALL FUEL SYSTEM AFE 18-60A CONTROL BOARD



ALL FUEL SYSTEM CONTROL BOARD - AFE18-60A


This wiring diagram is for reference only. Not all wiring is as shown above.

Refer to the appropriate wiring diagram for the unit being serviced.


(For use with Heat Pumps in conjunction with 80% or 90% Single-Stage or Two-Stage Furnaces)



10kw and Below, One Stage Electric Heat



15kw and Above, Two Stage Electric Heat




Typical Wiring Schematics for OT/EHR18-60 (Outdoor Thermostat & Emergency Heat Relay).

This wiring diagram is for reference only. Not all wiring is as shown above.

Refer to the appropriate wiring diagram for the unit being serviced.




15kw and Above with Two OT/EHR18-60's, Two Stage Electric Heat and Two Stage Thermostat




Typical Wiring Schematics for OT/EHR18-60 (Outdoor Thermostat & Emergency Heat Relay).

This wiring diagram is for reference only. Not all wiring is as shown above.

Refer to the appropriate wiring diagram for the unit being serviced.






Typical Wiring Schematic ADPF, ARPF, ARUF with Electric Heat.

This wiring diagram is for reference only. Not all wiring is as shown above.


Refer to the appropriate wiring diagram for the unit being serviced.






Typical Wiring Schematic MBR Blower with Electric Heat.

This wiring diagram is for reference only. Not all wiring is as shown above. Refer to the appropriate wiring diagram for the unit being serviced.






Typical Wiring Schematic AEPF with Electric Heat.

This wiring diagram is for reference only. Not all wiring is as shown above.

Refer to the appropriate wiring diagram for the unit being serviced.





Diower occion


Typical Wiring Schematic MBE Blower with Electric Heat.

This wiring diagram is for reference only.

Not all wiring is as shown above.

Refer to the appropriate wiring diagram for the unit being serviced.






Typical Wiring Schematic ASPF****16A* with Electric Heat.

This wiring diagram is for reference only. Not all wiring is as shown above. Refer to the appropriate wiring diagram for the unit being serviced.




HIGH VOLTAGE!
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS
UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO
DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.




NOTE: WHEN INSTALLING HEATER KIT, ENSURE SPEED TAP DOES NOT EXCEED M INIMUM BLOWER SPEED (MBS) SPECIFIED FOR THE AIRHANDLER/HEAT ER KIT COMBINATION ON THIS UNIT'S S&R PLATE. AFTER INSTALLING OPTIONAL HEAT KIT, MARK AN "X" IN THE PROVIDED ABOVE.


MARK ACCORDING TO NUMBER OF HEATER ELEMENT ROWS INSTALLED. NO MARK INDICATES NO HEAT KIT INSTALLED.



Typical Wiring Schematic ASPF****16B* with Electric Heat.

This wiring diagram is for reference only. Not all wiring is as shown above. Refer to the appropriate wiring diagram for the unit being serviced.







Typical Wiring Schematic ASPF****16** with Electric Heat.


This wiring diagram is for reference only. Not all wiring is as shown above. Refer to the appropriate wiring diagram for the unit being serviced.

AIRHANDLERS







ADPF, ARPF, ARUF, ATUF





ADPF, ARPF, ARUF, ATUF







AEPF*****CA



























BLOWERS


Single Stage Cooling with Single or Two-Stage Heating








COOLING ONLY - 2 STAGE HEAT (T'STAT ENABLED OT)



HEATPUMP - WITH 1 STG EMHT 1 STG AUX HEAT

HIGH VOLTAGE!
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS
UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO
DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH

WARNIN




OUTDOOR THERMOSTAT ROOM THERMOSTAT **HEATPUMP** (R) (Y) (C) (O) (w2) (E) @ (O) (C) (R) (G) (Y) HUMIDISTAT (OPTIONAL) 1 SEE NOTE 4 REMOVE NOTES: 1.) Y ENABLES HI SPD FAN COOLING **PRODUCTION** WIRE Y1 - O 2.) E ENABLES LO SPD FAN HEATING W2 ENABLES LO SPD FAN HEATING W2 AND OT2 CLOSED ENABLES HI SPD FAN HEATING ⊕ □ 3.) 0T2 PJ2 MUST BE CUT FOR THIS CONFIGURATION OT1 € 4.) CUT HUM PJ6 JUMPER IF USING HUMIDISTAT STAT OPENS ON HUMIDITY RISE 5.) DIP SWITCH #4 MUST BE IN THE "ON" POSITION \oplus GOODMAN MFG. - 2nd STAGE HEATER 1st STAGE HEATER 1st STAGE AUX HEAT ENABLED BY ROOM T'STAT 2ND STAGE AUX ENABLED BY ROOM T'STAT AND OUTDOOR T'STAT


HEATPUMP - 2 STG EMHT 2 STG AUX - 1 OUTDOOR T'STAT

Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.






HEATPUMP - 2 STG EMHT 2 STG AUX - 2 OUTDOOR T'STATS




HEATPUMP - 2 STG EMHT 2 STG AUX - 1 OUTDOOR T'STAT

Two-Stage Cooling with Conventional Two-Stage Thermostat




2 SPD COOLING ONLY - WITH 2 STAGE HEAT THERMOSTAT

Two-Stage Cooling with Conventional Two-Stage Thermostat



2 SPD COOLING ONLY - 2 STAGE HEAT (1st T'STAT 2nd OT)




2 SPD COOLING ONLY - 2 STAGE HEAT (T'STAT ENABLED OT)

HIGH VOLTAGE! DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEA


WARNIN

Heat Pump with Single or Two-Stage Heating (Options for Emergency Heat) with Conventional Thermostat




HEATPUMP - 2 STG EMHT 1 STG AUX HEAT






HEATPUMP - 2 STG EMHT 2 STAG AUX - 1 OUTDOOR T-STAT



NO AUX HEAT IN HEATPUMP MODE UNTIL OUTDOOR T'STAT CLOSES

HEATPUMP - 2 STG EMHT 2 STAG AUX - 2 OUTDOOR T-STATS







NO AUX HEAT IN HEATPUMP MODE UNTIL OUTDOOR T'STAT CLOSES

HEATPUMP - 2 STG EMHT 1 STG AUX - 1 OUTDOOR T'STAT

Two Speed Heat Pump with Single or Two-Stage Heating (Options for Emergency Heat) with Conventional Two-Stage Thermostat







HEATPUMP - 2 STG EMHT 1 STG AUX HEAT

WARNING


롣


WARNIN






HEATPUMP - 2 STG EMHT 2 STG AUX - 2 OUTDOOR T'STATS






NO AUX HEAT IN HEATPUMP MODE UNTIL T'STAT CLOSES

HEATPUMP - 2 STG EMHT 1 STG AUX - 1 OUTDOOR T'STAT




Two-Stage Cooling with Conventional Two-Stage Thermostat (Encoded with add on 1N006 Diodes) (TSTWK01 Kit Required)





HIGH VOLTAGE!
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS
UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO
DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

WARNING




Encoded Two-Stage Cooling with GMC Thermostat Part # CHET18-60 (TSTWK01 Kit Required)







REMOTE/SPLITS




WIRING DIAGRAMS


ASH130[18-60]1A*









WIRING DIAGRAMS







WIRING DIAGRAMS

