



MULTI *21*

SLIM CONCEALED DUCT OWNER'S MANUAL

Models:

DUCT09HP230V1AD

DUCT12HP230V1AD

DUCT18HP230V1AD

DUCT24HP230V1AD



Thank you for choosing a Gree Slim Concealed Duct Air Conditioning & Heating System!

You can feel confident in your selection because the same pride in craftsmanship and engineering knowledge that goes into millions of other Gree installed products worldwide has gone into your unit.

Please read this owner's manual carefully before operation and retain it for future reference.

Table of Contents

| | |
|-----------------------------------|--------------|
| <i>Introduction</i> | <i>2</i> |
| <i>Nomenclature</i> | <i>2</i> |
| <i>Safety Precautions</i> | <i>3</i> |
| <i>System Parts</i> | <i>4</i> |
| <i>System Functions</i> | <i>5-7</i> |
| <i>Wired Tether Controller</i> | <i>8-16</i> |
| <i>Wireless Remote Controller</i> | <i>17-22</i> |
| <i>Care and Cleaning</i> | <i>23</i> |
| <i>Troubleshooting</i> | <i>24</i> |
| <i>Diagnostic Codes</i> | <i>25-28</i> |
| <i>Energy Saving Tips</i> | <i>29</i> |
| <i>Warranty</i> | <i>Back</i> |

INTRODUCTION

Superior Design for Superior Performance

Compact and powerful, this Gree Slim Concealed Duct indoor unit offers the ultimate in flexibility and discretion. It is designed to be concealed above suspended ceilings or within open closet spaces to deliver conditioned air via ducting and suitable ceiling or wall grilles. This arrangement provides immense flexibility, in terms of both the distribution of conditioned air and the type of grille or diffuser that best complements any room's styling. Your unit is easily operated from the wall-mounted wired Tether Controller, or the infrared wireless Remote Controller.

Like all Gree systems, this unit provides quiet comfort and energy efficient heating and cooling. For many residential and light commercial applications, it is the ideal solution to balance comfort, efficiency and ease of use. The Slim Concealed Duct unit works in conjunction with the Multi21 outdoor compressor section, featuring Gree's exclusive G-10 Inverter technology. The Inverter constantly adjusts compressor speed to save energy, reduce outdoor noise and maintain a steady room temperature, by eliminating the harsh starts and stops of conventional systems.

Thank you for selecting this Gree air conditioner. Before operating your unit, please read this manual carefully and retain it for further reference.

NOMENCLATURE

Example: DUCT24HP230V1AD

DUCT 24 HP 230V 1 A D

Series Designation

MULTI - Multiple Port Outdoor Unit
DUCT - Slim Duct
CAS - Ceiling Cassette
FLR - Floor/Ceiling
CONS - Floor Console

Cooling Capacity

09 - 9,000 BTUH
12 - 12,000 BTUH
18 - 18,000 BTUH
24 - 24,000 BTUH
30 - 30,000 BTUH
36 - 36,000 BTUH

Model Type

AC - Cooling Only
HP - Heat Pump
HC - Heat/Cool

Product Type

S - System
O - Outdoor units
H - Indoor High Wall
D - Indoor Duct
C - Indoor Cassette
F - Indoor Floor/Ceiling

Revision Level


Style/Color Designation

Electrical Rating

230V - 208/230V 60Hz 1PH
115V - 115V 60Hz 1PH

SAFETY PRECAUTIONS

Please read the following before operation.

Recognize safety information.  This is the safety-alert symbol. When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury. Understand these signal words: **DANGER**, **WARNING**, and **CAUTION**. These words are used with the safety-alert symbol.

DANGER identifies the most serious hazards which will result in severe personal injury or death.

WARNING signifies hazards which could result in personal injury or death.

CAUTION is used to identify unsafe practices which may result in minor personal injury or product and property damage.

NOTE is used to highlight suggestions which will result in enhanced installation, reliability, or operation.

NOTE: Your actual air conditioning & heating system and related devices may differ from the images shown in this manual.

WARNING

This appliance is not intended for use by children without responsible adult supervision. Proper care should be taken to ensure safety.

WARNING

Heat pumps, air conditioners & heating equipment should be installed, started up, and serviced only by qualified installers and service technicians. Air conditioning, heat pumps and refrigeration systems are hazardous due to high voltage electrical components, high refrigerant pressures, and moving parts.

WARNING


- Disconnect electrical power to the indoor and outdoor units before performing any maintenance or cleaning.
- Do not attempt to repair the Gree system yourself. Incorrect repairs may cause electric shock or fire. Contact a qualified service technician for all service requirements.
- Keep combustible materials away from the unit.

CAUTION

- Do not put hands or any objects into the air inlets or outlets. This may cause personal injury or damage the unit.
- When cleaning, be careful not to splash water on the unit. Doing this may cause electric shock or damage to unit.
- In the event of a failure (burning smell, etc.), immediately disconnect all electrical power to indoor and outdoor units.


SYSTEM PARTS

Indoor Unit




Part Name

1. Gas & Liquid Pipes
2. Electric Box
3. Interconnection Cable
4. XK-19 Wired Tether Controller
5. Remote Controller
6. Interconnection Cable
7. Front Panel
8. Service Cover
9. Liquid Pipe
10. Gas Pipe
11. Drain Hose
12. Outdoor Power Supply



Outdoor Unit



CAUTION

The refrigerant pipe, drain pipe, electrical wiring, and duct for this unit should be installed by a qualified HVAC professional only.

SYSTEM FUNCTIONS

WHISPER QUIET

Not only are the Gree systems energy efficient but they are quiet too. Slim Duct operates with sound levels starting as low as 31 dB(A).

MULTI FAN SPEEDS

Whether operating in either Cooling or Heating mode, the indoor fan can be set to your choice of three different speeds (Low, Medium or High) to achieve maximum comfort.

BUILT IN CONDENSATE LIFT PUMP

The unit features a built-in drain pump that lifts condensate up to 11 inches above the drain pan to a gravity condensate drain system. In most cases, the internal condensate lift mechanism will avoid the need for an external condensate pump.

CONDENSATE SENTRY

The unit's fail-safe mechanism recognizes when there is a high level in the condensate pan and shuts off the system to prevent overflow.

INTELLIGENT PRE-HEATING

Slim Duct guards against the annoying cool air blown into the room in heating mode. The system constantly monitors the discharge air temperature. It will delay the indoor fan until the indoor coil has warmed up to prevent blowing uncomfortable cool air into the room.

CONTROLLERS

The Slim Duct unit comes with a factory supplied Wireless Remote Controller and a Wired Tether Controller.

WIRELESS REMOTE

The Gree multi-functional infrared hand held wireless controller is sleek, ergonomically designed, easy to use and has a large backlit LCD display.

TETHER CONTROLLER

The Gree wired Tether Controller mounts to the wall up to 26 feet from the unit. It provides complete control over your unit's operation mode, desired temperature, fan speed, airflow direction and more.

SYSTEM FUNCTIONS

INTELLIGENT DEFROST

The Intelligent Defrost function increases room comfort and saves energy by eliminating unnecessary defrost cycles. In heating mode, the unit will monitor the outdoor coil for frost buildup. Once frost buildup has been detected, the system will switch into a defrost mode to remove the frost.

I FEEL MODE

In Cooling Mode, the unit will sense room temperature at the Tether Controller instead of at the indoor unit. It then adjusts airflow and temperature accordingly for the ultimate in personal comfort control and energy savings.

POWER FAILURE MODE

Power interruptions are no problem for the Slim Duct system. User selections and system parameters are stored in non-volatile memory. These parameters are retained during a power failure. When power is returned, the Slim Duct system will automatically return to the last operating mode.

TURBO MODE

Use Turbo Mode for situations where you wish to achieve the desired room temperature in the shortest possible time. This mode runs the unit at ultra high speeds for quickest results.

CLOCK

The Tether and wireless controllers have a built-in clock feature. The remote will display the time of day in a 24-hour format.

TIMER MODE

The unit can be programmed to turn ON or OFF after a specific amount of time. The time period is adjustable between one half and 24 hours.

MODE BUTTON

The unit can be set to five different operating modes: HEAT, COOL, DRY, FAN ONLY and AUTO.

NOTE: AUTO MODE has fixed setpoints of 68 °F heating and 78 °F cooling, which are not adjustable. The system will automatically select heating or cooling to maintain room temperature within this band.

FAHRENHEIT °F / CELSIUS °C

The remote controller can be set to display in either °F or °C.

SYSTEM FUNCTIONS

SLEEP MODE

The unit will automatically adjust room temperature during your sleep time. This slight change in temperature will not affect your comfort level due to the natural effects that sleeping has on the body, but it will save on energy consumption and will lower electric bills.

X-FAN MODE

When operating in humid areas, the X-fan or Dry Coil function allows the indoor fan to run for a pre-determined amount of time after the unit is turned off (cooling or dry modes) to ensure that additional moisture is removed from coil.

SELF-DIAGNOSIS

With an on-board computer using real-time diagnostics, the Slim Duct system helps to prolong its own life. The automatic diagnosis feature continuously scans for unacceptable operating conditions or malfunctions. If such conditions occur, the system takes corrective action or stops. Error codes are shown on the Tether Control display to facilitate easy troubleshooting and repair.

PRIVACY LOCK MODE

The Tether and wireless controllers have a Privacy Lock. The Privacy Lock averts unauthorized access or tampering with system settings.

AGENCY LISTINGS


All systems are listed with AHRI (Air conditioning, Heating, and Refrigeration Institute) and are ETL certified per UL Standards.

OPERATION OF WIRED TETHER CONTROLLER

Wired Tether Controller



INTRODUCTION FOR ICONS ON DISPLAY SCREEN




Part Name

- | | |
|-------------------------------------|---|
| 1. Swing Louver | 9. Keypad Lock Function |
| 2. Sleep Function | 10. Turbo Function State |
| 3. Auto Mode | 11. Memory Function (power failure recovery mode) |
| 4. Cool Mode | 12. Ambient/setting Temperature Value |
| 5. Dry Mode | 13. X-Fan Function |
| 6. Fan Mode | 14. Timer Function Value |
| 7. Heat Mode | |
| 8. Outdoor Unit Defrost Function | |


OPERATION OF WIRED TETHER CONTROLLER

ON/OFF BUTTON

Press On/Off to turn On the unit. Press again to turn it Off.





"Off" State



"On" State


MODE SETTING

When the unit is ON, press Mode button to select an operating mode. It will change sequentially as shown below: Auto–Cool–Dry–Fan–Heat



TEMPERATURE SETTING



Press ▲ or ▼ to increase/decrease the setpoint temperature as shown below. In Cool, Dry, Fan or Heat mode, the setpoint temperature range is 61°F - 86°F. In Auto mode, the setpoint temperature is not adjustable.



OPERATION OF WIRED TETHER CONTROLLER

FAN SETTING

When the unit is ON, press Fan button to select the fan speed of the indoor unit. It will change sequentially as shown below.






TURBO MODE


Turbo mode will force the unit up to maximum capacity to heat or cool the room in the shortest amount of time. Turbo Mode can only be used on Heat or Cool modes.

Turbo Setting

Press Function button until the Turbo icon is displayed. Then press Enter/Cancel to confirm. To cancel, press the Function button to re-enter the Turbo setting status, then press Enter/Cancel.



Turn On the unit and select Heat or Cool mode. Press Function until Turbo mode Icon is displayed. Press Enter/Cancel to start Turbo mode.



Cancel Turbo Mode

To cancel, press Function button to re-enter the Turbo settings, then press Enter/Cancel button.


OPERATION OF WIRED TETHER CONTROLLER

TIMER SETTING


The Slim Duct system has two timer modes. The Timer-On mode will turn the unit ON after the preset time period. The Timer-Off Mode will turn the unit OFF after the preset time period. The preset time period can be from 0.5 to 24 hours in 0.5 hour increments.

Timer-On Setting


Turn the unit Off, press the Timer button. The OFF icon will flash and the hours will be displayed. Set the time period for the unit to remain OFF before turning ON by pressing the ▲ or ▼ buttons. Press Timer button to confirm and start Timer-On mode.




Turn Off the unit.




Press Timer button to select Timer On mode.



Press ▲ or ▼ to select time period.



Press Enter/Cancel to start timer mode.




Cancel Timer

Timer modes can be cancelled anytime by pressing the Timer button.


OPERATION OF WIRED TETHER CONTROLLER

Timer-Off Setting


Turn the unit On, press the Timer button. The ON icon will flash and the hours will be displayed. Set the time period for the unit to remain ON before turning OFF by pressing the ▲ or ▼ buttons. Press Timer button to confirm and start Timer-Off mode.




Turn On the unit and select Heat or Cool mode.




Press Timer button to select Timer Off mode.



Press ▲ or ▼ to select time period.



Press Enter/Cancel to start timer mode.




Cancel Timer

Timer modes can be cancelled anytime by pressing the Timer button.

OPERATION OF WIRED TETHER CONTROLLER

SLEEP MODE

The unit will automatically adjust room temperature during your sleep time. This slight change in temperature will not affect your comfort level due to the natural effects that sleeping has on the body, but it will save on energy consumption and will lower your electric bill. Press the SLEEP button to select Sleep Mode. The SLEEP  icon will appear.

In Cool or Dry modes:


The unit will run at current room setpoint for 1 hour. After 1 hour, the setpoint will increase by 2 °F. After 2 hours, the setpoint will increase by 4 °F and maintain this setpoint until Sleep Mode is canceled.

In Heat mode:

The unit will run at current room setpoint for 1 hour. After 1 hour, the setpoint will decrease by 2 °F. After 2 hours, the setpoint will decrease by 4 °F and maintain this setpoint until Sleep Mode is canceled.

Sleep Setting


Turn the unit On and select a mode (ex. Heat, Cool, or Dry). Press the Function button until the Sleep icon appears on the display. Press the Enter/Cancel button to start Sleep Mode.



Turn On the unit and select a mode.

Press Function until the Sleep icon is displayed.

Press Enter/Cancel to start Sleep Mode.



Cancel Sleep Mode

Press Function until the Sleep icon appears.
Press the Enter/Cancel button to cancel Sleep Mode.


OPERATION OF WIRED TETHER CONTROLLER

X-FAN MODE


The X-Fan function may only be selected in Cool and Dry modes. After the unit is turned Off, the X-Fan function will keep the indoor fan running for a predetermined amount of time to dry the indoor evaporator coil to help avoid mold and mildew growth.

X-Fan Settings


Turn the unit On and select Cool or Dry mode. Press Function button until X-fan icon is displayed and then press Enter/Cancel to activate this function.




Turn On the unit, select Cooling or Dry mode.



Press Function until the X-fan icon is displayed.



Press Enter/Cancel to start X-fan mode.




Cancel X-Fan Mode

To cancel, press Function button to re-enter the X-Fan settings, then press Enter/Cancel button.

CELSIUS OR FAHRENHEIT TEMPERATURE DISPLAY

The wired Tether Controller is set from the factory to display temperature in Fahrenheit (°F). If Celsius (°C) is desired, turn the unit OFF, press Mode and ▼ buttons at the same time for 5 seconds to alternate between temperature displays.



To change temperature display.


OPERATION OF WIRED TETHER CONTROLLER

I-FEEL MODE


In Cool Mode, the Slim Duct unit will sense room temperature at the wired Tether Controller instead of at the return air section of the indoor unit.

I-Feel Settings


Press the Function button until the I-Feel icon is displayed, then press Enter/Cancel to activate the function.




Turn Unit On.



Press Function until the I-Feel icon is displayed.



Press Enter/Cancel to start I-Feel mode.




Cancel I-Feel Mode

To cancel, press Function button to re-enter the I-Feel settings, then press Enter/Cancel button.

PRIVACY LOCK

The Privacy Lock prevents unauthorized access to the unit controls and prevents tampering with system settings. To lock the wired Tether Controller, press ▲ and ▼ buttons simultaneously for 5 seconds and the Lock Icon will be displayed.

Repeat the process to unlock the Tether Controller and cancel Privacy Lock.



To activate Privacy Lock.

OPERATION OF WIRED TETHER CONTROLLER

POWER FAILURE MODES

The unit has two selectable system power up modes:

IMPORTANT: This mode arrives set at “factory default,” but should not be left there. It must be reset to “Power Failure Recovery,” especially for use in commercial IT/server/computer rooms.

Power Failure Recovery

After the initial power up, the unit will store user selections and system parameters in non-volatile memory. These parameters are retained during a power failure. When power is returned, the system will automatically return to the last operating mode.


Power Failure Standby

The system will power up in standby or off mode. This is the factory default setting.


POWER FAILURE MODE SETTINGS

To set Power Failure Recovery Mode, turn the unit OFF and press the Mode and ▲ buttons simultaneously for 5 seconds until the MEMORY Icon is displayed.


Repeat the process to select Standby mode. In Standby mode the Memory icon is not displayed.



Turn Unit Off.




Press Mode and ▲ buttons 5 sec until MEMORY icon is displayed.



Repeat to change Modes.

OPERATION OF WIRELESS REMOTE CONTROLLER


Remote Controller



Part Name

1. ON/OFF Button
2. Down Button
3. Up Button
4. Fan Button
5. Mode Button
6. I Feel Button
7. Clock Button
8. Timer On Button
9. X-Fan Button
10. Timer Off Button
11. Turbo Button
12. Sleep Button
13. Light Button

INTRODUCTION FOR ICONS ON DISPLAY SCREEN




OPERATION OF WIRELESS REMOTE CONTROLLER

REMOTE CONTROLLER OPERATIONS

The wireless remote controller is sleek, versatile and allows you to change room temperatures and functions on your Slim Duct system from the palm of your hand. The large LCD display and buttons make it easy-to-understand and easy-to-use.


The remote controller is set from factory to display temperatures in °F. If °C is desired, turn the remote controller **OFF** with the **ON/OFF** button and then press "**MODE**" and "**▼**" buttons on the remote simultaneously for 5 seconds.

ON/OFF BUTTON

When the system is in **OFF** mode, the remote controller will display the time and last room setpoint. When you press the **ON/OFF** button, this indicator  will be displayed and the unit will start in the last operating mode and room setpoint.

NOTE: If the **ON/OFF** button is pressed too soon after a stop, the compressor will not start for up to 5 min. due to the inherent protection against frequent compressor cycling.

I FEEL MODE

In Cool Mode, press this button to use the I FEEL function, and the () icon will be displayed. The unit will sense room temperature at the remote controller instead of at the indoor unit. It then adjusts airflow and temperature accordingly for the ultimate in personal comfort control and energy savings. Press the button again to exit this function. For best performance, keep remote controller away from heat or cold temperature sources while using this function.

LIGHT BUTTON

Press this button to turn off display light on indoor unit. Press again to turn it back on.



ON Mode Display



I Feel Mode



Light Display

OPERATION OF WIRELESS REMOTE CONTROLLER

MODE BUTTON

Use the “**MODE**” button to select one of the available modes. The selected mode will be displayed on the remote controller and the appropriate light will illuminate on the front display panel.

AUTO – Unit will automatically select heating or cooling to maintain room temperature between 68 °F and 77 °F. The remote controller will display the Auto Mode icon with no setpoint.

COOL – To cool to selected setpoint and remove moisture. Press ▲ or ▼ to adjust set temperature. System varies compressor speed to maintain desired temperature.


HEAT – To heat to selected room setpoint. Press ▲ or ▼ to adjust set temperature. System varies compressor speed to maintain desired room temperature.


FAN ONLY – To circulate air without heating or cooling. Use Fan Speed button to select speed from low to high.

DRY – Select **DRY MODE** to increase moisture removal during warm humid conditions. In this mode, fan speed cannot be adjusted.

1. If the Room Temperature is above or equal to the set temperature, the system will be operating with high fan speed for several minutes and then it will switch to the selected fan speed.
2. If the Room Temperature is below the set temperature, the system will be OFF and the indoor fan will be at low speed.

TURBO MODE

The desired room setpoint can be achieved faster in **TURBO** mode. After selecting the “**HEAT**” or “**COOL**” mode button, push the “**TURBO**” button. The **TURBO**  icon will be displayed on the remote controller and the unit will run at an ultra-high speed. To deactivate the feature, push the “**TURBO**” button again. The unit will return to normal operation.



Icons Displayed



Turbo Mode Display

OPERATION OF WIRELESS REMOTE CONTROLLER

FAN BUTTON

Press the FAN button to adjust the indoor fan speed:

Low (▲), Medium (▲▲), High (▲▲▲), Turbo and Auto.

- Turbo function is not available in Dry and Auto mode.
- The fan operates at low speed in Dry and Auto modes, and the speed cannot be adjusted.
- When Auto is selected, the unit will select the proper fan speed automatically, according to the ambient temperature.

NOTE: Turbo function is not available in Dry and Auto Modes. The Slim Duct unit will select proper fan speed automatically according to ambient temperature.



Fan Display

CLOCK SETTING

Press this button to set clock time. "⌚" icon on remote controller will blink. Within 5 seconds, press ▲ or ▼ button to set clock time. With each pressing of ▲ or ▼ buttons, clock time will increase or decrease 1 minute. To quickly adjust time setting, press and hold ▲ or ▼ button for 2 seconds. Release button when you have reached the desired time setting. Press "CLOCK" button to confirm the time, and "⌚" icon will stop blinking.

NOTE: Clock time adopts 24-hour mode. A 12-hour time format is not available.



Clock Setting Display

PRIVACY LOCK 🔒

The Privacy Lock prevents unauthorized access to the unit controls and prevents tampering with system settings. The remote controller can be locked by pushing the "▲" and "▼" buttons simultaneously for 5 seconds. The Privacy Lock icon will be displayed on the remote controller. Repeat the process to unlock the remote controller.



Privacy Lock Display

OPERATION OF WIRELESS REMOTE CONTROLLER

TIMER SETTING

Timer-ON / Timer-OFF BUTTON

To set when you want the unit to turn On at the end of a selected time period, use the button labeled "Timer-ON /Timer-OFF" on the remote controller. Press this button to make the clock icon disappear, replaced with the word "ON" (blinking). Press ▲ or ▼ buttons to adjust timer setting 1 minute at a time. Press and hold ▲ or ▼ button to set timer more quickly. Press "Timer-ON /Timer-OFF" button again to confirm setting, and the word "ON" will stop blinking. To cancel, press "Timer-ON /Timer-OFF" button again.





Timer Setting ON/OFF

To set when you want the unit to turn Off at the end of a selected time period, use the same button. Press this button to make the clock icon disappear, replaced with the word "OFF" (blinking). Adjust settings the same as with "Timer-ON /Timer-OFF" settings.

NOTE: Under Timer On and Off status, you can set "Timer-ON /Timer-OFF" simultaneously. Before setting timer, be sure to set clock to correct time.

SLEEP MODE

The Slim Duct system will automatically adjust room temperature during your sleep time. This slight change in temperature will not affect your comfort level due to the natural effects that sleeping has on the body, but it will save on energy consumption and will lower your electric bill. Press the SLEEP button to select Sleep mode or Cancel. The SLEEP  icon will appear.



Sleep Mode Display

TRADITIONAL MODE - SLEEP

In Traditional Mode the unit will slowly relax the room set temperature by up to 4 °F until Sleep Mode is cancelled.

In Cool or Dry modes:

The unit will run at current room setpoint for 1 hour. After 1 hour, the setpoint will increase by 2 °F (1°C). After 2 hours, the setpoint will increase by 4 °F (2°C) and maintain this setpoint until Sleep Mode is cancelled.

In Heat mode:

The unit will run at current room setpoint for 1 hour. After 1 hour, the setpoint will decrease by 2 °F (1°C). After 2 hours, the setpoint will decrease by 4 °F (2°C) and maintain this setpoint until Sleep Mode is cancelled.

OPERATION OF WIRELESS REMOTE CONTROLLER

CHANGING BATTERIES AND ADDITIONAL NOTES


To change batteries, slide cover off battery compartment on back of remote controller. Remove and safely discard old batteries. Insert two new AAA 1.5V dry batteries, using correct polarity. Reattach back cover.

NOTE:


- If the remote controller will not be used for a long time, remove batteries to prevent leakage damage.
- Be sure to aim the remote controller at the receiver of the main unit when operating.
- When remote emits a signal, icon will flicker; a tone will be heard when unit receives that signal.

CHANGING BATTERIES

**Remove
old batteries**



**Install
new batteries**



CARE AND CLEANING

CLEANING THE FILTER

- *Never remove the air filter from the unit except for cleaning; otherwise it may cause dust or dirt to restrict airflow to the unit.*
- *When the air conditioning unit is used in an environment with heavy dust, the air filter should be cleaned often (generally once every two weeks).*

Perform the following on an annual basis:

- *Clean or replace air filter.*
- *Inspect drain line for potential clogs or leaks.*
- *Hose off both sides of the coil in the outdoor unit to remove loose debris or dirt buildup.*



CAUTION

Take notice of the following items before cleaning your air conditioning unit.

- *To avoid electric shock or injury, do not attempt to clean the unit unless it has been turned off and disconnected from the main power supply.*
- *Do not wash the unit with water; this may cause an electric shock.*
- *During cleaning, be sure to use a stable standing platform.*

TROUBLESHOOTING

| PROBLEM | CAUSE/SOLUTION |
|--|--|
| System does not restart. | <p>Cause: The system has a built-in 5-minute delay to prevent short and/or rapid cycling of the compressor.</p> <p>Solution: Wait 5 minutes for the protection delay to expire.</p> |
| Indoor unit emits unpleasant odor when started | <p>Cause: Typically unpleasant odors are the result of mold or mildew forming on the coil surfaces or the air filter.</p> <p>Solution: Wash indoor air filter in warm water with mild cleaner. If odors persist, contact a qualified service professional to clean the coil surfaces.</p> |
| You hear a “water flowing” sound. | <p>Cause: It is normal for the system to make “water flowing” or “gurgling” sounds from refrigerant pressures equalizing when the compressor starts and stops</p> <p>Solution: The noises should discontinue as the refrigerant system equalizes after two or three minutes.</p> |
| A thin fog or vapor coming out of the discharge register when system is running. | <p>Cause: It is normal for the system to emit a slight fog or water vapor when cooling extremely humid warm air.</p> <p>Solution: The fog or water vapor will disappear as the system cools and dehumidifies the room space.</p> |
| You hear a slight cracking sound when the system stops or starts. | <p>Cause: It is normal for the system to make “slight cracking” sounds from parts expanding and contracting during system starts and stops.</p> <p>Solution: The noises will discontinue as temperature equalizes after 2 or 3 minutes.</p> |
| The system will not run. | <p>Cause: There are a number of situations that will prevent the system from running.</p> <p>Solution: Check for the following:</p> <ul style="list-style-type: none"> • Circuit breaker is “tripped” or “turned off.” • Power button of controller is not turned on. • Controller is in sleep mode or timer mode. • Otherwise, contact a qualified service professional for assistance. |
| The unit is not heating or cooling adequately. | <p>Cause: There are a number of reasons for inadequate cooling or heating.</p> <p>Solution: Check the following:</p> <ul style="list-style-type: none"> • Remove obstructions blocking airflow into the room. • Clean dirty or blocked air filter that is restricting airflow into the system. • Seal around door or windows to prevent air infiltration into the room. • Relocate or remove heat sources from the room. |
| Water leaking from the indoor unit into the room. | <p>Cause: While it is normal for the system to generate condensate water in cooling mode, it is designed to drain this water via a condensate drain system to a safe location.</p> <p>Solution: If water is leaking into the room, it may indicate one of the following.</p> <ul style="list-style-type: none"> • The indoor unit is not level right to left. Level indoor unit. • The condensate drain pipe is restricted or plugged. All restrictions must be removed to allow continuous drainage by gravity. • If problem persists, contact a qualified service professional for assistance. |
| The unit will not deliver air. | <p>Cause: There are a number of system functions that will prevent air flow.</p> <p>Solution: Check for the following:</p> <ul style="list-style-type: none"> • In heating mode, the indoor fan may not start for three minutes if the room temperature is very low. This is to prevent blowing cold air. • In heat mode, if the outdoor temperature is low and humidity is high, the system may need to defrost for up to 10 minutes before beginning a heating cycle. • In dry mode, the indoor fan may stop for up to three minutes during the compressor off delay. • Otherwise, you should contact a qualified service professional for assistance. |

DIAGNOSTIC CODES

Troubleshooting

The unit has onboard diagnostics. The outdoor unit will provide status indicators. The Tether controller will display error codes. The following is a summary of the codes with explanation:

| Malfunction Name | Tether Control Display | Outdoor Unit Indicators | | Possible Causes |
|---|------------------------|-------------------------|-------------------------|---|
| | | Yellow | Red | |
| Liquid Valve Coil Temperature Sensor Malfunction | b5 | | | <ol style="list-style-type: none"> 1) Loose or bad connection between sensor and control board 2) Liquid valve temperature sensor damaged 3) Control board malfunction |
| Gas valve temperature sensor is open/short circuited | b7 | | | Hardware malfunction |
| System Configuration Malfunction | C5 | | | <ol style="list-style-type: none"> 1) No jumper cap inserted on the control board 2) Incorrect or damaged jumper cap on control board 3) Indoor and outdoor units are not compatible |
| Wrong connection of communication wire or malfunction of electronic expansion valve | dn | | | Hardware malfunction |
| System High Pressure | E1 | | | <ol style="list-style-type: none"> 1) Over charged with refrigerant 2) Blocked or dirty outdoor coil 3) Extreme outdoor ambient conditions |
| Indoor Anti-Freeze Protection | E2 | 3 flashes and 1 sec Off | | <ol style="list-style-type: none"> 1) Low return airflow 2) Indoor fan speed is too low 3) Indoor coil is blocked or dirty |
| Low Pressure Protection | E3 | | 9 flashes and 1 sec Off | <ol style="list-style-type: none"> 1) Low on refrigerant 2) Pressure sensor is damaged |
| Compressor High Discharge Temperature Protection | E4 | 7 flashes and 1 sec Off | | Please refer to the malfunction analysis (discharge temperature, overload) in service manual |
| Overcurrent Protection | E5 | 5 flashes and 1 sec Off | | <ol style="list-style-type: none"> 1) Supply voltage is unstable 2) Supply voltage is too low and system load is too high 3) Indoor coil is blocked or dirty |
| Communication Malfunction | E6 | Continuous On | | <ol style="list-style-type: none"> 1) Communication cable is mis-wired between indoor and outdoor units 2) Indoor or Outdoor control board malfunction |
| Mode conflict (Indoor units calling for simultaneously Heating and Cooling) | E7 | | | Operation status |

DIAGNOSTIC CODES

| Malfunction Name | Tether Control Display | Outdoor Unit Indicators | | Possible Causes |
|--|------------------------|--------------------------|--------------------------|--|
| | | Yellow | Red | |
| High Temperature Resistant Protection | E8 | 6 flashes and 1 sec Off | | 1) Incorrect refrigerant charge level 2) Refrigerant metering device malfunction 3) Compressor malfunction |
| Cold Air Protection | E9 | | | 1) Indoor coil has not reach minimum heating temperature 2) Indoor ambient is abnormally cold 3) Indoor control board malfunction |
| EEPROM Memory Malfunction | EE | 11 flashes and 1 sec Off | | Control board malfunction |
| Module Phase Current Protection - Frequency Decrease/Limit Mode | En | | | Outdoor control board malfunction |
| Module Temperature Protection - Frequency Decrease/Limit Mode | EU | | 11 flashes and 1 sec Off | 1) IPM module over heating or malfunctioning 2) Improper voltage at IPM Module |
| Refrigerant Leakage Protection | F0 | | 9 flashes and 1 sec Off | 1) refrigerant leak(s) 2) Indoor coil temperature sensor no calibrated 3) Refrigerant flow is restricted (ex. valve, exv, debris) |
| Indoor Ambient Temperature Sensor Malfunction | F1 | | | 1) Loose or bad connection between sensor and control board 2) Indoor ambient temperature sensor damaged 3) Control board malfunction |
| Indoor Coil Temperature Sensor Malfunction | F2 | | | 1) Loose or bad connection between sensor and control board 2) Indoor coil temperature sensor damaged 3) Control board malfunction |
| Outdoor Ambient Temperature Sensor Malfunction | F3 | | 6 flashes and 1 sec Off | 1) Loose or bad connection between sensor and control board 2) Outdoor ambient temperature sensor damaged 3) Control board malfunction |
| Outdoor Coil Temperature Sensor Malfunction | F4 | | 5 flashes and 1 sec Off | 1) Loose or bad connection between sensor and control board 2) Outdoor coil temperature sensor damaged 3) Control board malfunction |
| Outdoor Discharge Temperature Sensor Malfunction | F5 | | 7 flashes and 1 sec Off | 1) Loose or bad connection between sensor and control board 2) Discharge temperature sensor damaged 3) Control board malfunction |
| Compressor Overload Protection - Frequency Decrease/Limit Mode | F6 | | 3 flashes and 1 sec Off | 1) Incorrect refrigerant charge 2) Metering device malfunction 3) Compressor malfunction |
| Oil Return Protection - Frequency Decrease/Limit Mode | F7 | | | Normal function status code only |
| System Current Overload Protection - Frequency Decrease/Limit Mode | F8 | | 1 flashes and 1 sec Off | 1) Input voltage too low 2) System pressure too low |

DIAGNOSTIC CODES

| Malfunction Name | Tether Control Display | Outdoor Unit Indicators | | Possible Causes |
|---|------------------------|--------------------------|-------------------------|--|
| | | Yellow | Red | |
| High Compressor Discharge Temperature - Frequency Decrease/Limit Mode | F9 | 2 flashes and 1 sec Off | 4 flashes and 1 sec Off | <ol style="list-style-type: none"> 1) Cooling load is too great 2) Outdoor ambient temperature too high 3) Refrigerant charge too low 4) Metering device malfunction |
| Indoor Coil Freeze Protection - Frequency Decrease/Limit Mode | FH | | | <ol style="list-style-type: none"> 1) Indoor coil has not reach minimum heating temperature 2) Indoor ambient is abnormally cold 3) Indoor control board malfunction |
| Pump Down or Gathering Refrigerant Status | Fo | 17 flashes and 1 sec Off | | Optional Service Mode |
| Defrost Mode in Heating | H1 | | | Operation status |
| Compressor Overload Protection | H3 | 8 flashes and 1 sec Off | | <ol style="list-style-type: none"> 1) Wiring terminal OVC-COMP is loose 2) Refer to the malfunction analysis in Service Manual |
| IPM Module Protection | H5 | 4 flashes and 1 sec Off | | <ol style="list-style-type: none"> 1) IPM module over heating 2) Improper or Low voltage at the IPM module 3) IPM module malfunction |
| Indoor DC Fan Motor Malfunction | H6 | | | <ol style="list-style-type: none"> 1) Loose connections between fan motor and control board 2) Fan motor or blower wheel bearings malfunction 3) Control board malfunction |
| Compressor De-Synchronized Malfunction | H7 | | | <ol style="list-style-type: none"> 1) Compressor voltage is not balance 2) Control board malfunction 3) Compressor malfunction |
| Power Factor Correction (PFC) Protection | HC | 14 flashes and 1 sec Off | | <ol style="list-style-type: none"> 1) Mis-wiring of the reactor filter and PFC capacitor 2) Reactor filter or PFC capacitor malfunction 3) Control board malfunction |
| Compressor Demagnetization Protection | HE | | | Compressor malfunction |
| High Input Power Protection | L9 | 9 flashes and 1 sec Off | | <ol style="list-style-type: none"> 1) Compressor malfunction 2) Power circuit malfunction |
| Start-Up Malfunction | LC | | | <ol style="list-style-type: none"> 1) Over charged with refrigerant 2) Control board malfunction 3) Compressor malfunction |
| Compressor phase-lacking/phase-inverse protection | Ld | | | Hardware malfunction |

DIAGNOSTIC CODES

| Malfunction Name | Tether Control Display | Outdoor Unit Indicators | | Possible Causes |
|---|------------------------|--------------------------|-----|--|
| | | Yellow | Red | |
| Incompatible Indoor and Outdoor Units | LP | 16 flashes and 1 sec Off | | Indoor and outdoor units are not compatible |
| Compressor Phase Current Protection | P5 | | | 1) IPM module malfunction 2) Outdoor control board malfunction 3) Compressor malfunction |
| Module Temperature Sensor Malfunction | P7 | | | Outdoor control board malfunction |
| Module Temperature Protection | P8 | | | 1) Lack of thermal grease on IPM module 2) Heat sink (radiator) not tightly mounted 3) Control board malfunction |
| High DC Bus Voltage Protection | PH | 13 flashes and 1 sec Off | | 1) Supply voltage on L1 and N is above 265Vac 2) Capacitor on control board malfunction 3) Outdoor control board malfunction |
| Low DC Bus Voltage Protection | PL | 12 flashes and 1 sec Off | | 1) Supply voltage on L1 and N is below 150Vac 2) Capacitor on control board malfunction 3) Outdoor control board malfunction |
| Capacitor Charging Malfunction | PU | | | Capacitor malfunction |
| Compressor Phase-Current Detection Malfunction | U1 | | | Outdoor control board malfunction |
| DC Bus Voltage Dip | U3 | | | Outdoor control board malfunction |
| Input Current Detection Malfunction | U5 | | | Outdoor control board malfunction |
| The four-way valve is abnormal | U7 | | | Hardware malfunction |
| Zero cross detection circuit malfunction(for indoor unit) | U8 | | | Hardware malfunction |

Notes: 1) During defrosting process, the heating indicator is on for 10s and off for 0.5s.
2) Refer to Service Manual for additional information.

ENERGY SAVING TIPS

- 1. Relaxing room temperature at night is OK:** During the nighttime hours you don't require the same level of conscious cooling or heating. Try using Sleep Mode to gradually relax room temperature and allow the unit to run less and save energy.
- 2. Curtains and shades:** In the summer, you need to block the effects of the sun. Close window curtains and shades on the south and west side of your home to help block solar heat. In winter, the sun is your friend. Open curtains and shades to allow solar heat into your room.
- 3. Close doors:** If you don't need to heat and cool your whole home, confine the heating and cooling to one room by closing doors. Limit the space you're heating and cooling to specified capability of the unit.
- 4. Service the unit:** Some basic maintenance might be all you need. The outdoor unit will greatly benefit from a good hosing out, especially in treed areas where seeds and other debris can stick to coil fins and make the unit work up to 15% harder!
- 5. Rearrange the room:** Furniture that obstructs airflow means you could be heating and cooling the back of a chair or the front of a sofa instead of the actual living space. Remove or rearrange obstacles blocking airflow.
- 6. Try 75 degrees:** 75 °F is a good point for an air conditioner to run at its optimal performance level. Even a 5-degree change in temperature can make your unit use up to 40% more energy!
- 7. Lighting:** Turning lights off can help reduce your heat. Each light bulb is a tiny heater. Your air conditioner must waste energy overcoming the heat from your lights to reach and hold your desired room temperature.
- 8. Is anyone home?** If possible, while you're away turn your unit to Auto mode and make sure windows and drapes are closed. Although room temperature may be less than optimal for a few minutes when you come home, the unit will soon have the room back to your desired temperature.
- 9. Don't forget the fan:** The fan is much like a car. The faster it runs, the more energy it uses. Sometimes we need the car to go fast, but slow is good enough most of the time. Try saving money by using the comfortable quiet low fan speed as much as possible.



LIMITED WARRANTY STATEMENT

FOR WARRANTY SERVICE OR REPAIR: Contact your installing contractor. You may find the installer's name on the equipment or in your Owner's packet or on your invoice.

ONLINE REGISTRATION IS AVAILABLE AT: www.greecomfort.com/resources/product-warranty/

Or complete product registration below:

Email completed form* to: service@twclimate.com

or
Send copy of completed form* to:

Gree Warranty Registration

14610 Breakers Dr.

Jacksonville, FL 32258

* Keep copy of completed form for your files.

PRODUCT REGISTRATION

Indoor Model No: _____ Serial No: _____

Outdoor Model No: _____ Serial No: _____

Owner Name: _____ Date of Installation: _____

Address of Installation: _____

Installing Contractor: _____

Address: _____

Phone No. / Email: _____

GREE distributor (hereinafter "Company") warrants this product against failure due to defect in materials or workmanship under normal use and maintenance as follows. All warranty periods begin on the date of original installation. If the date cannot be verified, the warranty period begins one hundred twenty (120) days from date of manufacture. If a part fails due to defect during the applicable warranty period, Company will provide a new or remanufactured part, at Company's option, to replace the failed defective part at no charge for the part. This limited warranty is subject to all provisions, conditions, limitations and exclusions listed below.

- A warranty period of Five (5) years on all parts to the original registered end user when installed in a residential application.
- A warranty period of One (1) year on all parts to the original registered end user, when installed in commercial applications.
- A warranty period of 90 days on remote controls from purchase date.
- Limited warranty applies only to systems that are properly installed by a state certified or licensed HVAC contractor, under applicable local and state law in accordance with all applicable building codes and permits; GREE installation and operation instructions and good trade practices.
- Warranty applies only to products remaining in their original installation location.
- Defective parts must be returned to the distributor through a registered servicing dealer for credit.

LIMITATIONS OF WARRANTIES: ALL IMPLIED WARRANTIES AND/OR CONDITIONS (INCLUDING IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR USE OR PURPOSE) ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY OR CONDITION LASTS, SO THE ABOVE MAY NOT APPLY TO YOU. THE EXPRESS WARRANTIES MADE IN THIS WARRANTY ARE EXCLUSIVE AND MAY NOT BE ALTERED, ENLARGED, OR CHANGED BY ANY DISTRIBUTOR, DEALER, OR OTHER PERSON, WHATSOEVER.

THIS WARRANTY DOES NOT COVER:

1. Labor or other costs incurred for diagnosing, repairing, removing, installing, shipping, servicing or handling of either defective parts, or replacement parts, or new units.
2. Product cleaning required prior to warranty service and repair.
3. Normal maintenance as outlined in the installation and servicing instructions or Owner's Manual, including filter cleaning and/or replacement and lubrication.
4. Failure due to faulty installation or repairs, damage, misapplication, abuse, improper servicing, lack of or insufficient maintenance, unauthorized alteration or improper operation.
5. Failure to start due to voltage conditions, blown fuses, open circuit breakers, or damages due to the inadequacy or interruption of electrical service.
6. Failure or damage due to floods, winds, fires, lightning, accidents, corrosive environments (rust or residue etc.) or other conditions beyond the control of the Company.
7. Failure or damage of coils, piping or other parts due to corrosion, when installed within one (1) mile of sea coast or corrosive body.
8. Parts not supplied or designated by Company, or damages resulting from their use.
9. Products installed outside the 48 contiguous United States, except the District of Columbia and Hawaii.
10. Electricity or fuel costs, or increases in electricity or fuel costs from any reason whatsoever, including additional or unusual use of supplemental electric heat.
11. Any cost to replace, refill or dispose of refrigerant, including the cost of refrigerant.
12. Shipping damage or damage as a result of transporting the unit.
13. Accessories such as condensate pumps, line sets and so forth are not covered.
14. Any special, indirect or consequential property or commercial damage of any nature whatsoever. Some states do not allow the exclusion of incidental or consequential damages, so the above limitation may not apply to you.
15. Consumable components, such as air filters, are not covered under parts warranty.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.