



SECURE CHASSIS TO WALL SLEEVE

THE SIX (6) SCREWS PROVIDED IN THIS BAG ARE TO BE USED TO SECURE THE CHASSIS TO THE WALL SLEEVE. THREE (3) SCREWS SHOULD BE USED ON EACH SIDE OF THE UNIT TO SECURE IT PROPERLY TO THE WALL SLEEVE. IF ALL THREE (3) SCREWS ARE NOT USED, THE CHASSIS MAY NOT BE DRAWN IN TIGHTLY TO THE WALL SLEEVE. THIS COULD CAUSE UNSATISFACTORY OPERATION.

INSERT EACH SCREW THROUGH THE HOLE IN THE SIDE SEAL OF THE CHASSIS AND SECURE INTO THE "TINNERMAN CLIPS" IN THE WALL SLEEVE. REPEAT FOR EACH OF THE SIX SCREWS. SEE DRAWING TO LOCATE PLACEMENT OF EACH SCREW.