

Attach the chimney pot over the Clay Flue Liner using Tap-Con® screws or bolts and anchors. It is recommended to apply silicone to the screw threads to seal the penetration.

*If installing to a metal flue pipe, it is recommended to use the optional metal sleeve adapter and appropriate mounting hardware.

